Industrial automation Elincom Group European Union: www.elinco.eu Russia: www.elinc.ru

# OMRON

## **Programmable Terminal**

NA-series Software

**User's Manual** 

NA5-15 101 NA5-12 101 NA5-9 001 NA5-9 001





V118-E1-04

#### NOTE

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

#### - Trademarks

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD and SDHC logos are trademarks of SD-3C, LLC.
- Portions of this software are copyright 2014 The FreeType Project (www.freetype.org). All rights reserved.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

#### Copyrights

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

## Introduction

Thank you for purchasing an NA-series Programmable Terminal.

This manual contains information that is necessary to use the NA-series Programmable Terminal. Please read this manual and make sure you understand the functionality and performance of the NA-series Programmable Terminal before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

### **Intended Audience**

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- · Personnel in charge of introducing FA systems.
- · Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- Personnel in charge of managing FA systems and facilities.

### **Applicable Products**

This manual covers the following products.

- NA-series Programmable Terminals<sup>\*1</sup>
- \*1. Unless otherwise specified, the descriptions for the NA5-DDWDDD apply to the NA5-DDUDDD as well.

## **Relevant Manuals**

The basic information required to use an NA-series PT is provided in the following three manuals.

- NA-series Programmable Terminal Hardware User's Manual (Cat. No. V117)
- NA-series Programmable Terminal Software User's Manual (Cat. No. V118)
- NA-series Programmable Terminal Device Connection User's Manual (Cat. No. V119)

Operations are performed from the Sysmac Studio Automation Software.

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Sysmac Studio.

Other manuals are necessary for specific system configurations and applications.

The following manual is also available to walk you through installations and operations up to starting actual operation using simple examples.


Refer to it as required.

• NA-series Programmable Terminal Startup Guide Manual (Cat. No. V120)

## **Manual Structure**

### **Page Structure and Markings**

The following page structure is used in this manual.



Note This illustration is provided only as a sample. It may not literally appear in this manual.

### **Special Information**

Special information in this manual is classified as follows:



#### Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.

#### Precautions for Correct Use

Indicates precautions on what to do and what not to do to ensure proper operation and performance.



#### **Additional Information**

Additional information to read as required.


This information is provided to increase understanding or make operation easier.



#### **Version Information**

Information on differences in specifications and functionality with different versions is given.

## **Sections in this Manual**



## CONTENTS

Introduction	1
Relevant Manuals	2
Manual Structure	3
Sections in this Manual	5
Terms and Conditions Agreement	11
Safety Precautions	13
Precautions for Safe Use	15
Precautions for Correct Use	18
Regulations and Standards	19
Related Manuals	21
Terminology	25
Revision History	

### Section 1 Introduction to the NA-series Programmable Terminals

1-1	NA-se	eries Programmable Terminals	
	1-1-1	Features	
1-2	How I	HMIs Operate	
	1-2-1	HMI Software Configuration	
	1-2-2	HMI Projects	
	1-2-3	Pages	
	1-2-4	Objects	
	1-2-5	Memory Specifications for Connected Devices	1-6
	1-2-6	Events	1-7
	1-2-7	Subroutines	
	1-2-8	Functions Shared by the Entire HMI Project	
	1-2-9	Data That Retained When Power Is Turned OFF	
1-3	Opera	ating Procedure for HMIs	
	1-3-1	Overall Procedure	
	1-3-2	Procedure Details	1-11

### Section 2 Basic Sysmac Studio Operations

2-1	Parts of the Sysmac Studio Window	2-2
	2-1-1 Application Window	
2-2	Menu Command Structure	
2-3	Basic Editing Operations	
2-4	Sysmac Studio Settings and Operations	
	2-4-1 Setting Parameters	
	2-4-2 Programming	
	2-4-3 Library Functions	2-11

	2-4-5	Operations for Debugging Communications Security Measures	
	2-4-7	Online Help	2-12
		One methods a fear LINI Drack sta	0.40
2-5	Basic	Operations for HMI Projects	
2-5		Creating a Project File from the Project Window	
2-5	2-5-1	• •	

## Section 3 HMI Configuration and Setup

3-1	Outline of Configurations and Setup           3-1-1         Connected Device Registration and Variable Mapping	
2 2		
3-2	Device References           3-2-1         Types of Connected Devices	
	3-2-1 Types of Connected Devices	
	3-2-3 Registering External Connected Devices	
3-3	Mapping Variables	
00	3-3-1 Mapping Variables	
	3-3-2 Opening the Variable Mapping Tab Page and Tab Page Parts	
	3-3-3 Variable Mapping Methods	
3-4	HMI Settings	
• •	3-4-1 HMI Settings	
	3-4-2 Device Settings	
	3-4-3 TCP/IP Settings	
	3-4-4 FTP Settings	
	3-4-5 NTP Settings	
	<ul><li>3-4-6 FINS Settings</li><li>3-4-7 VNC Settings</li></ul>	
	3-4-7     VNC Settings       3-4-8     Printing Settings	
3-5	Security Settings	
3-6	Troubleshooter	
3-7	Language Settings	
3-8	HMI Clock	
3-9	Updating the HMI Name	
3-10	Write Protecting the HMI	
	Clear All Memory	
	2 Resetting the HMI	

## Section 4 Creating the HMI Application

4-1	Regis	stering Variables	
	4-1-1	Variables	
	4-1-2	Registering Global Variables	
	4-1-3	Registering External Variables	
	4-1-4	Attributes and Entry Methods for Global Variables	
	4-1-5	System-defined Variables	
	4-1-6	Subroutine Variables	
4-2	Regis	stering Data Types	
4-3	Creat	ing Pages	
	4-3-1	• •	
	4-3-2	Registering Pages	
	4-3-2 4-3-3	Registering Pages Page Property Settings	
	<b>Creat</b> 4-3-1	ing Pages Displaying Pages	<b>4-1</b> 4

4-4	Settin	g Common Object Functions	
	4-4-1	Registering User Alarms	
	4-4-2	Setting Controller Events	4-23
	4-4-3	Registration for Data Logging	4-26
	4-4-4	Registering Data Groups	4-27
	4-4-5	Registering Recipes	4-28
	4-4-6	Registering Custom Keypads	4-29
	4-4-7	Setting Global Events and Corresponding Actions	4-31
	4-4-8	Registering Global Subroutines	4-34
	4-4-9	Setting Up Resources	4-35
	4-4-10	Setting Up IAG Resources	4-36
	4-4-11	Registering Scaling	4-37
4-5	Subro	utines	
	4-5-1	Subroutine Execution	
	4-5-2	Precautions on Internal Processing	
	4-5-3	Code Editor	4-45
	4-5-4	Differences in Language Specifications	4-45
4-6	Searc	h and Replace	
4-7	Cross	References	
	4-7-1	Cross References	
4-8	Buildi	ng	
	4-8-1	Building	
	4-8-2	Build Operation	
4-9	Offline	e Comparison	
- J	5		

### Section 5 Objects

5-1	Obied	ts	
	-	Object List	
	5-1-2	Object Attributes	
	5-1-3	Using Objects	
5-2	Exam	ples of Using Objects	5-12
	5-2-1	Displaying a PDF File	5-12
	5-2-2	Displaying a User Alarm	
	5-2-3	Displaying a Trend Graph	5-16
	5-2-4	Displaying a Broken-line Graph	
	5-2-5	Using a Recipe	
	5-2-6	Setting the Order of Automatic Move of Input Focus	
	5-2-7	Displaying Text Strings by Indirect Addressing	

## Section 6 Connecting to the HMI

6-1	Introd	luction	6-2
6-2	Going	g Online with an HMI	
		Methods for Going Online with an HMI	
		Setting the Connection Method	
	6-2-3	Online Connection	
	6-2-4	Going Online after Checking the Connection Method	
		Going Offline	
		Confirming Serial IDs	

### Section 7 Debugging

7-1	HMI D	ebugging Functions	7-2
	7-1-1	Watch Tab Page	
	7-1-2	Breakpoints	7-3

7-1-3	Step Execution	.7-4
7-1-4	Offline Debugging with Only the HMI Simulator	.7-6
7-1-5	Offline Debugging with the Controller Simulator	.7-7

### Section 8 Synchronizing Projects

8-1	Syncl	hronizing Projects	
8-2	Down	lloading	
		Downloading While Online	
		Using Storage Media for Downloading	
8-3	Uploa	ading	
		Uploading Projects Online	
	8-3-2	Uploading with Storage Media	
		Relinking Internal Devices	

### Section 9 Reusing Objects

9-1	Reusing Objects			
9-2	IAGs			
	9-2-1	Differences when an IAG Project Is Selected		
	9-2-2	Creating an IAG		
		Using IĂGs		
9-3	Custom Objects			
	9-3-1	Objects That You Can Register as Custom Objects		
	9-3-2	Creating Custom Objects		
	9-3-3	Deleting Custom Objects		
	9-3-4	Using Custom Objects		

### Section 10 Connecting to HMIs from External Devices

10-1	Acces	sing an HMI from an External Device	10-2
		VNC	
	10-1-2	FTP	. 10-3

### Section 11 Other Functions

11-1	Sysmac Studio Option Settings	11-2
11-2	Printing	11-4
	11-2-1 Printable Items	

### Appendices

A-1	Events and Actions	A-2
A-2	Supported Formats	A-5
A-3	Differences between the Physical HMI and Simulator	A-7
A-4	Version Upgrade History	A-8
A-5	Precautions for Version Upgrades	A-11

### Index

## **Terms and Conditions Agreement**

### Warranty, Limitations of Liability

### Warranties

#### Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

### Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

### • Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

### Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CON-SEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

### **Application Considerations**

### Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

### **Programmable Products**

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

#### Disclaimers

### Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

### **Change in Specifications**

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

### **Errors and Omissions**


Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

## **Safety Precautions**

### **Definition of Precautionary Information**

The following notation is used in this manual to provide precautions required to ensure safe usage of the NA-series Programmable Terminal. The safety precautions that are provided are extremely important to safety. Always read and heed the information provided in all safety precautions.

The following notation is used.



## Precautions for Correct Use

Indicates precautions on what to do and what not to do to ensure proper operation and performance.

### Symbols




The circle and slash symbol indicates operations that you must not do. The specific operation is shown in the circle and explained in text. This example indicates prohibiting disassembly.



The triangle symbol indicates precautions (including warnings). The specific operation is shown in the triangle and explained in text. This example indicates a general precaution.

### Warnings


## 



Never press two points or more on the touch panel of the NA Unit at a time. Touching two points or more interrupts normal touch panel operations.

## **Precautions for Safe Use**

- When unpacking the NA Unit, check carefully for any external scratches or other damages. Also, shake the NA Unit gently and check for any abnormal sound.
- The NA Unit must be installed in a control panel.
- The mounting panel must be between 1.6 and 6.0 mm thick. Tighten the Mounting Brackets evenly to
  a torque of between 0.5 and 0.6 N·m to maintain water and dust resistance. If the tightening torque
  exceeds the specified value, or the tightening is not even, deformation of the front panel may occur.
  What is more, make sure the panel is not dirty or warped and that it is strong enough to hold the NA
  Unit.
- Do not let metal particles enter the NA Unit when preparing the panel.
- Turn OFF the power supply before connecting or disconnecting cables.
- Periodically check the installation conditions in applications where the NA Unit is subject to contact with oil or water.
- Be certain to use the cables with lock mechanism such as serial cable or the Ethernet cable after confirming if it is securely locked.
- Do not touch the packaging part of the circuit board with your bare hands. Discharge any static electricity from your body before handling the board.
- Do not use volatile solvents such as benzene and thinners or chemical cloths.
- Water and oil resistance will be lost if the front sheet is torn or is peeling off. Do not use the NA Unit, if the front sheet is torn or is peeling off.
- As the rubber packing will deteriorate, shrink, or harden depending on the operating environment, periodical inspection is necessary.
- Confirm the safety of the system before turning ON or OFF the power supply, or pressing the reset switch.
- The whole system may stop depending on how the power supply is turned ON or OFF. Turn ON/OFF the power supply according to the specified procedure.
- · Operate DIP switch according to the following way.



The DIP switch may break if it is levered with a tool against the case as shown in the figure.

- Once the DIP switch settings are changed, reset by pressing the reset switch, or restart the power supply.
- Initialize the project, after confirming that existing project is backed up at the Sysmac Studio.
- When changing the password, do not reset or turn OFF the power supply until the writing is completed. A failure to store the password may cause the project to fail to function.
- While uploading or downloading a project or a system program, do not perform the operations as follows. Such operations may corrupt the project or the system program:
  - Turning OFF the power supply of the NA Unit
  - Resetting the NA Unit.
  - Removing the USB devices or SD card.
  - Disconnecting the cable between a support tool and the NA Unit.
- Do not connect an AC power supply to the DC power terminals.
- Do not perform a dielectric strength test.

- Use a DC power with a slight voltage fluctuation and that will provide a stable output even if the input is momentarily interrupted for 10 ms. Also use the one with reinforced insulation or double insulation. Rated Power Supply Voltage: 24VDC (Allowable range 19.2 to 28.8VDC)
- Use a power cable with AWG#12 to #22 thick (0.35mm2 to 3.31mm2). Peel the coating 7mm length and tighten the terminal screw with the torque in the range of 0.5 to 0.6 N·m. Also confirm if the terminal screw is tighten appropriately.
- To prevent malfunctions caused by noise, ground the NA Unit correctly.
- Do not use any battery if strong impact is applied to it (e.g. by dropping on the floor) because such a battery may cause a leakage.
- · Confirm the type of the battery to install the battery properly.
- Apply power for at least five minutes before changing the battery. Mount a new battery within five minutes after turning OFF the power supply. If power is not supplied for at least five minutes, the clock data may be lost. Check the clock data after changing the battery.
- Do not dismantle a battery nor let it short-circuit.
- Do not apply an impact with the lithium battery, charge it, dispose it into a fire, or heat it. Doing either of them may cause an ignition or a bursting.
- Dispose of the NA Units and batteries according to local ordinances as they apply.



• The following precaution must be displayed on all products containing lithium primary batteries with a perchlorate content of 6ppb or higher when exporting them to or shipping them through California, USA.

Perchlorate Material - special handling may apply.

See www.dtsc.ca.gov/hazardouswaste/perchlorate

The NA-Series contains a lithium primary battery with a perchlorate content of 6ppb or higher. When exporting a product containing the NA-Series to or shipping such a product through California, USA, label all packing and shipping containers appropriately.

- Do not connect the USB devices in the environment subject to the strong vibration.
- · Do not connect USB devices which are not allowed to connect to NA Unit.
- Start actual system application only after checking normal operation of the system including storage devices such as USB memory and SD card.
- When connecting peripheral devices which do not meet the performance level of the NA Unit for noise and static electricity, ensure sufficient countermeasures against noise and static electricity during installation of the peripheral devices to the NA Unit.
- Do not carry out the following operations when accessing USB devices or SD card:
  - · Turning OFF the power supply of the NA Unit
  - · Press the Reset switch of the NA Unit
  - · Pull out the USB devices or SD card
- When using the No. 6 pin of the serial port connector for a voltage of DC+5V, make sure the supply equipment's current capacity is below 250mA before using it. The DC+5V voltage output of the NA Unit is +5V±5%, and the maximum current is 250mA.
- To ensure the system's safety, make sure to incorporate a program that call periodically signals during the operation at connected device side and can confirm the normal functionality of the NA Unit before running the system.
- Start actual system application only after sufficiently checking project, subroutine and the operation of the program at the connected device side.
- To execute a subroutine with multiple threads, fully check the operation of the program that takes multithreads into consideration, before starting actual system application.
- To use numeric input functions safely, always make maximum and minimum limit settings.
- Do not press the touch panel with a force greater than 30 N.

- Do not use hard or pointed objects to operate or scrub the screen, otherwise the surface of the screen may be damaged.
- The deterioration over time may cause the touch points to move on the touch panel. Calibrate the touch panel periodically.
- A touch position detection error of approximately 20 pixels may occur due to the precision of the touch panel. Always take this into account when positioning objects on the panel so adjoining objects will not be activated by mistake.
- Confirm the safety of the system before pressing the touch panel.
- Do not accidentally press the touch panel when the backlight is not lit or when the display does not appear or is too dark to identify visually.
- You can change the brightness by changing the setting such as in the system menu or by downloading project.

If the brightness is set to very dark, it causes flickering or unreadable screen. Additionally, the brightness can be restored by transferring the project again after setting the property of the brightness appropriately.

In a case of the applications where end users can control the brightness, create the applications so as keeping on operations by such as assigning the function which restores the brightness to one of function keys, if necessary.

- Signals from the touch panel may not be entered if the touch panel is pressed consecutively at high speed. Make sure to go on the next operation after confirming that the NA Unit has detected the input of the touch panel.
- The function keys have the restrictions as follows:
  - Using both anti-reflection sheet and protective cover interrupts the normal function key operation. Do not use them together.
  - When you use gloves or others, the function keys may not work correctly depending on the material and thickness of the gloves. Take actual conditions of the gloves usage into considerations prior to the system startup to perform the confirmation.
  - The function keys do not work when covered with water. Remove the water completely before use.

## **Precautions for Correct Use**

#### • Do not install or store the NA Unit in any of the following locations:

- · Locations subject to severe changes in temperature
- · Locations subject to temperatures or humidity outside the range specified in the specifications
- · Locations subject to condensation as the result of high humidity
- · Locations subject to corrosive or flammable gases
- · Locations subject to strong shock or vibration
- · Locations outdoors subject to direct wind and rain
- · Locations subject to strong ultraviolet light
- · Locations subject to dust
- · Locations subject to direct sunlight
- · Locations subject to splashing oil or chemicals

#### Take appropriate and sufficient countermeasures when installing systems in the following locations:

- · Locations subject to static electricity or other forms of noise
- · Locations subject to strong electric field or magnetic field
- · Locations close to power supply lines
- · Locations subject to possible exposure to radioactivity

## **Regulations and Standards**

### **Conformance to EC Directives**

### **Applicable Directives**

EMC Directive

### Concepts

#### • EMC Directive

OMRON devices that comply with EC Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.\*

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EC Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

 \* Applicable EMC (Electromagnetic Compatibility) standards are as follows: EMS (Electromagnetic Susceptibility): EN 61131-2:2007
 EMI (Electromagnetic Interference): EN 61131-2:2007

### • Conformance to EC Directives

The NA-series PTs comply with EC Directives. To ensure that the machine or device in which the NA-series PT is used complies with EC Directives, the NA-series PT must be installed as follows:

- The NA Unit must be installed within a control panel.
- You must use reinforced insulation or double insulation for the DC power supplies connected to the NA Unit.
- NA-series PTs that comply with EC Directives also conform to the Common Emission Standard (EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment complies with EC Directives.

• This is a Class A product (for industrial environments). In a residential environment, it may cause radio interference, in which case the user may be required to take appropriate measures.

### **Conformance to KC Standards**

Observe the following precaution if you use NA-series PTs in Korea.

A 급 기기 (업무용 방송통신기자재) 이 기기는 업무용(A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A Device (Broadcasting Communications Device for Business Use)

This device obtained EMC registration for office use (Class A), and it is intended to be used in places other than homes. Sellers and/or users need to take note of this.

## **Related Manuals**

Manual name	Cat. No.	Models	Applications	Description
NA-series Program- mable Terminal Hard- ware User's Manual	V117	NA5-0W000	Learning the speci- fications and set- tings required to install an NA-series PT and connect peripheral devices.	Information is provided on NA-series PT specifications, part names, instal- lation procedures, and procedures to connect an NA Unit to peripheral devices. Information is also provided on main- tenance after operation and trouble- shooting.
NA-series Program- mable Terminal Soft- ware User's Manual	V118	NA5-0W0000	Learning about NA-series PT pages and object functions.	NA-series PT pages and object func- tions are described.
NA-series Program- mable Terminal Device Connection User's Manual	V119	NA5-0W0000	Learning the speci- fications required to connect devices to an NA-series PT.	Information is provided on connec- tion procedures and setting proce- dures to connect an NA-series PT to a Controller or other device.
NA-series Program- mable Terminal Startup Guide	V120	NA5-0W0000	Learning in con- crete terms infor- mation required to install and start the operation of an NA-series PT.	The part names and installation pro- cedures are described followed by page creation and transfer proce- dures with the Sysmac Studio. Also operation, maintenance, and inspec- tion procedures after the project is transferred are described. Sample screen captures are provided as examples.
NX-series CPU Unit Hardware User's Manual	W535	NX701-□□□	Learning the basic specifications of the NX-series CPU Units, including introductory infor- mation, designing, installation, and maintenance. Mainly hardware information is pro- vided.	<ul> <li>An introduction to the entire NX-series system is provided along with the following information on the CPU Unit.</li> <li>Features and system configuration</li> <li>Introduction</li> <li>Part names and functions</li> <li>General specifications</li> <li>Installation and wiring</li> <li>Maintenance and inspection</li> <li>Use this manual together with the NJ/NX-series CPU Unit Software User's Manual (Cat. No.W501).</li> </ul>

The following manuals are related to the NA-series PTs. Use these manuals for reference.

Manual name	Cat. No.	Models	Applications	Description
NJ-series CPU Unit	W500	NJ501-□□□	Learning the basic	An introduction to the entire
Hardware User's		NJ301-□□□□	specifications of	NJ-series system is provided along
Manual		NJ101-□□□□	the NJ-series CPU	with the following information on a
			Units, including introductory infor-	Controller built with a CPU Unit.
			mation, designing,	Features and system configuration
			installation, and	Introduction
			maintenance.	<ul> <li>Part names and functions</li> </ul>
			Mainly hardware	General specifications
			information is pro-	<ul> <li>Installation and wiring</li> </ul>
			vided.	<ul> <li>Inspection and maintenance</li> </ul>
				Use this manual together with the
				NJ-series CPU Unit Software User's
	14/504			Manual (Cat. No. W501).
NJ/NX-series CPU Unit Software User's	W501	NX701-000	Learning how to program and set	Provides the following information on a Controller built with an
Manual		NJ501-□□□	up an	NJ/NX-series CPU Unit.
		NJ301-□□□	NJ/NX-series CPU	CPU Unit operation
		NJ101-□□□	Unit.	CPU Unit features
			Mainly software	Initial settings
			information is pro-	Programming based on IEC
			vided.	61131-3 language specifications
				Use this manual together with the
				NJ/NX-series CPU Unit Hardware
				<i>User's Manual</i> (NJ Series: W500, NX Series: W535).
CJ Series Program-	W393	CJ1H-CPU□□H-R	Learning the basic	The following information is provided
mable Controllers		CJ1G/H-CPU□□H	specifications of	on a CJ-series PLC.
Operation Manual		CJ1G-CPU□□P	the CJ-series	Introduction and features
			PLCs, including	System configuration design
			introductory infor-	Installation and wiring
			mation, designing, installation, and	I/O memory allocation
			maintenance.	Troubleshooting
				Use this manual together with the
				Programming Manual (Cat. No.
				W394).
CS/CJ/NSJ Series	W394	CS1G/H-CPU□□H	Learning about the	The following information is provided
Programmable Con-		CS1G/H-CPU□□-V1	functions of the	on a CS/CJ-series or NSJ-series
trollers Operation Manual		CS1D-CPU□□H	CS/CJ-series and NSJ-series PLCs.	PLC.
wallual		CS1D-CPU□□S	NOJ-SELLES PLOS.	Programming
		CJ1H-CPU□□H-R		Master function
		CJ1G/H-CPU□□H		File memory
		CJ1G-CPU□□P		Other functions
				Use this manual together with the
		CJ1G-CPU□□		Operation Manual (CS-series PLCs:
				W339, CJ-series PLCs: W393).
		NSJ□-□□□(B)-G5D		
		NSJ□-□□□(B)-M3D		

Manual name	Cat. No.	Models	Applications	Description
CS/CJ/NSJ-series	W340	CS1 <sub>□</sub> -CPU-□□□-□□	Learning detailed	Instructions are described in detail.
Instructions Refer- ence Manual		CJ10-CPU-000-000 CJ2H-CPU-000-000 NSJ00-00000-000	information on pro- gramming instruc- tions.	When programming, use this manual together with the <i>Operation Manual</i> (CS-series PLCs: W339, CJ-series PLCs: W393) and the <i>Programming Manual</i> (W394).
CS/CJ Series Pro- gramming Consoles Operation Manual	W341	CQM1H-PRO01 CQM1-PRO01 C200H-PRO27 +CS1W-KS001	Learning the oper- ating procedures of the Program- ming Consoles.	The operating procedures of the Pro- gramming Consoles are described. When programming, use this manual together with the <i>Operation Manual</i> (CS-series PLCs: W339, CJ-series PLCs: W393), the <i>Programming</i> <i>Manual</i> (W394), and the <i>Instructions</i> <i>Reference Manual</i> (W340).
CS/CJ/NSJ Series Communications Commands Refer- ence Manual	W342	CS1G/H-CPU CS1G/H-CPU CS1D-CPU S CS1D-CPU S CS1W-SCU CJ1W-SCB CJ1G/H-CPU CJ1G-CPU CJ1G-CPU CJ1G-CPU CJ1G-CPU CJ1W-SCU CJ1W-SCU CJ1W-SCU	Learning detailed specifications on the communica- tions instructions addressed to CS/CJ-series CPU Units and NSJ-series PLCs.	<ol> <li>C-mode commands and 2) FINS commands are described in detail.</li> <li>Refer to this manual for information on communications commands (C-mode commands and FINS com- mands) addressed to CPU Units.</li> <li>Note This manual describes com- munications commands that are addressed to a CPU Unit. The communications path is not relevant. (The communi- cations commands can be sent through the serial com- munications port of the CPU Unit, the communications port of a Serial Communica- tions Board/Unit, or a com- munications port on another Communications Unit.)</li> </ol>
CJ-series CJ2 CPU Unit Hardware User's Manual	W472	CJ2H-CPU6□-EIP CJ2H-CPU6□ CJ2M-CPU□□	Learning the hard- ware specifica- tions of CJ2 CPU Units.	<ul> <li>The following information is provided on a CJ2 CPU Unit.</li> <li>Introduction and features</li> <li>Basic system configuration</li> <li>Part names and functions</li> <li>Installation and setting procedures</li> <li>Troubleshooting</li> <li>Use this manual together with the Software User's Manual (Cat. No. W473).</li> </ul>
CJ-series CJ2 CPU Unit Software User's Manual	W473	CJ2H-CPU6□-EIP CJ2H-CPU6□ CJ2M-CPU□□	Learning the soft- ware specifica- tions of CJ2 CPU Units.	<ul> <li>The following information is provided on a CJ2 CPU Unit.</li> <li>CPU Unit operation</li> <li>Internal memory</li> <li>Programming</li> <li>Settings</li> <li>Functions built into the CPU Unit Use this manual together with the <i>Hardware User's Manual</i> (Cat. No. W472).</li> </ul>


Manual name	Cat. No.	Models	Applications	Description
Ethernet Units Oper- ation Manual Con- struction of Networks	W420	CS1W-ETN21 CJ1W-ETN21	Learning how to use an Ethernet Unit.	Information is provided on the Ether- net Units. Information is provided on the basic setup and FINS communications. Refer to the <i>Communications Com- mands Reference Manual</i> (Cat. No. W342) for details on FINS com-
				mands that can be sent to CS/CJ-series CPU Units when using the FINS communications service.
Ethernet Units Oper- ation Manual Con- struction of Applications	W421	CS1W-ETN21 CJ1W-ETN21	Learning how to use an Ethernet Unit.	Information is provided on construct- ing host applications, including func- tions for sending/receiving mail, socket service, automatic clock adjustment, FTP server functions, and FINS communications.
CS/CJ-series Ether- Net/IP™ Units Oper- ation Manual	W465	CJ2H-CPU6□-EIP CJ2M-CPU3□ CS1W-EIP21 CJ1W-EIP21	Learning how to use the built-in EtherNet/IP port of the CJ2 CPU Units.	Information is provided on the built-in EtherNet/IP port and EtherNet/IP Units. Basic settings, tag data links, FINS communications, and other functions are described.
Sysmac Studio Ver- sion 1 Operation Manual	W504	SYSMAC-SE2□□□	Learning about the operating proce- dures and func- tions of the Sysmac Studio.	The operating procedures of the Sysmac Studio are described.
CX-Programmer Operation Manual	W446	CXONE-AL□□C-V4 CXONE-AL□□D-V4	Learning about the CX-Programmer except for informa- tion on function blocks, ST pro- gramming, and SFC programming.	The operating procedures of the CX-Programmer are described.

## Terminology

Term	Description
HMI	A general term for interface devices that indicates both hardware and software elements. In
	this manual, "HMI" refers to an OMRON Sysmac-brand product unless otherwise specified.
PT	The hardware elements of the HMI.
NA Series	The NA Series of Programmable Terminals and peripheral devices.
HMI Project	A Sysmac Studio project for an HMI.
NA Unit	An NA-series Programmable Terminal.
Download	Transferring data from the Sysmac Studio to an HMI.
Upload	Transferring the project from an HMI to the Sysmac Studio.
IAG collection	When you provide IAGs, you provide them as IAG collections. IAGs are also imported as
	IAG collections. An IAG collection contains one or more IAGs.

## **Revision History**

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content
01	June 2014	Original production
02	October 2014	Made revisions accompanying version upgrade.
03	April 2015	Made revisions accompanying version upgrade.
04	October 2015	Made revisions accompanying version upgrade.

# Introduction to the NA-series Programmable Terminals

This section describes the features, basic system configuration, specifications, and overall operating procedure of the NA-series Programmable Terminals.

1-1	NA-series Programmable Terminals 1					
	1-1-1	Features	1-2			
1-2	How H	IMIs Operate	1-4			
	1-2-1	HMI Software Configuration	1-4			
	1-2-2	HMI Projects	1-4			
	1-2-3	Pages	1-4			
	1-2-4	Objects	1-5			
	1-2-5	Memory Specifications for Connected Devices	1-6			
	1-2-6	Events	1-7			
	1-2-7	Subroutines	1-8			
	1-2-8	Functions Shared by the Entire HMI Project	1-9			
	1-2-9	Data That Retained When Power Is Turned OFF	1-9			
1-3	Operating Procedure for HMIs					
	1-3-1	Overall Procedure	1-10			
	1-3-2	Procedure Details	1-11			


## **1-1 NA-series Programmable Terminals**

The NA-series Programmable Terminals represent the next generation of HMIs for industrial applications. They display information on FA manufacturing sites and function as control interfaces while providing safety, reliability, and maintainability. They provide all of the functions of traditional programmable terminals with a clearer, easy-to-use interface.

OMRON offers the new Sysmac Series of control devices designed with unified communications specifications and user interface specifications.

The NA-series Programmable Terminals are Sysmac devices that you can use together with the NJ-series Machine Automation Controllers and the Sysmac Studio Automation Software to achieve optimum functionality and ease of operation.

If you connect an NA-series Programmable Terminal to an NJ/NX-series Controller, all you have to do to specify memory in the Controller is to specify the Controller variables for the objects on the Programmable Terminal screens. This allows you to create screens without being concerned with the memory map of the Controller.



### 1-1-1 Features

### **Hardware Features**

#### • High-resolution Display Panels

High-resolution display panels are used to more clearly display large amounts of information than was possible with previous OMRON products.

#### • Two Ethernet Ports (Standard Feature)

You can use both Ethernet ports to separate the segment attached to control devices from the segment attached to maintenance devices. Access is possible from both segments at the same time.

You can connect the following devices.

- NJ/NX-series Controllers
- PLCs
- Computers
- Sysmac Studio

1

### • Standard-feature SD Memory Card Slot

You can use an SD Memory Card inserted in the NA Unit to automatically transfer the project you created on the Sysmac Studio to the NA Unit, to update the system program in the NA Unit, or to save the log data from the NA Unit.

### **Software Features**

#### • Specifications with Variables for Superior Reusability

If you connect to an NJ/NX-series Controller, all you have to do to specify memory in the Controller is to specify the Controller variables. This allows you to create objects that are not dependent on specific devices or memory maps. This in turn makes the objects much more reusable than they were with previous PTs.

### Program with Visual Basic

You can use Microsoft's Visual Basic to program advanced functions that you cannot achieve with standard objects.

### • A Wealth of Security Features

The many security features of the NA-series PTs include operation authority settings and execution restrictions with IDs.

#### Use the Integrated Development Environment of Sysmac Studio Automation Software

You use the Sysmac Studio to create applications for the NA-series Programmable Terminals.

The Sysmac Studio provides an integrated development environment that covers not only the NA-series Programmable Terminal, but also the Controller and devices on EtherCAT as well.

You can use consistent procedures for all devices regardless of differences in the devices. The Sysmac Studio supports all phases of Controller application, from page creation and sequence design through debugging, simulations, commissioning, and changes during operation.

### • A Wealth of Simulation Features

You can perform simulations using a virtual HMI on the Sysmac Studio. And you can also perform online debugging with a virtual NJ/NX-series Controller.

## 1-2 How HMIs Operate

This section describes how the HMI operates.

### 1-2-1 HMI Software Configuration

An HMI consists of the following software.

· System Program

The system program is required to start the HMI and execute the runtime. For details, refer to NA-series Programmable Terminal Hardware User's Manual (V117).

• Runtime


The runtime is the middleware that executes the project. The runtime is started by the system program and it manages execution of the project.

Project

You use the Sysmac Studio to create your applications. The applications are executed on the runtime.

### 1-2-2 HMI Projects

An HMI project contains mainly the following data.




In addition, there is data that is shared by the entire project, such as user alarms, data logging, recipes, and resources.

### 1-2-3 Pages

One HMI screen is called a page.

There are the following two types of pages.



You paste objects on the pages.

1

### 1-2-4 Objects

Element Properties These are static properties. \_ \_ \_ \_ \_ Example: Names and other general properties, colors, positioning, and other display properties, and assigned condition expressions or variables Object - - - - -Operating properties for condition expressions Animations Example: Operating specifications, such as flashing, enabling/disabling operation, size/coordinate changes, and displaying/hiding. You can specify events and the actions to perform when the - -Events and events occur. Actions Example: You can specify subroutines to execute, e.g., when a function key is pressed or a value changes.

The objects that you paste on HMI pages consist of the following three elements.


### **1-2-5** Memory Specifications for Connected Devices

### Overview

You use HMI global variables to specify memory in a Controller or PLC.

You assign HMI global variables to connected device variables in advance to map them.

- Variables for connected devices are registered to device variables in the HMI project with one of the following methods.
  - a) Variables for connected devices that are registered in the same project are registered automatically.
  - b) You can copy and paste variables from another project using the clipboard.
  - c) You can import variables from the external connected device.
- 2) Devices variables are assigned to HMI global variables.
- 3) The assigned HMI global variables are specified in the properties of the objects.
- 4) Then, you transfer the project that you created to the HMI.



Refer to 4-1 Registering Variables on page 4-3 for the details on HMI variables.

1

### 1-2-6 Events

Events

Events are triggers that activate actions.\*1

\*1. Actions are various operations that can be directly assigned to events.

Events occur when the common page status or object status meets certain conditions.

Events are classified into three groups as shown below.

Group

Description

Global events Events that occur for shared project status.

Page and object events Events that occur for specific page or object status.

Events that occur for user alarm status.

### 1-2-7 Subroutines

You can execute user-created subroutines in the HMI based on the following three types of conditions.

- · When global events occur
- When events occur on pages or for objects
- · When user alarm events occur

There are two types of subroutines that you can create.


· Global Subroutines

You create these subroutines under the global subroutine item of the HMI project.

· Page Subroutines

You create these subroutines with the page code editor.

You can use Visual Basic to write both the global subroutines and the page subroutines.



• You can call a global subroutine by executing the CallSubroutine action when a global event occurs.

1

- You can call a global subroutine or page subroutine by executing the CallSubroutine action when an event occurs on the page or for an object.
- You can call a global subroutine by executing the CallSubroutine action when a user alarm event occurs.

You can also call a global subroutine from another global subroutine or a page subroutine.

#### 1-2-8 Functions Shared by the Entire HMI Project

In addition to global events, the following functions are shared by the entire HMI project.

#### Alarms

Alarms notify the user when certain conditions are met in the HMI.

The following alarms are supported.

User alarms

#### Data Logging

You can log data to store the changes in the values of specified variables over time.

You can display the saved data with Trend Graph objects. You can also save this data to external files.

#### Recipes

A recipe is used to write data (numeric data or text strings) that was set in advance in the project to all of the specified variables as a group or to read all of the specified variables as a group.

You can manipulate the registered recipe data with Recipe Viewer objects.

#### Resources

You can manage resources, such as the text strings, movies, still images, and documents that are displayed for objects and alarms on pages.

#### 1-2-9 Data That Retained When Power Is Turned OFF

The following data is retained when the power supply is turned OFF.

With No Battery or Low Battery Voltage

- Project data
- · Log data that is not written to the SD Memory Card
- · User alarm history
- · Values of variables with Retain attribute
- · Calibration information for touch panel

With Good Battery (in addition to the above)

Clock information

### **1-3 Operating Procedure for HMIs**

This section gives the operating procedure for an HMI and then describes it in more detail.

#### 1-3-1 Overall Procedure

The overall procedure to use an HMI is given below.

STEP1

System Configuration and Project Design

Design the system configurations and project.

STEP 1-1 Designing the System ConfigurationsSTEP 1-2 Designing the Project (Pages, Variables, Subroutines, etc.)

#### STEP2

**P2** Software Settings (Configurations and Setup) and Creating the HMI Application

Create the system configurations that you designed in step 1 on the Sysmac Studio. Also create the project (pages, variables, subroutines, etc.), build the project, and debug it with simulation and other functions.

Determining the Connected Device Variables and Mapping HMI Variables to Them (We rec- ommend this as the basic procedure.)	Setting HMI Variables First and Then Mapping Them to Connected Device Variables
STEP 2-1 Starting the Sysmac Studio and Creating	STEP 2-1 Starting the Sysmac Studio and Creating
a Project	a Project
STEP 2-2 Software Settings (Configurations and	STEP 2-2 Creating the HMI Application
Setup)	
STEP 2-3 Creating the HMI Application	STEP 2-3 Software Settings (Configurations and
	Setup)
STEP 2-4 Building the HMI	STEP 2-4 Building the HMI
STEP 2-5 Offline Debugging	STEP 2-5 Offline Debugging

#### STEP3

#### Mounting and Wiring

Mount the HMI.

Connect the connected device and computer (Sysmac Studio) to the HMI.

#### STEP4

Confirming Operation and Starting Actual System Operation

Download the project from the Sysmac Studio.

Make the settings on the System Menu, check operation on the physical devices, and start operation.

#### 1-3-2 Procedure Details

STEP1

System Configuration and Project Design

Step	Description	Reference
STEP 1-1 Designing the System Configu- rations	<ul> <li>Connect an HMI to the external device.</li> <li>Connect an HMI to the Sysmac Studio.</li> </ul>	Section 2 Configuration Units in NA Series Programmable Terminal Hardware User's Manual (V117) NA-series Programmable Terminal Device Connection User's Manual (V119)
STEP 1-2 Designing the Project (Pages, Variables, Sub- routines, Etc.)	Design the project as given below.	NA Series Programmable Terminal Software User's Manual (V118)
1) Designing the Pages and Sub- routines	<ul> <li>Design the contents to display on the pages (the pages and objects to use).</li> <li>Design the execution methods and contents of the subroutines.</li> </ul>	
2) Designing Items Shared by All Pages	<ul> <li>Design the global events.</li> <li>Design the alarms, recipes, data logging, and other functions.</li> <li>HMI external variable design: Design the mappings between the connected device variables and the HMI global variables.</li> </ul>	
3) Variable Design	<ul> <li>Design the HMI internal variables and subroutine variables.</li> <li>Define the attributes of the above variables, such as the Data Type, Name, and Retain attributes.</li> </ul>	

#### STEP2

Software Settings (Configurations and Setup) and Creating the HMI Application

Step	Description	Sysmac Studio oper- ations	Reference
STEP 2-1	1. Start the Sysmac	Press the New Project	Sysmac Studio Version 1 Opera-
Starting the Sys-	Studio and create a	Button.	tion Manual (W504)
mac Studio and	project.	Use HMI on the Insert	Section 2 Basic Sysmac Studio
Creating a Project	2. Insert the HMI.	Menu.	Operations

1

## • Determining the Connected Device Variables and Mapping HMI Variables to Them

We recommend this procedure as the basic procedure.

· Connecting to a Connected Device Registered in the Current Project

STEP 2-2	Make the initial software settings	Use Configurations and	Section 3 HMI Con-
Software Set- tings (Configura- tions and Setup)	on the Sysmac Studio.	Setup in the Multiview Explorer of the Sysmac Studio.	figuration and Setup
Mapping Vari- ables	<ul> <li>Assign global variables to con- nected device variables (map- ping variables).</li> </ul>	Map the variables under Configurations and Setup – Variable Map- ping.	3-3 Mapping Vari- ables on page 3-7
HMI Settings	<ul> <li>Set the parameters related to the HMI.</li> <li>Startup Page, Brightness Set- tings, IP Address, FTP Settings, NTP Settings, FINS Settings, VNC Settings, etc.</li> </ul>	Make the settings under Configurations and Setup – HMI Settings.	3-4 HMI Settings on page 3-10
<ul> <li>Security Set- tings and Lan- guage Settings</li> </ul>	<ul> <li>Set the operation rights to the HMI and the language to display on the HMI.</li> </ul>	Make the settings under Configurations and Setup – Security Set- tings and Configura- tions and Setup – Language Settings.	3-5 Security Settings on page 3-18 3-7 Language Set- tings on page 3-20

· Connecting to a Connected Device Not Registered in the Current Project

STEP 2-2 Software Set- tings (Configu- rations and Setup)	Make the initial software settings on the Sysmac Studio.	Use <b>Configurations and</b> <b>Setup</b> in the Multiview Explorer of the Sysmac Studio.	Section 3 HMI Con- figuration and Setup
	<ul> <li>Register the external connected devices.</li> <li>You can do either of the following.</li> <li>a) Importing Variables from the</li> </ul>	Add the connected device under <b>Configura-</b> <b>tions and Setup</b> – <b>Device References</b> . Set up communications	3-2 Device Refer- ences on page 3-3
Device Set-	Actual Connected Device: Place the Sysmac Studio online with the connected device and import the variables from the connected device.	and import the variables.	
tings	b) Importing Variables from Another Project: Copy the variable table in the other project and paste it in the variable table for the con- nected device to import the vari- ables.	Copy the variable table from another project using the clipboard.	
	<ul> <li>c) Importing Variables from a File: Import the information on the variables of the connected device from a file, such as an Excel file.</li> </ul>	Import variable informa- tion from a file.	

	Assign global variables to connected	Map the variables under	Section 3 HMI Con-
<ul> <li>Mapping Variables</li> </ul>	device variables (mapping variables).	Configurations and Setup – Variable Map- ping.	<i>figuration and</i> <i>Setup</i> and 3-3 <i>Map-</i> <i>ping Variables</i> on page 3-7
• HMI Settings	<ul> <li>Set the parameters related to the HMI.</li> <li>Startup Page, Brightness Settings, IP Address, FTP Settings, NTP Settings, FINS Settings, VNC Set- tings, etc.</li> </ul>	Make the settings under Configurations and Setup – HMI Settings.	3-4 HMI Settings on page 3-10
<ul> <li>Security Set- tings and Language Settings</li> </ul>	<ul> <li>Set the operation rights to the HMI and the language to display on the HMI.</li> </ul>	Make the settings under Configurations and Setup – Security Set- tings and Configura- tions and Setup – Language Settings.	3-5 Security Set- tings on page 3-18 3-7 Language Set- tings on page 3-20

	Create the explication (respect		Continue 4 Oursetting at
STEP 2-3	Create the application (pages,	Use <b>HMI</b> in the Multiv-	Section 4 Creating the
Creating the HMI	variables, subroutines, etc.) with	iew Explorer of the	HMI Application
Application	the Sysmac Studio.	Sysmac Studio.	
1) Registering	<ul> <li>Register the variables in the HMI global variable table with the Sysmac Studio.</li> <li>Note: Variables that were mapped</li> </ul>	Use the editor for HMI – Data – Global Vari- ables	4-1 Registering Vari- ables on page 4-3
Variables	in step 2-2 are automatically regis- tered in the HMI global variables table.		
2) Creating Pages	Paste the objects on each page and set the object properties	Use the editor for <b>HMI</b> – <b>Pages</b> .	4-3 Creating Pages on page 4-14
	and other settings.		Section 5 Objects
<ul> <li>3) Creating Subroutines</li> <li>4) Settings Shared by All Pages</li> </ul>	<ul> <li>Create the subroutines.</li> <li>You can create the following.</li> <li>Global subroutines</li> <li>Page subroutines</li> <li>Make the settings that are shared by the project: alarms, recipes, data logging, global events, etc.</li> </ul>	Subroutines shared by the entire project: Select HMI – Global Subroutine. Page subroutines: Use HMI – Pages   Page Name and select View Code from the individ- ual pages. Use HMI – User Alarms, HMI – Reci- pes, etc.	<ul> <li>4-5 Subroutines on page 4-39</li> <li>4-4 Setting Common Object Functions on page 4-22</li> </ul>
STEP 2-4 Building the HMI	Convert the HMI project into a form that the HMI can execute.	Use <b>Build HMI</b> on the Project Menu.	4-8 Building on page 4-48
STEP 2-5 Offline Debug- ging	<ul> <li>Check the operation of the pages on the Simulator (a virtual HMI).</li> </ul>	Use Start NA Simula- tion or Run with Con- troller Simulator on the Simulation Menu.	Section 7 Debugging

1

• Setting HMI Variables First and Then Mapping Them to Connected Device Variables

STEP 2-2 Creating the HMI Application 1) Registering	Create the application (pages, variables, subroutines, etc.) with the Sysmac Studio. Register the variables in the	Use <b>HMI</b> in the Multiview Explorer of the Sysmac Stu- dio. HMI – Data – Global Variables	Section 4 Creating the HMI Application 4-1 Registering Vari-
Variables	HMI global variable table with the Sysmac Studio.	Table	ables on page 4-3
2) Creating Pages	Paste the objects on each page and set the object prop- erties.	Use the editor for <b>HMI</b> – <b>Pages</b> .	4-3 Creating Pages on page 4-14 Section 5 Objects
3) Creating Sub- routines	Create the subroutines. You can create the following. • Global subroutines • Page subroutines	Subroutines shared by the entire project: Select <b>HMI</b> – <b>Add Global Subroutine</b> . Page subroutines: Use <b>HMI</b> – <b>Pages</b> and select <b>View Code</b> from the individual pages.	4-5 Subroutines on page 4-39
4) Settings Shared by All Pages	Make the settings that are shared by the project: alarms, recipes, data logging, global events, etc.	Use <b>HMI – User Alarms</b> , HMI – <b>Recipes</b> , etc.	4-4 Setting Common Object Functions on page 4-22

· Connecting to a Connected Device Registered in the Current Project

STEP 2-3	Make the initial software settings	Use Configurations	Section 3 HMI Config-
Software Set-	on the Sysmac Studio.	and Setup in the Mul-	uration and Setup
tings (Configura-		tiview Explorer of the	
tions and Setup)		Sysmac Studio.	
	Assign global variables to con-	Map the variables	3-3 Mapping Vari-
Mapping Vari-	nected device variables (map-	under Configura-	ables on page 3-7
ables	ping variables).	tions and Setup –	
		Variable Mapping.	
	<ul> <li>Set the parameters related to</li> </ul>	Make the settings	3-4 HMI Settings on
	the HMI.	under Configura-	page 3-10
LIMI Cottings	Startup Page, Brightness Set-	tions and Setup –	
HMI Settings	tings, IP Address, FTP Settings,	HMI Settings.	
	NTP Settings, FINS Settings,	-	
	VNC Settings, etc.		
	Set the operation rights to the	Make the settings	3-5 Security Settings
	HMI and the language to display	under Configura-	on page 3-18
Security Set-	on the HMI.	tions and Setup –	3-7 Language Set-
tings and Lan-		Security Settings and	tings on page 3-20
guage Settings		Configurations and	
		Setup – Language	
		Settings.	

STEP2-3	Make the initial software settings	Use Configurations	Section 3 HMI Config-
Software Set- tings (Configura- tions and Setup)	on the Sysmac Studio.	and Setup in the Mul- tiview Explorer of the Sysmac Studio.	uration and Setup
	Register the external connected devices.	Add the connected device under Configu- rations and Setup – Device References.	<i>3-2 Device References</i> on page 3-3
	<ul> <li>You can do either of the follow- ing.</li> <li>a) Importing Variables from the Unit Connected Device: Place the Sysmac Studio online with the connected device and import the vari- ables from the connected device.</li> </ul>	Set up communica- tions and import the variables.	3-2-2 Connected Devices in the Current Project on page 3-3
Connected     Device Settings	<ul> <li>b) Importing Variables from Another Project: Copy the variable table in the other project and paste it in the device variable table.</li> </ul>	Copy the variable table from another project using the clipboard.	
	c) Importing Variables from a File: Import the information on the variables of the con- nected device from a file, such as an Excel file.	Import variable infor- mation from a file.	
	<ul> <li>Assign global variables to con- nected device variables (map- ping variables).</li> </ul>	Map the variables under Configura- tions and Setup – Variable Mapping.	3-3 Mapping Vari- ables on page 3-7
HMI Settings	<ul> <li>Set the parameters related to the HMI.</li> <li>Startup Page, Brightness Set- tings, IP Address, FTP Settings, NTP Settings, FINS Settings, VNC Settings, etc.</li> </ul>	Make the settings under Configura- tions and Setup – HMI Settings.	3-4 HMI Settings on page 3-10
<ul> <li>Security Set- tings and Lan- guage Settings</li> </ul>	<ul> <li>Set the operation rights to the HMI and the language to display on the HMI.</li> </ul>	Make the settings under Configura- tions and Setup – Security Settings and Configurations and Setup – Language Settings.	3-5 Security Settings on page 3-18 3-7 Language Set- tings on page 3-20
STEP 2-4	Convert the HMI project into a	Use Build HMI on the	4-8 Building on page
Building the HMI	form that the HMI can execute.	Project Menu.	4-48
STEP2-5 Offline Debug- ging	<ul> <li>Check the operation of the pages on the Simulator (a virtual HMI).</li> </ul>	Use Start NA Simula- tion or Run with Con- troller Simulator on the Simulation Menu.	Section 7 Debugging

۰.

Connecting to a Connected Device Not Registered in the Current Project

1-3 Operating Procedure for HMIs

1

1-3-2 Procedure Details

#### **STEP3** Mounting and Wiring

Step	Description	Reference
1) Mounting	<ul><li>Mount the HMI to the panel.</li><li>Wire Power Supply.</li></ul>	3-3 Installing NA Units in NA Series Pro- grammable Terminal Hardware User's Man- ual (V117)
2) Wiring the Ethernet Cable to the Connected Device	<ul> <li>Wire the Ethernet cables.</li> </ul>	3-4 Wiring Method in NA Series Program- mable Terminal Hardware User's Manual (V117) NA-series Programmable Terminal Device Connection User's Manual (V119)
3) Connecting the Computer (Sys- mac Studio)	<ul><li>Wire the USB cable.</li><li>or</li><li>Wire the Ethernet cable.</li></ul>	2-4 Support Software in NA Series Program- mable Terminal Hardware User's Manual (V117)

#### STEP4

Confirming Operation and Starting Actual System Operation

Step	Description	Sysmac Studio operations	Reference
1) Online Connec- tion to Sysmac Studio and Proj- ect Download	<ul> <li>Turn ON the power supply to the HMI and place the Sysmac Stu- dio online. Then, download the project.*1</li> <li>*1.Use the Synchronize operation of the Sysmac Studio to download the project.</li> </ul>	Use <i>Communica-</i> <i>tions Setup</i> on the HMI Menu. Use <i>Synchroniza-</i> <i>tion</i> on the HMI Menu.	Section 6 Connecting to the HMI and Section 8 Synchronizing Proj- ects
2) Operation Check on NA Unit	• Integrate the NA Unit into the actual system, manipulate the project that you created and confirm the following: that correct values are written to the connected device, that the pages change correctly, and that values set at the connected device are updated.		Section 7 Debugging
3) Actual System Operation	Start actual operation.		

## 

## **Basic Sysmac Studio Operations**

This section describes basic operations on the Sysmac Studio.

2-1	Parts	of the Sysmac Studio Window 2-2
	2-1-1	Application Window 2-2
2-2	Menu	Command Structure 2-6
2-3	Basic	Editing Operations 2-8
2-4	Sysm	ac Studio Settings and Operations 2-10
	2-4-1	Setting Parameters 2-10
	2-4-2	Programming
	2-4-3	Library Functions
	2-4-4	Operations for Debugging2-11
	2-4-5	Communications
	2-4-6	Security Measures
	2-4-7	Online Help
2-5	Basic	Operations for HMI Projects 2-13
	2-5-1	Creating a Project File from the Project Window
	2-5-2	Adding an HMI to an Existing Project 2-14
	2-5-3	Changing Devices

## 2-1 Parts of the Sysmac Studio Window

This section gives the names and functions of the parts of the Sysmac Studio Window.


This manual describes only functions that apply when an HMI is selected for the device. For information on Sysmac Studio functions not described in this manual, refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).

#### 也

#### **Precautions for Correct Use**

When you use the Sysmac Studio, use the standard Windows desktop theme. If you do not use the standard Windows desktop theme, part of the display may not be correct.

#### 2-1-1 Application Window




Number	Name		
(a)	Multiview Explorer		
(b)	Edit Pane		
(C)	Toolbox		

The functions of these parts are described starting on the next page.

# 2-1 Parts of the Sysmac Studio Window

2-1-1 Application Window

#### Multiview Explorer (a)



- This pane is your access point for all Sysmac Studio data. When an HMI is selected, it is divided into a Configurations and Setup Layer and an HMI Layer.
- You can also display the Page Explorer to display lists of objects on pages or the Code Explorer to display lists of subroutines.

#### • Layers and Items in the Multiview Explorer

Configurations and Setup		
Device References		
Variable Mapping		
HMI Settings		
Security Settings		
Troubleshooter		
Language Settings		

HMI
Pages
Page
User Alarms
Group
Controller Events
User Events
Data Logging
DataSet
Data Groups
DataGroup
Recipes
Custom Keypads
Data
Data Types
Global Variables
Global Events
Global Subroutines
Resources
Root
Imported IAGs
Scale Transformations



#### **Precautions for Correct Use**

You cannot download the data to the HMI if an error icon is displayed.


#### Page Explorer



The Page Explorer displays a list of objects on a page. If you click an object in the Page Explorer, the object will be selected on the Edit Pane.

To change the attributes for grouped objects or for individual objects in IAGs, select the individual objects on the Page Explorer.

#### Code Explorer



The Code Explorer displays the subroutines in the project. You can double-click a subroutine to edit it.

#### Edit Pane (b)

The basic Sysmac Studio operations on the Edit Pane generally apply to HMIs. If an HMI is selected, you can edit pages and set up the HMI.

#### Toolbox (c)

Toolbox 🗸 🗸
<search></search>
Button
Button
Momentary Button
Reset Button
Set Button
E Toggle Button
▶ Lamps
▶—Shapes
Standard Controls
▶ -Gauges
HMI Controls
Custom
Arrows
Button
A Button object.

• The Toolbox shows the objects that you can use to edit the page that is displayed in the Edit Pane.

You can also display the Properties Window, Animations Window, and Events and Actions Window to make the settings of the objects.

## 2-2 Menu Command Structure

The menu commands that are displayed when an HMI is selected as the device are listed below.

Menu	Submenu/comr	nand
File	Close	
	Save	
	Save As	
	Save As New Number	
	Import	
	Export	
	Page Settings	
	Print	
	Exit	
Edit	Undo	
	Redo	
	Cut	
	Сору	
	Paste	
	Delete	
	Select All	
	Search and Replace	
View	Multiview Explorer	
	Toolbox	
	Output Tab Page	
	Watch Tab Page	
	Cross Reference Tab Page	
	Build Tab Page	
	Search and Replace Results Tab Page	
	Page Explorer	
	Code Explorer	
	Properties	
	Animations	
	Events and Actions	
	Smart Project Search	_
	Recently Closed Windows	—
	Clear Recently Closed Windows History	—
	Zoom	Zoom In
		Zoom Out
		Zoom to Fit
		Zoom Reset
	Reset Window Layout	

Menu	Submenu/c	command
Insert	Controller	NJ101
		NJ301
		NJ501
		NX701
	HMI	NA5
	Measurement Sensor	ZW
	Vision Sensor	FQ-M
		FH
	Slave Terminal	Ethernet/IP Coupler
	External Device	
	Page	
	Page Group	
	User Alarm Group	
	Data Set	
	Recipe	
	Global Subroutine Group	
Project	Build HMI	
	Abort Build	
	IAG Collections Manager	
HMI	Communications Setup	
	Change Device	
	Online	
	Offline	
	Synchronization	
	Transfer to Media Device	
	HMI Clock	
	Update HMI Name	
	Security	HMI Write Protection
	Clear All Memory	
	Reset HMI Device	
Simulation	Start NA Simulation	
	Stop NA Simulation	
	Step Execution	
	Step In	
	Step Out	
	Continue	
	Set/Clear Breakpoint	
	Clear All Breakpoints	
	Run with Controller Simulator	
Tools	Option	
Help	Help Contents	
r	Keyboard Mapping Reference	
	Online Registration	———————————————————————————————————————
	About Sysmac Studio	

## 2-3 Basic Editing Operations

This section describes differences in basic Sysmac Studio operation when an HMI is selected as the device.

#### Entry Assistance

There are some differences in the standard operation of the Sysmac Studio when an HMI is selected as the device. This section describes those differences.

#### • Entering Variable Names and Data Types

- · Entering variable names, e.g., when setting properties
- Entering data types in variable tables

Example: When you enter a variable name as a property, the variable names that you can enter are displayed in a list.

Μ	Behavior					
	Variable		bl			
	IsEnabled	Ŷ	blnValue0	Boolean blnValue0		
	DoubleTouchTime	Ŷ	blnValue1			
		0	blnValue2			
	OnDelayTime		0			
	OffDelayTime		0			

#### • Entering Text in the Code Editor

• When you enter text in the Code Editor, the cursor moves to the first item in the list that starts with the character that you entered.

Page0.vb	×			
-Q Button	1_Click			
1	Sub Button1		outines for the page.	
3	Dim intVa	lue0 As i		
4 5	a=10 End Sub	<ul> <li>Boolean</li> <li>Byte</li> <li>Char</li> <li>Date</li> <li>Decimal</li> <li>Double</li> <li>Clobal</li> <li>Integer</li> <li>Long</li> <li>Microsoft</li> </ul>	Structure System.Int32	

• When you press the **Tab** Key after entering the first part of the keyword ("in" in this example), the rest of the keyword is automatically entered.

Digeo va 🗙	
Button2_Click	
1 Code behind Page - Add local su	broutines for the page.
2 🗄 Sub Button1_Click	
3 Dim intValue0 As Integer	
4 3=10	
5 End Sub	

### 2-4 Sysmac Studio Settings and Operations

This section lists the operations of the Sysmac Studio that can be used only when an HMI is selected.

#### 2-4-1 Setting Parameters

	Item	Description	Reference
HMI Settings		You can make settings for an HMI.	Section 3 HMI Configuration
			and Setup
Device	References	If you connect an HMI to a device (e.g., Control-	3-2 Device References on
		ler or PLC) that is not registered in the current	page 3-3
		HMI project, the connected external device will	
		be added.	
	Internal Device	Controllers registered in the project are dis-	
		played.	
	External Device	You can set up communications and import vari-	
		ables for connected devices that have been	
		added.	
Variable Mapping		You can associate variables in the connected	3-3 Mapping Variables on
		devices with variables in the HMI.	page 3-7

#### 2-4-2 Programming

Item	Description	Reference
Toolbox	The Toolbox displays a list of the objects that you can use.	Section 5 Objects
	You can search for the required objects and drag them to the Page Editor to position the objects.	
Properties	You can set the static attributes of the pages and objects.	
Animations	You can set the operations for object condition expressions.	
Events and Actions	You can set the actions to perform when events occur.	
Page Explorer	The Page Explorer displays a list of objects on a page. You can select objects or change the order of the display.	
Code Explorer	The Code Explorer displays lists of subroutines in the project. You can double-click a subroutine to edit it.	
Page Editor	You can position objects and create pages. You can also use the Page Editor to make settings for objects.	4-3 Creating Pages on page 4-14
Code Editor	You can use Visual Basic to create subroutines.	4-5 Subroutines on page 4-39

Item		Description	Reference	
Search and Replace		You can search and replace strings in project	4-6 Search and Replace on	
		data.	page 4-46	
Cross Reference		Searches the area where the search target is allocated, and displays a list.	4-7 Cross References on page 4-47	
Build Build HMI		Convert the project into a form that the HMI can execute.	4-8 Building on page 4-48	
	Abort Build	You can abort a build operation.	1	

#### 2-4-3 Library Functions

Item Description		Reference
Toolbox	ox You can register objects that you have created	
	and then reuse them.	
IAG	You can output an IAG that you created in an	
	IAG project as an IAG collection, to use it in	
	another project.	

#### 2-4-4 Operations for Debugging

Item	Description	Reference	
Monitoring	You can monitor variables during project execution.	Section 7 Debugging	
	You can monitor the present values of HMI global variables. You use the Watch Tab Page for monitoring.		
Changing the Present Values of Variables	You can change the present values of global variables and system-defined variables.	Section 7 Debugging	
Controlling Execution with	You can do this on a Watch Tab Page. You can control simulation execution to monitor	Section 7 Debugging	
Controlling Execution with Breakpoints and Step Execu- tion	the program or to check operation. Step execution and pausing are also possible.		

#### 2-4-5 Communications

Item	Description	Reference
Going Online with an HMI You can place the computer online with an HMI		Section 6 Connecting to the
	to synchronize the project.	НМІ

#### 2-4-6 Security Measures

Item		Description	Reference
Prevention of	Confirming HMI	If the device name or the serial ID is different	3-5 Security Settings
Incorrect Con-	device Names and	between the project and the HMI when an	on page 3-18
nections Serial IDs		online connection is established, a confirmation	
		dialog box is displayed.	
Preventing Incor-	Operation Author-	You can use operation authorities to restrict the	
rect Operation	ity Verification	ability to perform operations or display data.	

Item		Description	Reference
Prevention of the Theft of Assets	Password Protec- tion for Project Files	You can set password protection for project files to protect your assets.	

#### 2-4-7 Online Help

Item	Description	Reference
Sysmac Studio Help System	You can access Sysmac Studio operating pro-	
	cedures.	
Keyboard Mapping Reference	You can display a list of convenient shortcut	
	keys that you can use on the Sysmac Studio.	


## 2-5 Basic Operations for HMI Projects

This section describes how to create and save projects and perform other basic operations to use HMIs.

#### 2-5-1 Creating a Project File from the Project Window

Use the following procedure to create a project file from the Project Window.


**1** Click the **New Project** Button in the Project Window.



The Project Properties Dialog Box is displayed. The following table gives the functions of the buttons.


Menu command	Description
New Project Button	Creates a project file.
Open Project Button	Opens an existing project file.

2 Enter the project name, author, and comment in the Project Properties Dialog Box, select *HMI* from the device category, and then click the **Create** Button. (Only the project name is required.)



You can change the properties later. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).

A project file is created and the following window is displayed.




A project file is created with the specified device already inserted.

Multiview Explorer	- <b>d</b>
HMI_NA5_0 🔻	
Configurations and S	etup
► HMI	

#### 2-5-2 Adding an HMI to an Existing Project

Right-click the Controller Icon and select Add Device from the menu.



Or, select the device directly from the Insert Menu.

Example: HMI - NA5: The Add Device Dialog Box is displayed.

Add Device		
Select D	evice	
Category	HMI 💌	
Device	NA5 🔻 - 12W101 🖛	
Version	1.00 🔻	
	OK Cancel	

Select the device and then click the OK Button. The device is added to the project.



To change the target device, select a device from the list.

#### 2-5-3 Changing Devices

Right-click the HMI Icon and select *Change Device* from the menu. Or, select *Change Device* from the HMI Menu.



The Change Device Dialog Box is displayed.

📓 Change Device 💽							
Select Device							
Category	HMI						
Device	NA5 🔻 - 12W101 🗖 🔻						
Version	1.00 🔻						
	OK Cancel						

Select the device and then click the **OK** Button. The device is changed.

#### Precautions for Correct Use

- If you change the device, the settings for functions that are not supported by the new model will be lost.
- If you change to a model that has a different display size, the objects will be enlarged or reduced according to the new display size. However, elements other than objects, such as font sizes, will not change.

#### **HMI Versions**

Set the version when you create a new HMI project or when you add an HMI to an existing project.

You can set the version to the runtime version of the HMI that you are using. You can program and make settings within the ranges that are supported for the runtime version. If you attempt to use functions that are not supported by the runtime version that you set, you will not be able to use them or errors will occur.

#### Additional Information

When you open the project that was created in past versions of the Sysmac Studio version 1.11 or higher, it will be converted as follows.

Version of the Runtime	Sysmac Studio			
before conversion	V1.10	V1.11 or V1.12	V1.13	V1.14
1.00	1.00	1.01 <sup>*1</sup>	1.02 <sup>*1</sup>	1.03 <sup>*1</sup>
1.01		1.01	1.02 <sup>*1</sup>	1.03 <sup>*1</sup>
1.02			1.02	1.03 <sup>*1</sup>
1.03				1.03

\*1. The runtime version will be converted.

## 3

## **HMI Configuration and Setup**

This section describes how to configure and set up HMIs on the Sysmac Studio, including mapping variables with connected devices and HMI settings.

3-1	Outlin	ne of Configurations and Setup		. 3-2				
	3-1-1	Connected Device Registration and Variable Mapping		3-2				
3-2	Devic	e References		. 3-3				
	3-2-1	Types of Connected Devices		3-3				
	3-2-2	Connected Devices in the Current Project		3-3				
	3-2-3	Registering External Connected Devices		3-4				
3-3	Марр	ing Variables		. 3-7				
	3-3-1	Mapping Variables		3-7				
	3-3-2	Opening the Variable Mapping Tab Page and Tab Page Parts		3-7				
	3-3-3	Variable Mapping Methods		3-8				
3-4	HMI S	Settings		3-10				
	3-4-1	HMI Settings		. 3-10				
	3-4-2	Device Settings		3-11				
	3-4-3	TCP/IP Settings		. 3-12				
	3-4-4	FTP Settings						
	3-4-5	NTP Settings						
	3-4-6	FINS Settings						
	3-4-7	VNC Settings						
	3-4-8	Printing Settings						
3-5	Secur	rity Settings	• • • • •	3-18				
3-6	Troub	lleshooter		3-19				
3-7	Langu	uage Settings		3-20				
3-8	НМІ С	Clock		3-21				
3-9	Updat	Updating the HMI Name 3-22						
3-10	Write	Protecting the HMI		3-23				
3-11	Clear	All Memory		3-24				
3-12	Reset	ting the HMI		3-25				

## 3-1 Outline of Configurations and Setup

This section describes how to set up HMIs and connected devices, such as Controllers and PLCs. The following items are provided in the HMI Configurations and Setup.

Item	Description
Device References	You can set up connected devices and import variables.
Variable Mapping	You can assign HMI variables to the variables in the connected devices.
HMI Settings	These are the parameters related to the HMI.
Security Settings	You can set up restrictions to operations on HMIs.
Troubleshooter	You can set parameters for the Troubleshooter.
Language Settings	You can make settings for multi-language projects.


#### 3-1-1 Connected Device Registration and Variable Mapping

Device references must be set only to connect to external devices that are not registered in the current project. They are not necessary to connect to a Controller that is registered in the current project.

The following figure shows the relationship between connected device references and variable mapping.

The HMI global variables are mapped to the connected device variables.

To access variables in the connected devices from an HMI, you must map the variables.



Sysmac Studio Project

- (A) Connected device variables are a) automatically imported from the same project or b) copied from another project or manually imported from an external device or a file, such as an Excel file.
- (B) The connected device variables are automatically registered in the variable mappings.
- (C) The HMI global variables are mapped to the connected device variables.
- (D) The mapped HMI global variables are automatically registered in the global variable table of the HMI.
- (E) You specify HMI global variables in the object properties.

## **3-2 Device References**

This section describes how to set up HMIs and connected devices, such as Controllers and PLCs.

#### 3-2-1 Types of Connected Devices

Different operations are used to connect to Controllers that are registered and Controllers that are not registered in the current project.

- Controllers that are already registered in the current project are automatically registered in the HMI project as internal connected devices.
- To connect to a device that is not registered in the current HMI project, you must register the device as an external connected device.

#### Additional Information

If you upload a project that includes Controllers registered as internal connected devices to a project in which the Controllers are not registered, the devices are registered as internal connected devices that do not have links to Controllers. Refer to *8-1 Synchronizing Projects* on page 8-2 for details.

#### 3-2-2 Connected Devices in the Current Project

Controllers that are registered in the current project are displayed as connected devices. Use the following procedure to display the device settings if you need to check them.

- 1 Click Device References under Configurations and Setup in the Multiview Explorer.
- **2** The Controllers that are registered in the current project are displayed under **Internal Device**.
- **3** Double-click the project to display the following Device Configuration Tab Page.

New Project - HMI_NA5_0 - Sys	mac Studio			
$\underline{E} i le  \underline{E} dit = \underline{V} i e w  \underline{I} n s e i t = \underline{E} n o j e$	$sct = H\underline{M}I = \underline{S}imulation$	<u>Tools H</u> elp		
8 . B . D . C .	i ta ta ta	< # 16 10 B	• 5 R R A A A O F F H B	61
Multiview Explorer 4	new_Controller_D ×	1		-
Configurations and Setup	Device Configuration Device Name	new Controller fi	Communications Configuration	
▼ III Device References ▼ III Internal Devices	Device Vendor	Omitan	IP Address	
JP Variable Mapping	Device Series Communication Driver	hll Blanto d	Timeout 2 seconds	
<ul> <li>III HMI Settings</li> <li>III, Security Settings</li> <li>A, Language Settings</li> </ul>				

#### 3-2-3 Registering External Connected Devices

To connect the HMI to a device that is not registered in the current HMI project, you must register the device as an external connected device. The procedures to register and set up external connected devices are given below.


#### **Registering and Setting Up External Connected Devices**

This section describes how to register and set up external connected devices.


**1** Right-click **Device References** under **Configurations and Setup** in the Multiview Explorer.



2 Select Add - ExternalDevice. The device is added as ExternalDevice, where is a serial number starting from 0.



**3** Double-click the new ExternalDevice



4 Select the vendor of the required device in the *Device Vendor* Box under **Device Configuration**. The device series of the selected vendor is displayed. Make the selections for the required device. The device communications drivers of the vendor selected for the device series are displayed. Select the communications driver for the required device.

🔄 ExternalDevice0 🗙			
Device Configuration		-	
- Device Configuration -			Communications Configuration
Device Name	ExternalDevice0		IP Address
Device Vendor	Qn <del>on</del>	F	Timeout
Device Series	NJ		Communication Error Indication
Communication Driver	Ethemet	•	
Import Status N	at Imported. 🔻		
Import	Update		Impart From File

**5** Make the required settings in the *Communications Configuration* Area. Refer to the *NA-series Programmable Terminal Device Connection User's Manual* (Cat. No. V119) for details.

👔 ExternalDevice0 🗙					*
Device Configuration					
Provice Configuration -			Communications	Configuration ———	
Device Name	ExternalDeviceU		IP Address	192.168.250, _1	
Device Vendor	Ommon	F	Timeout	2 🗧	seconds
Device Series	N		🛛 🖸 Communication	n Error Indication	
- Device Configuration - Device Name Device Vendor Device Series Communication Driver	Finamat	Ŧ			
-	it Imported. 🔽				
Import	Update		Import From File		

#### **Importing External Connected Device Variables**

To connect the HMI to a device that is not registered in the current HMI project, you must import the variables from the external connected device.

There are three ways to import external connected device variables.

- · Importing device variables online from the actual external connected device
- · Copying variables from the variable table in another project
- · Importing variables from an Excel or CXT file

#### Importing Device Variables Online from the Actual External Connected Device

Click the Import Variables Button. The variables are imported from the external connected device.

Refer to the *NA-series Programmable Terminal Device Connection User's Manual* (Cat. No. V119) for details.

#### • Copying Variables from the Variable Table in Another Project

You can use the clipboard to copy the required variables from the Support Software for the connected device and paste them in the device variables table for the external connected device. However, you cannot copy connected device variables if they are structure variables.

Refer to the *NA-series Programmable Terminal Device Connection User's Manual* (Cat. No. V119) for details.

#### Importing Variables from an Excel or CXT File

Click the **Import from File** Button. The variables are imported for the external connected device. Refer to the *NA-series Programmable Terminal Device Connection User's Manual* (Cat. No. V119) for details.

#### **Updating Device Variables**

If you change the variables on a device, update the device variables in the HMI project as required.

There are three ways to update device variables.

- · Updating device variables online from the actual external connected device
- · Copying variables from the variable table in another project
- · Importing variables from an Excel or CXT file

#### • Updating Device Variables Online from the Actual External Connected Device

Click the **Update Variables** Button. The differences between the variables on the external connected device and the device variables in the HMI project are displayed. Select the variables to update.

#### • Copying Variables from the Variable Table in Another Project

You can use the clipboard to copy the required variables from the Support Software for the connected device and paste them in the device variables table for the external connected device.

#### Importing Variables from an Excel or CXT File

Click the **Import from File** Button. The differences between the variables in the Excel file and the device variables in the HMI project are displayed. Select the variables to be updated.

## **3-3 Mapping Variables**

This section describes the settings required to access variables in connected devices through HMI global variables.

#### 3-3-1 Mapping Variables

Mapping variables refers to assigning variables in devices connected to the HMI (called device variables) to global variables in the HMI. Device variables are used on the HMI by assigning them to HMI global variables.

Therefore, mapping variables is required. Not accessing device variables directly allows you to reuse projects simply by changing the variable mappings.

Global variables that are assigned to device variables are called external variables.

#### **3-3-2** Opening the Variable Mapping Tab Page and Tab Page Parts

**1** Double-click Variable Mapping under Configurations and Setup.

The Variable Mapping Tab Page is displayed.

Port	Data T <u>ype</u>	Variable	Variable Comment	
ured Devices				
	Port ured Devices	Port   Data Type   ured Devices	Port Data Type Variable ared Devices	Port Data Type Variable Variable Comment ured Devices

#### Parts of the Window

No	Item	Description
1	Position Displays the IP addresses of the connected devices.	
2	Port Displays the connected devices and device variables in a tree structure	
3	Data Type	The data types of the device variables are displayed.

No	ltem	Description
4	Variable	You can set the name of a HMI global variable. You can use entry assistance to
		select from a list of previously registered HMI global variables.
5	Variable Comment	You can set comments for the HMI global variables. These comments are also applied to the global variable table.

#### 3-3-3 Variable Mapping Methods

To map variables, you can either create new global variables and assign them or you can assign previously created global variables.

To increase the reusability of the project, create the global variables first and then assign them.

However, if a device variable is a structure, you must create a new external variable during variable mapping.

#### **Creating New External Variables**


You can create a new global variable and assign it to a device variable.

When you create an external variable, you can either have the name generated automatically or you can create it manually.

#### Automatically Creating New Variable Names

Use the following procedure.

1 Select one or more device variables in the variable mappings, right-click, and select **Create Device Variable** from the popup menu.



Automatically generated variable names are registered in the global variable table according to the following rule.

Automatic generation rule: The device variable name is added after the controller name and separated with an underline.

#### Manually Entering New Variable Names

Select the device variable and directly enter the variable name in the Variable column.

## Selecting Previously Registered Global Variables and Mapping Them

You can select global variables that are already registered in the global variable table and assign them to device variables.

For example, this method can be used to map external variables in the following cases.

- Setting an HMI global variable first and then assigning it to a device variable
- · Creating a common project first and specifying connected devices later

Use the following procedure.

**1** Register the global variables in the global variable table in advance.

**2** When you map variables, you can select global variables from lists of variables that are already registered in the global variable table and assign them to device variables.

noitien	Port	Data Type	Variable	Variable Comment	
	ang allower		Contractory of Contra		
2.168. 🛛 🔻 🕴	new_Controller_0				
Þ	System Variables				
	/ User Variables				
	binValue1	BOOL	<b>T</b>		
	intValue1		_HML_CariEjectSDCarc _HML_IsBatteryLow _HML_IsBatteryLow _HML_IsBageSwitching _HML_IsScreenSaverAd _HML_RunSignal _HML_NaValue1	,	

3

## 3-4 HMI Settings

This section describes the HMI settings.

#### 3-4-1 HMI Settings

You can make settings for an HMI.

The following table lists the setting items.

Item	lcon	Description	When setting is required
Device Settings		There are page, screen saver, brightness settings, and other set- tings.	These settings are always required.
TCP/IP Settings	TCP /IP	These are the Ethernet settings for Ethernet ports 1 and 2.	These settings are always required.
FTP Settings	FTP	These are the FTP server settings.	These settings are required to use the FTP server.
NTP Settings	TTP	These are the NTP client settings.	These settings are required when you use an NTP client.
FINS Settings		These are the settings for FINS com- munications.	These settings are required when using FINS communications with a CJ-series PLC.
VNC Settings	VIC	These are the VNC settings.	These settings are required to use VNC.
Print Settings	E.	These are the settings for printing and capturing screens on the HMI.	These settings are required to print or capture screens.

#### **Setting Procedure for HMI Settings**

- **1** Double-click **HMI Settings** under **Configurations and Setup** in the Multiview Explorer. The HMI Settings Tab Page is displayed in the Edit Pane.
- **2** Click the icons on the left to display the corresponding dialog boxes.

#### 3-4-2 Device Settings

These are the device settings.

■ HMI Setti	ngs			™®®∛ • E X
LÍ.	Q Device S	ettings		
	▼ Startup Page			
赗	Page name	Poge9		
ZIP	🔻 Startup Language			
	Startup language			
FTP	V Software Keypads / U	USB Keyboard		
	System Keypad size	100	<b>;</b> %	
-	USB Keyboard layout			
TTP	Vienti			
-		ut user after period of in	nactivity.	
<b>₽</b> ₽	Inactivity period	15	minutes	
	V Screen Saver			
	Screen søver type	-		
VIIE	Activate after	15	minutes of inactivity	
	▼ Screen Brightness			
	Screen brightness	200	1	
	System Menu			
	Double-Tap Interval	1 Second		
		Top Left	📕 Tap Right	
	Detectable Corner	Bottom Left	🖾 Bottom RighI	
	a see bu			in the second
	Touch Input Notifica	tion		
	Alarm Notification	ype Continuous		
		rity User Foult Level 8		
	Y Internal Retained Me			
	Maximum Number of U			
		oc nameogo www		

Item	Description
Startup Page	
Page name	Sets the page to display first when the HMI is started.
Startup Language	
Startup language	Sets the project language to use when the HMI is started.
Software Keypads/USB Keyboard	
System Keypad Size	Sets the display size of the system keypad.
USB Keyboard layout	Sets the layout of the USB keyboard.
Security	
Automatically log out user after	Select this check box to automatically log out the user after a specified
period of inactivity.	period of inactivity.
Inactivity period	Specify the time of inactivity before the user is logged out automatically.
Screen Saver	
Screen saver type	Sets the type of screen saver.
Active after	Sets the time after the screen is touched before the screen saver is started.
Screen Brightness	
Screen brightness	Sets the brightness of the screen.
System Menu	
Double-tap Interval	Sets the interval to use to detect double taps.
Detectable corner	Select the corners in which to detect the operation to display the System Menu.
Sound	
Touch Input Notification	Sets whether to beep when an input is accepted.
Alarm Notification	Sets the buzzer that is beeped when an alarm occurs, specifically, the type
	of buzzer and the user alarm level.
Internal Retained Memory Settings	
Maximum Number of User	Sets the maximum number of alarm logs to save in the NA.
Alarm Logs	

3-4 HMI Settings

3

#### 3-4-3 TCP/IP Settings

#### These are the settings for TCP/IP.

P / IP Settings
Aurt 1 - IP Address
IP Address 192 104.250 _2
ubnet mask 255 255 255 _0
ult gateway
fort 1 - DNS
DNS server
DNS server
VINS server
VINS server
Ant 2 - IP Address
nection with Sysmac Studio
P Address
ubnet mask
ult gateway
Roit 2 - DNS
DNS server
DNS server
VINS server
VINS server
the second se

The following settings are provided for Ethernet port 1 and Ethernet port 2.

Item	Description
Ethernet Port 1 - Settings	
IP Address	Sets the local IP address.
Subnet mask	Sets the subnet mask.
Default gateway	Sets the IP address of the default gateway. This setting is not required when
	a default gateway is not used.
Primary DNS server	Sets the IP address of the primary DNS server.
Secondary DNS server	Sets the IP address of the secondary DNS server.
Primary WINS server	Sets the IP address of the primary WINS server.
Secondary WINS server	Sets the IP address of the secondary WINS server.
Ethernet Port 2 - Settings	
Direct connection with Sys-	Select this check box to connect Ethernet port 2 directly to the Sysmac Stu-
mac Studio	dio without going through an Ethernet switch. If you select this check box,
	the IP addresses and other settings for Ethernet port 2 are ignored.
IP Address	Sets the local IP address.
Subnet mask	Sets the subnet mask.
Default gateway	Sets the IP address of the default gateway. This setting is not required when
	a default gateway is not used.
Primary DNS server	Sets the IP address of the primary DNS server.
Secondary DNS server	Sets the IP address of the secondary DNS server.
Primary WINS server	Sets the IP address of the primary WINS server.
Secondary WINS server	Sets the IP address of the secondary WINS server.

## 3-4-4 FTP Settings

These are the FTP server settings.


IMI Settings ×
FTP FTP Settings
FTP server 🔘 Do not use 🔎 Use
Login name 71P Password Contraction
FTP
ПТР
vnc

Item	Description
FTP Settings	
FTP server	Specifies whether to use the FTP server of the HMI.
Login name	Sets the login name to externally connect to Ethernet port 1 or 2 on the HMI via FTP. You can use up to 12 alphanumeric characters.
Password	Sets the password to use to externally connect to Ethernet port 1 or 2 via FTP. You can use 8 to 32 alphanumeric characters.

## 3-4-5 NTP Settings

These are the settings for an NTP (Network Time Protocol) client.

The HMI gets the clock information from the specified NTP server at the specified interval and updates the built-in clock information.



	Item	Description
NTP Settings		
	Synchronize with an Internet	Select this check box to synchronize the built-in clock in the HMI with the
	time server	clock information from the NTP server.
	NTP server	Sets the IP address of the NTP server.
	Interval	Sets the interval at which to get the clock information from the NTP server.

## 3-4-6 FINS Settings

These are the settings for FINS communications.

These settings are required when FINS communications are used between the HMI and a CJ-series PLC.

HMI Settings	× .
L.	FINS Settings
	▼ FINS Address
TCP 71P	Network Nade Ethemet.port #1. 1
	Ethernet port #2 2
STE	▼ FINS/UDP
	RINS/UDP port no UU
	🔻 Remote Network Table
DI	Remote Network Relay Network Relay Node
E.H	
_	
VIC	
Atés	

ltem	Description
INS Address	
Ethernet port #1	Sets the FINS network address of Ethernet port 1.
	The FINS node address is automatically created from the IP address.
Ethernet port #2	Sets the FINS network address of Ethernet port 2.
	The FINS node address is automatically created from the IP address.
FINS/UDP	
FINS/UDP port no	Displays the port number used for FINS/UDP.
Remote Network Table	Sets the routing table.

## 3-4-7 VNC Settings

These are the settings for VNC (Virtual Network Computing).

VNC implements a remote desktop to allow remote control of a computer located on a network.

You must enable the server functionality on the HMI to control. You can start the client software on the computer from which to perform remote control, connect to the HMI, and then control it remotely.

□ HMI Setti	ngs	17 A A I X
	vnr VNC Settings	
	VNC Server Do not use Use	
	Port No. 201	
MP	Mode Password	
	rassivoitu Enable login 🔿 Disable 🌰 Enable	
FTP	Enable registered dient login 🍙 Disable 🗴 Enable	
	19 Address MAC Address Comment	3
IDC		
JUC		

Item	Description	
VNC Settings		
VNC Server	Specifies whether to use VNC.	
Port No.	Sets the port number.	
Mode	Sets the operations to enable from the VNC client.	
Password	Sets the password.	
Enable VNC multiple login	Specifies whether to allow multiple clients to log in.	
Enable registered client login	Specifies whether to allow only certain clients to log in.	
IP Address	Registers the IP addresses of the client devices to be allowed	
	to log in.	
MAC Address	Registers the MAC addresses of the client devices to be allowed to log in.	
	(e.g., 3D:F2:C9:A6:B3:4F).	
Comment	Specifies a comment.	

## 3-4-8 Printing Settings

These are the settings for printing and capturing screens on the HMI.

You can capture screens displayed on the HMI.

III ⊢MI Sett	ings	© @ @ ® • □ X
	Printing Settings	
	▼ Printing Settings	
TEP	Color Vith Title 🔵 Without Title 💭 With Title	
FTP		
TTE		
Vnc		
Ę		
		1


ltem	Description
Printing Settings	
Color Mode	Sets one of the following options for the number of colors or use of highlight-
	ing:
	• Color
	Grayscale
	Reverse Grayscale
Print With Title	Sets whether to print the page title.

# **3-5 Security Settings**

These settings are used to restrict the operations that can be performed on the HMI and register accounts.

## **Setting Procedure for Security Settings**

**1** Double-click **Security** under **Configurations and Setup** in the Multiview Explorer. The Security Settings Tab Page is displayed in the Edit Pane.



ltem	Description
User Accounts	Registers user accounts.
Roles and Access Levels	Sets the access level for each role.
Security Settings	Sets the level of operations to permit from the System Menu.

## **3-6 Troubleshooter**

These settings are used for the troubleshooter for the NJ/NX series.

Refer to the NA-series Programmable Terminal Hardware User's Manual (Cat. No. V117) for details.

# 3-7 Language Settings

These settings are used for multi-language projects.

## Project Language and System Language

There are two languages on the HMI.

Project Language

The project language is displayed for the project that you create.

System Language

The system language is displayed for the System Menu and for error messages displayed by the system.

The two language settings are managed as pairs. If you change the project language, the paired system language will also change.

#### Language Setting Procedure

**1** Double-click Language Settings under Configurations and Setup in the Multiview Explorer. The Language Settings Tab Page is displayed in the Edit Pane.

Language Settings			ന് ക ര	19. y 🖬
-fault language				
Project Languages English (United States)	System Languages English (United States)	Software Keypads Standard	Transfer to Device	
Other languages				
Project Languages	System Languages	Saitware Keypads	Transfer to Device	
+				

Item	Description
Default language	Sets the language that is displayed by default.
Other languages	Sets the languages to add in addition to the default languages.
System languages	Sets the language to display system menus or system error messages.
Software keypads	Sets whether to use the default system keypad or a custom keypad.

#### Additional Information

You can clear the selection of the *Transfer to Device* Check Box so that the language files are not transferred to the HMI. You can use this to delete unnecessary languages depending on the destination of the HMI.

# 3-8 HMI Clock


To set the clock in the HMI, select *HMI Clock* from the HMI Menu when you are online. Set the required items and click the **Apply** Button to update the information in the HMI.

HMI Clock	<b>×</b>
TimeZone	
Computer	HMI
(UTC-08:00) Pacific Time (US & Canada)	UTC
	Automatically adjust clock for DST
	Apply
Date and time	
Computer	HMI
6/5/2014	6/5/2014 15
>> Synchronize wi	03 : 12 : 12
	Apply
	Close

Item	Description
Time Zone	
Computer	Displays the time zone of the computer.
HMI	Sets the time zone of the HMI
Automatically adjust clock for	Select this check box to enable automatically adjusting for daylight savings
DST	time.
Date and time	
Computer	Displays the current date and time on the computer.
Synchronize with computer	Updates the clock information on the HMI with the clock information from the
	computer.
HMI	Set the clock information on the HMI.

# 3-9 Updating the HMI Name

To change the HMI name, select *HMI Name* from the HMI Menu when you are online. A confirmation dialog box is displayed. To update the HMI name that is set in the project, click the **Yes** Button.



# 3-10 Write Protecting the HMI

To write-protect the HMI, select **Security - HMI Write Protection** from the HMI Menu when you are online.

A confirmation dialog box is displayed. Click the Yes Button to write-protect the HMI.



Only the project is write-protected. The project can still log data and write other data.

# 3-11 Clear All Memory

You can initialize the HMI.

When you perform the Clear All Memory operation, all data is cleared except for time data. To clear all memory in the HMI, select *Clear All Memory* from the HMI Menu when you are online.


A confirmation dialog box is displayed. Click the OK Button to clear all memory.



# **3-12 Resetting the HMI**

You can reset the HMI.

To reset the HMI, select **Reset HMI Device** from the HMI Menu when you are online. A confirmation dialog box is displayed. Click the **Yes** Button to reset the HMI.



# 4

# **Creating the HMI Application**

This section describes how to create the HMI application (pages, variables, subroutines, etc.) with the Sysmac Studio.

4-1	Regis	tering Variables	4-3
	4-1-1	Variables	4-3
	4-1-2	Registering Global Variables	4-4
	4-1-3	Registering External Variables	4-5
	4-1-4	Attributes and Entry Methods for Global Variables	4-6
	4-1-5	System-defined Variables	4-9
	4-1-6	Subroutine Variables	4-12
4-2	Regis	stering Data Types	4-13
4-3	Creat	ing Pages	4-14
	4-3-1	Displaying Pages	
	4-3-2	Registering Pages	
	4-3-3	Page Property Settings	
	4-3-4	Editing Pages	
4-4	Settin	ng Common Object Functions	4-22
	4-4-1	Registering User Alarms	4-22
	4-4-2	Setting Controller Events	4-23
	4-4-3	Registration for Data Logging	4-26
	4-4-4	Registering Data Groups	4-27
	4-4-5	Registering Recipes	4-28
	4-4-6	Registering Custom Keypads	
	4-4-7	Setting Global Events and Corresponding Actions	4-31
	4-4-8	Registering Global Subroutines	4-34
	4-4-9	Setting Up Resources	
	4-4-10		
	4-4-11	Registering Scaling	4-37
4-5	Subro	outines	4-39
	4-5-1	Subroutine Execution	4-40
	4-5-2	Precautions on Internal Processing	4-44
	4-5-3	Code Editor	4-45
	4-5-4	Differences in Language Specifications	4-45
4-6	Searc	h and Replace	4-46

4-7	Cross	References
	4-7-1	Cross References
4-8	Buildi	ng4-48
	4-8-1	Building
	4-8-2	Build Operation
4-9	Offlin	e Comparison

# 4-1 Registering Variables

#### 4-1-1 Variables

A variable is a 'container' that holds data.

The HMI supports the following types of variables.

	Variable type	Description					
Glob	oal variables	Global variables are defined by the user and can be accessed from anywhere in the project. You can register up to 35,000 total in the entire project and up to 30,000 for each connected device. <sup>*1</sup>					
		Global variables are declared in the HMI global variable table.					
		Global variables include external variables and internal variables, which are described below.					
	External variables	External variables are global variables that are used to access data in Controllers and other connected devices.					
		External variables are assigned to device variables in the variable mapping.					
	Internal variables	An internal variable can be used only within the HMI.					
		All global variables that are not external variables are internal variables.					
	System-defined variables	System-defined variables are provided in advance in the HMI. The names and all attributes are defined by the system. They have specific functions.					
		You cannot change the variable names or any other attributes of these variables.					
Sub	routine variables	Subroutine variables are defined by the user and are used only within subroutines.					
		Subroutine variables are declared in Dim statements in page subroutines or global subroutines.					
		You can use all of the data types that are supported by Visual Basic.					

\*1. For the Runtime version 1.02 or lower, the registerable numbers are up to 35,000 in the entire project, and up to 20,000 for each connected device.

#### 4-1-2 Registering Global Variables

#### • Opening the Global Variable Tab Page

Double-click **Global Variables** under **HMI** - **Data** in the Multiview Explorer. Or, right-click **Global Variables** under **HMI** - **Data** and select *Edit* from the menu.



The global variable table is displayed in the Edit Pane.

	Data Type	Initial Value	I AT	Retain	Constant	Update Rate		Scaling I	Comment
MI_blnValue1	Boolean					None	None		
MI_intValue1	Integer					None	None		

The basic Sysmac Studio operations for the global variable table generally apply to HMIs. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for the basic operations.

However, the following items are different. Refer to 4-1-4 Attributes and Entry Methods for Global Variables on page 4-6.

ltem	Description
Name	There are specific prohibited characters that apply to HMIs.
Data Type	There are specific data types for HMIs.
AT	You can set the device variables to which to assign the global variables. This setting is not used for internal variables.
Update Rate	You can select the interval at which to get values from the connected device. This set- ting is used only for external variables.
Scaling	You can select a conversion expression for the value obtained from the connected device. This setting is used only for an external variable.

#### Additional Information

Even if you change the name of a previously registered global variable, the name of the variable accessed from objects or subroutines will not change.

## 4-1-3 Registering External Variables

## **External Variables**

External variables are global variables that are used to access data in connected devices.

## **Creating External Variables**

External variables are created in the variable mapping.

The global variables are mapped to the connected device variables.

In the variable mapping, you can create new variables or you can select variables that were previously created.

If you create a new external variable in the variable mapping, it will automatically be registered as a global variable.

Refer to 3-3 Mapping Variables on page 3-7 for details on the variable mapping.

## Attributes of External Variables

If you create a new external variable in the variable mapping, the following attributes are registered for it in the global variable table.

Refer to 4-1-5 System-defined Variables on page 4-9 for details on the attributes of variables.

Attribute	Setting	Changes to set- tings
Name	Specified variable name	Possible.
Data Type	Refer to the NA-series Programmable Terminal Device Connection User's Manual (Cat. No. V119) for details on data type for the HMI global variables based on data types for device variable.	Possible.
Initial Value	None	Not possible.
AT	Device_name.Device_variable_name	Possible.
Retain	Non-retained	Not possible.
Constant	None	Not possible.
Update Rate	500 ms	Possible.
Scaling	None	Possible.
Comment	Specified comment	Possible.

#### 4-1-4 Attributes and Entry Methods for Global Variables

This section describes attributes and entry methods for global variables.

## Attributes of Global Variables

• Name Attribute



Enter a text string for the name. Observe the following restrictions.

- You cannot use any symbols except for underscores.
- The first letter cannot be a number.
- The names are not case sensitive.
- You cannot use names that start with "\_HMI", "\_eHMI\_", "\_sHMI\_", "\_uHMI\_", or "\_SyxSPC\_".
- You cannot use names that are reserved for the Sysmac Studio or Visual Basic.
- You cannot use more than 127 characters.
- · You cannot use three underscores in a row.

#### • Data Type Attribute



Enter a data type directly or select one from the list.

You can use the following data types, which are supported by Visual Basic. Arrays of the data types that are supported by Visual Basic are also supported. If you specify an array, specify the element number in parentheses after the data type in the same way as in Visual Basic.

Classifica- tion	Data type	Data type name	Size	Range of values			
Basic data	Boolean	Boolean	—	True or False			
types	Byte	Byte	1 byte	0 to 255 (unsigned)			
	Char	Char	2 bytes	0 to 65,535 (unsigned)			
	Date	Date	8 bytes	0:00:00 (midnight) on January 1, 0001 through 11:59:59 PM on December 31, 9999			
	Decimal	Decimal	16 bytes	0 through +/-79,228,162,514,264,337,593,543,950,335 (+/-7.9E+28) with no decimal point; 0 through +/-7.9228162514264337593543950335 with 28 places to the right of the decimal; smallest nonzero number is +/-0.00000000000000000000000000000000000			
	Double	Double	8 bytes	-1.79769313486231570E+308 through -4.94065645841246544E-324 for negative values; 4.94065645841246544E-324 through 1.79769313486231570E+308 for positive values			
	Integer	Integer 4 bytes -2,147,483,648 through 2,147,483,647 (signed)					
	Long	Long	9,223,372,036,854,775,807 (9.2E+18) (signed)				
	SByte	SByte	1 byte	-128 through 127 (signed)			
	Short	Short	2 bytes	-32,768 through 32,767 (signed)			
	Single	Single	4 bytes	-3.4028235E+38 through -1.401298E-45 for negative values; 1.401298E-45 through 3.4028235E+38 for positive values			
	String	String	Variable length	0 to approximately 2 billion Unicode characters			
	UInteger	UInteger	4 bytes	0 through 4,294,967,295 (unsigned)			
	ULong	ULong	8 bytes	0 through 18,446,744,073,709,551,615 (1.8E+19) (unsigned)			
	UShort	UShort	2 bytes	0 to 65,535 (unsigned)			
Derivative	TimeSpan	Structure that	at gives a tin	ne interval			
data types	Structures/ Unions/ Enumerations	This is a use group. You can nan		ata type that integrates different data types into a single type.			
		Specify the r	name of the	variables that use the user-defined data type, and one included in the group.			

Refer to the *NA-series Programmable Terminal Device Connection User's Manual* (Cat. No. V119) for information on which of the above HMI variable data types can be assigned to the data types of connected device variables for different connected devices.

#### Initial Value Attribute



Specify a value for the variable for one of the following situations when the Retain attribute is not specified.

- · When the power supply is turned ON
- · When you specify to initialize the value when the project is transferred

Enter a value directly or select an item from the list (the values in the list depend on the data type). If you do not enter an initial value, 0 is used as the initial value.

Select None for no initial value. You cannot specify the Initial Value attribute for an external variable.

#### AT Attribute



This attribute is specified for external variables. Use the following format.

Device\_name.Device\_variable\_name

#### Retain Attribute

🔤 Global Variables 🗙					-					-
Name	Data Type	Initial Value	I AT	Retain	Constant	Update Rate	I	Scaling	I	Comment
HMI_blnValue1	Boolean		new_Cont…			500 Milliseconds	None			

Specify whether to retain the value of the variable in the following cases.

- · When the power supply is turned ON
- · When you do not specify to initialize the value when the project is transferred

You cannot specify the Retain attribute for an external variable.

#### Constant Attribute



If you set the Constant attribute, you can set the initial value of the variable when the project is downloaded, but you cannot overwrite the value afterward.

You cannot specify the Constant attribute for an external variable.

#### • Update Rate Attribute

MI_binValue1 Boolean new_Cont ···  500 Milliseconds 500 Milliseconds 100 Milliseconds 100 Milliseconds 10 Seconds 10 Seconds 10 Seconds 10 Seconds 10 Seconds 10 Seconds 10 Minutes 10 Minute 10 Minutes 10 Minutes 10 Minut	Name	Data Type	Initial Value	I AT	Retain	Constan	t   Update Rate	Scaling	Comment
100 Milliseconds 500 Milliseconds 1 Second 2 Seconds 3 Seconds 10 Seconds 30 Seconds 1 Minute 5 Minutes	MI_blnValue1	Boolean		new_Cont…			500 Millisecor 🔻 No	e	
SOI Milliseconds 1 Second 2 Seconds 5 Seconds 10 Seconds 30 Seconds 1 Minute 5 Minutes									
1 Second 2 Seconds 5 Seconds 10 Seconds 30 Seconds 1 Minute 5 Minutes									
2 Seconds 5 Seconds 10 Seconds 30 Seconds 1 Minute 5 Minutes									
5 Seconds 10 Seconds 30 Seconds 1 Minute 5 Minutes									
10 Seconds 30 Seconds 1 Minute 5 Minutes									
30 Seconds 1 Minute 5 Minutes									
1 Minute 5 Minutes									
5 Minutes									

The update interval with the connected device is specified for external variables. If *None* is set for an external variable, the external variable will be treated as an internal variable. In that case, no communications for the variable will be performed with the connected device. You do not need to specify this attribute for an internal variable.

#### Scaling

Specify a conversion expression to apply to the values of the connected device for external variables.

For information on setting the conversion expression, refer to *4-4-11 Registering Scaling* on page 4-37.

#### Comment Attribute




#### 4-1-5 System-defined Variables

## System-defined Variables

System-defined variables are internal variables that are pre-defined by the system. All system-defined variable attributes are fixed. The names and all other attributes of these variables are defined, and special functions are assigned to them. You cannot change the names or any other attributes.

- You can use the system-defined variables for an HMI as soon as you register an HMI in the project. It is not necessary to register system-defined variables in the global variable table.
- System-defined variables that are related to an HMI start with "\_HMI\_".



## System-defined Variables

## • System-related Variables

Variable name	Meaning	Description	Data type	R/W
_HMI_Brightness	Brightness	Sets the brightness of the screen.	Integer	R/W
_HMI_CanEjectSDCard	Can Eject SD Card	Tells whether you can remove the SD Memory Card.	Boolean	R
		True: Ejection is possible, False: Ejec- tion is not possible.		
_HMI_ConnectedVNCClient Count	Connected num- ber of VNC Client	Gives number of client via VNC.	Integer	R
_HMI_CurrentPage	Current Page Name	Sets the name of the currently dis- played page.	String	R/W
_HMI_DateTime	System Time	Gives the system clock time as the local time.	Date- Time	R
_HMI_Hour	Current Hour	Gives the hour in the current time.	Integer	R
_HMI_IsBatteryLow	Low Battery Volt- age	Gives True if the battery voltage has dropped below a specific level.	Boolean	R
_HMI_lsDataInput	Data Entry in Progress	Gives True when a data entry object is selected.	Boolean	R
_HMI_IsPageSwitching	Page Switching in Progress	Gives True while page switching pro- cessing is in progress and False after processing is completed.	Boolean	R
_HMI_IsScreenSaverActive	Screen Saver Sta- tus	Tells whether the screen saver is active. True: Active, False: Not active.	Boolean	R/W
_HMI_ManagedRAMInUse	Usage of Man- aged RAM	Gives the total bytes of managed RAM that is currently allocated to some process.	ULong	R
_HMI_Millisecond	Current Millisec- onds	Gives the milliseconds in the current time.	Integer	R
_HMI_Minute	Current Minutes	Gives the minutes in the current time.	Integer	R
_HMI_RAMInUse	Usage of RAM	Gives the total bytes of RAM that is currently allocated to some process.	ULong	R
_HMI_RAMTotal	Total RAM	Gives the total bytes of RAM that the system is using or can use. This is not the currently usable amount of RAM.	ULong	R
_HMI_RunSignal	Run Signal	Changes periodically while the HMI is operating.	Boolean	R
_HMI_Second	Current Seconds	Gives the seconds in the current time.	Integer	R

#### • Alarm-related Variables

Variable name	Meaning	Description	Data type	R/W
_HMI_AlarmCount	Alarm Count	Gives the number of alarms that have occurred since startup.	Integer	R
_HMI_AlarmsClearedNotAck	Cleared Unac- knowledged Alarms	Gives the number of alarms that are cleared but not acknowledged.	Integer	R
_HMI_AlarmsNotAck	Unacknowledged Alarm Count	Gives the number of alarms that are not acknowledged.	Integer	R
_HMI_AlarmsRaised	Current Alarm Count	Gives the number of current alarms.	Integer	R
_HMI_AlarmsRaisedNotAck	Unacknowledged Current Alarm Count	Gives the number of current alarms that are not acknowledged.	Integer	R

#### • User and Security

Variable name	Meaning	Description	Data type	R/W
_HMI_CurrentUserName	Current User Name	Gives the name of the user that is cur- rently logged in.	String	R
_HMI_CurrentUserRole	Current User Authority	Gives the authority (role) of the user that is currently logged in.	String	R

## System Enumeration Variable Table

The following table shows the enumeration variables that are used to control the HMI.

Enumerators are specified for input enumeration variables instead of numerical values.

Data type name	Description
_eHMI_BUZZER_TYPE	Specifies the buzzer mode.
	ContinuousBuzzer: Continuous buzzer
	IntermittentLongPulse: Intermittent long buzzer
	IntermittentShortPulse: Intermittent short buzzer
_eHMI_GRAPH_CURSOR	Specifies the cursor for graphs.
	Cursor1: Cursor 1
	Cursor2: Cursor 2
_eHMI_GRAPH_DIRECTION	Specifies the direction of graphs.
	Left: Left
	Right: Right
_eHMI_GRAPH_ZOOM_TARGET	Specifies the expansion mode for graphs.
	Both: Both
	Horizontal: Horizontal direction only
	Vertical: Vertical direction only
_eHMI_KNOWN_PATH	Specifies the medium.
	SDCard: SD card
	USBMemory: USB memory
_eHMI_SERVICE_STATE	Specifies the state of the service.
	Running: Running
	Suspended: Suspended

Data type name	Description
_eHMI_SERVICE_TYPE	Specifies the type of the service.
	VNCServer: VNC server
_eHMI_TROUBLESHOOTER_PAGE	Specifies the screen displayed for the troubleshooter.
	ActiveControllerEvents: Controller error list screen
	ActiveUserEvents: User error list screen
	ControllerEventLogs: Controller error log list screen
	UserEventLogs: User error log list screen
_eHMI_VERTICAL_SCROLL_DIRECTION	Specifies the direction of scrolling.
	Downwards: Downwards
	Upwards: Upwards

## System Structure Variable Table

The following table shows the structure variables that are used to control the HMI.

Data type name	Variable	Data type	Description
_sHMI_VNC_CLIENT_INFO	Comment	String	Specifies a comment.
	IPAddress	String	Specifies an IP address.
	MACAddress	String	Specifies a MAC address.

#### 4-1-6 Subroutine Variables

## Subroutine Variables

Subroutine variables can be used only with subroutines. Subroutine variables conform to Visual Basic specifications.

Refer to the NA-series Subroutine Reference for details.

# 4-2 Registering Data Types

#### • Registering Data Types

You can combine existing data types to define and register a new data type.

To use a data type that was registered with the Data Type Editor, just select it from the data types in the Variable Editor. You can define data types that are structures or enumerations.

#### Opening the Data Types Tab Page

1 Double-click Data Types under HMI - Data in the Multiview Explorer, or right-click Data Types under HMI - Data and select Edit from the menu.



The Data Type Editor is displayed.

📴 Data Types	×						•
root							$\mathbf{v}$
Structures	I Name	1	Base Type	1	Comment	1	
Union	Empty. Click here to add Item.						
Enumerated							

The basic operating procedures for the Data Type Editor are the same throughout the Sysmac Studio. For basic usage instructions, refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504). The differences are as follows:


- · You cannot register unions.
- You cannot set the offset type, offset bytes, or offset bits.

# 4-3 Creating Pages

One page represents one screen in the HMI project.

You can arrange various objects on a page to achieve the required functions.

There are two types of pages, as described in the following table.




#### Main Pages

The main pages are the basic pages. You can create applications to call popup pages from main pages or move to other main pages. You can place up to 450 objects on one main page. You cannot place more than one Trend Graph, Broken-line Graph, or Media Player object on one page.

You can create layers of main pages.

You can specify a background page to make the top layer transparent and place a specified page underneath it. You can layer up to five pages including the main pages.

You can create a common page, e.g., with a toolbar, to display with all other pages and then specify it as the background page so that you do not have to create it more than once.



#### Popup Pages

Popup pages are called from main pages. Use them to display warnings and other information. You can place up to 450 objects on one popup page. You cannot display more than one popup page at the same time. Also you cannot place Trend Graph, Broken-line Graph, Tab Control, or Media Player objects on a popup page.

#### 4-3-1 Displaying Pages

Click Pages under HMI in the Multiview Explorer.

▼ HMI
■ ▶ m Pages

The pages are displayed under Pages.

▼ HM	[	1
-	🔻 🖬 Pages	0
	- ## Pagel	

#### 4-3-2 Registering Pages

The project contains one page by default, and you can add more pages as required.

## **Registering New Pages**

**1** Right-click **Pages** under **HMI** and select **Add - Page** from the menu.



A new page, Page1, is added under Pages.

## **Deleting Pages**


Right-click the page to delete in the Multiview Explorer and select *Delete* from the menu.
 A deletion confirmation dialog box is displayed.



Click the Yes Button. The page is deleted.


## **Copying and Pasting Pages**

1 Select the page to copy in the Multiview Explorer and press the **Ctrl + C** Keys. Or, right-click the page and select **Copy** from the menu.




The page is copied.

2 Select Pages in the Multiview Explorer and press the Ctrl + V Keys. Or, right-click Pages and select *Paste* from the menu.



The copied page is registered with "Copy\_1\_of\_" added to the front of the name of the page that was copied. All of the objects on the page are also copied.



#### Additional Information

- You can change the names of pages. Right-click the page and select *Rename* from the menu.
- If you copy a page from another product and a page with the same name already exists, the page will be named as a copy.

## 4-3-3 Page Property Settings

You can set properties for the pages.

## **Setting Properties**

- **1** Right-click in a location in the Edit Pane where there is no object and select **Properties**.
- **2** Set the properties for the page in the Properties Window that is displayed.

Item classifi- cation	Property	Description	Main pages	Popup pages
General	Name	Sets the name of the page. All names must be unique.	ОК	ОК
	Туре	The object type is dis- played. <b>Page</b> is displayed for a page.	Display only	Display only
Appearance	Background Color	Sets the background color. A transparent page will automatically be set if a background page is specified.	ОК	ОК
Behavior	PageType	Sets the type of page.	OK	OK
	BackgroundPage	Sets a page that is over- lapped as the back- ground.	ОК	
	AutoNavigateKeypads	If you select this check box, the keypad is auto- matically displayed according to the Data Input Order settings.	ОК	ОК
	DisplayMode	If you select <b>Modal</b> , no operations are possible on the main page while a popup page is displayed. If you select <b>Modeless</b> , main page operations are possible while a popup page is displayed.		ОК
	Moveable	If you select this check box, the popup page can be moved.		ОК
	CloseOnPageChange	If you select this check box, the popup page is automatically closed when the page is changed.		ок

Item classifi- cation	Property	Description	Main pages	Popup pages
Layout	Position (Let, Top)	Sets the display position of the popup page. If you select <b>Custom</b> , the coor- dinates of the top left cor- ner of the page are specified with (Left, Top).		ОК
	Size (Width, Height)	Sets the size of the page. The maximum size is the physical size of the screen.	Display only	ОК

OK: Can be edited, Display only: Cannot be edited, ---: Property does not exist.

Click the arrowhead  $(| \bullet |)$  at the right of each item to make selections.

If you select a popup for the behavior setting, you can increase and decrease the width and

height layout sizes with the arrowheads and the right side of the box after first selecting the size to change (left: width, right: height).

V Behavior	
PageType	Рорир 🔻
▼ Layout	
Size (Width,Height)	480, 240

#### 4-3-4 Editing Pages

You can arrange objects on the pages to achieve the required functions.


## **Positioning Objects**

Drag objects from the Toolbox to position them on a page.

ile Edit View Intext Project	Hini Simulation Tools Hulp				
* * * * * * *		1-1-1-0-5	REQ	9 🔺 🎽 0	
Altiveev Explore: Control of the second secon					Source Retain     Monochary Inter-     Monocha
Filter 🕐	Couput	ngjecu		• 1 ×	Custom Antony Conveyors Conveyors Button A Button cojuct


## Moving Objects

To move an object, click the object and drag it while the cross cursor is displayed.




## Resizing Objects

Click one of the resize handles around the object and drag it while the resizing cursor is displayed.



## **Rotating Objects**

Click the rotation handle 🕥 to the upper right of the object and drag it while the angle is displayed in the center of the object.



## **Changing Object Labels**

You can directly change the label of an object by selecting it and performing one of the following operations.

- Press the F2 Key.
- Double-click the left mouse button.
- Right-click and select Edit.
- Click the *Edit* Button on the Toolbar.



The following objects are supported for this function:

- All the button objects including Buttons, Momentary Buttons, Set Buttons, Reset Buttons, and Toggle Buttons
- · All the lamp objects including Bit Lamps and Data Lamps
- · Label objects
- Text Box objects
- Check Box objects
- · Radio Button objects

#### Editing with the Toolbar

The functions that are commonly used to edit pages are provided in the Toolbar.

Group This button creates a group of objects.
This button ungroups previously grouped objects.
Edit This button is used to edit graphic objects, labels of Button or Lamp objects, and other objects.
Rotate Right 90 Degrees This button rotates an object 90° clockwise.
Rotate Left 90 Degrees This button rotates an object 90° counterclockwise.
Flip Vertical This button flips a graphic object vertically.
Flip Horizontal This button flips a graphic object horizontally.
Bring to Front This button moves an object to the front.
Bring Forward This button moves an object toward the front.

Send Backward This button moves an object toward the back.
Send to Back This button moves an object to the back.
Align Left This button aligns the left edges of the selected objects.
Align Center Horizontal This button aligns the centers of the selected objects vertically.
Align Right This button aligns the right edges of the selected objects.
Align Top This button aligns the top edges of the selected objects.
Align Center Vertical This button aligns the centers of the selected objects horizontally.
Align Bottom This button aligns the bottom edges of the selected objects.
Distribute Horizontally This button positions the centers of the objects at equal distances horizontally.
Distribute Vertically This button positions the centers of the objects at equal distances vertically.
To Previous Tab Page This button displays the previous tab page.
To Next Tab Page This button displays the next tab page.
Data Input Order Setting This button changes the mode to the one to set data input order, and specifies the input order of objects.
Simulation Mode This button changes the mode to the one to confirm object state.
Simulation Index This button switches the index and lets you confirm the display state of objects.
English (United States)  Change Language

This box changes the project language that is displayed in the Edit Pane.

4-3 Creating Pages

4

4-3-4 Editing Pages

# **4-4 Setting Common Object Functions**

This section describes the settings for functions that are shared by the entire HMI project.

The following functions are provided.

- User alarms
- Controller events
- Data logging
- Data groups
- Recipes
- · Custom keypads
- · Global events
- · Global subroutines
- Resources
- Imported IAGs
- Scale Transformations

#### 4-4-1 Registering User Alarms

## **User Alarms**

You can specify conditions for specified variables to display user messages when the conditions are met.


You can use this to record information when errors occur, when operation is started, etc.

#### **Registering a New User Alarm**

You manage user alarms by group.

The groups are displayed in the User Alarms Viewer and are helpful in organizing information.

**1** Right-click **HMI** under **User Alarms** in the Multiview Explorer and select **Add - Group** from the menu.




Group1 is added under User Alarms.



## **2** Double-click the new group.

A tab page to edit the group is displayed in the Edit Pane so that you can register user alarms.



#### Additional Information

You can copy the user alarm settings to Excel or another spreadsheet application to edit the settings.

## Deleting, Copying, and Pasting Groups

You can delete, copy, and paste groups using the same procedures as those that you use for pages.

## 4-4-2 Setting Controller Events

## **Events**

Events are the errors, changes of states, or user-defined occurrences that occur in the controller. For details, refer to the *NJ-series CPU Unit Software User's Manual (Cat. No. W501)* and *NJ-series Troubleshooting Manual* (Cat. No. W503).

## **User Events**

User event s include the errors and information defined by users, and can be triggered by commands from the controller.

You can specify on the NA's NJ/NX-series troubleshooter, the user screens to be switched to from the troubleshooter screen when a detailed user event of the controller is displayed.

IJ/NX Troubleshooter			7/2/2015 3:19:50 PM	
Event Type	Error		6ack	
Event Name	test_event			
Event Code	123	Date/Time	7/2/2015 3-28:12 PM	
Group				
Event Level	User fault Level 1			
	-			
Detailed Information testtest2				
testtest2				
testtest2 Attached Info 1	0x00			
testtest2				
testtest2 Attached Info 1	0x00		Show Specified Page	


## **Registering User Events**

To switch a detailed user event screen of the troubleshooter to a user screen, you must specify the event table for the controller and the transition destination screen that corresponds to each event.

**1** Specify the event table of the user events in the project for the controller.

Multiview Explorer	🕨 Event Settings 🗙			-
new_Controller_0 💌	📕 Edit multiple table			
<ul> <li>Configurations and Setup</li> <li>EtherCAT</li> <li>CPU/Expansion Racks</li> <li>I/O Map</li> <li>IC Ontroller Setup</li> <li>Motion Control Setup</li> <li>Com Parts Settings</li> <li>Event Settings</li> </ul>	Event CodeEvent N 1 3 2 100 3 3 4 5000	iarne Event Level Group User faut Level 2 User faut Level 2 User faut Level 1 User fau't Level 2	Details	
Task Settings				

2 Double-click User Events under HMI - Controller Events in the Multiview Explorer of the project for the HMI, or right-click User Events under HMI - Controller Events and select *Edit* from the menu.




The User Event Editor is displayed.

🕨 User Events 🗙	<		•
Controller: ne	ew_Controller_0	T	
Event Code   E	Event Name/Comment	Troubleshooter Associated Page	

**3** Select the controller for which to perform the settings.

Select the target controller from the drop-down list at the top of the Edit Pane.



Controller:	new_Controller_0	▼	
Event Code	Event Name/Comment	Troubleshooter Associated Page	
1		Р	
<b>A</b> Pa	ge0		

## Deleting, Copying, and Pasting User Events

You can delete, copy, and paste user events using the same procedures as those that you use for pages.

#### 4-4-3 Registration for Data Logging

## **Data Logging**


You can use data logging to store the changes in the values of specified variables over time. You can display the saved data with Trend Graph objects. You can also save this data to external files.

## **Registering a New Data Set**

To log data, you must create one or more data sets. You can create different data sets to change the location where the data is saved.

1

Right-click HMI - Data Logging in the Multiview Explorer and select Add - Data Set from the menu.



DataSet0 is added under Data Logging.

▼ HN	11
	🕨 🖮 Pages
	🕨 🐗 User Alarms
	🔍 🔤 Data Logging
0	💷 🌆 DataSet0

2 Double-click the new data set.

> A tab page to make settings for the data set is displayed in the Edit Pane. You can set the variables to log, the storage locations, and other parameters.

Storage Type	197		Start New Database File	
rget Device	S9 Memory Gard	1.	<ul> <li>Daily (from 00:00 - 23:59)</li> <li>After specific time period</li> </ul>	
rget Folder	\Data Logging\Log F es		2	
pdate Type	Regular Interval		After specific number of lo	gs
Jpdate Rate	5 Seconds		Number of logs 1000	-
Automatically St	art on HMI Device			
	Variable	Data Type		Comment



#### **Additional Information**

You can copy the data set settings to Excel or another spreadsheet application to edit the settings.

## Deleting, Copying, and Pasting Data Sets

You can delete, copy, and paste data sets using the same procedures as those that you use for pages.

## 4-4-4 Registering Data Groups

## **Data Groups**

You can register the data groups that are displayed as broken-line graphs.

You can register multiple series of data as a data group. You can also register multiple variables or array variables in each data series.


## Registering a New Data Group

To display a block-line graph, you must create a data group. A maximum of 32 groups can be registered. You can specify up to 20 series of data for a single group.

**1** Right-click **HMI - Data Groups** in the Multiview Explorer and select **Add - Data Groups** form the menu.



DataGroup0 is added under Data Groups.



**2** Double-click the new data group.

A tab page to perform settings for the data group is displayed in the Edit Pane. You can specify variables to be displayed, as well ad other parameters.

A DataGroup0 ×			•
Data Series	Туре	Data Type	Comment
+ 💼			
Variable		Data Type	Comment
+ = + +			

## Deleting, Copying, and Pasting Data Groups

You can delete, copy, and paste data groups using the same procedures as those that you use for pages.

## 4-4-5 Registering Recipes

## Recipes

A recipe is used to write data (numeric data or text strings) that was set in advance in the HMI to all of the specified variables as a group or to read all of the specified variables as a group.

You can manipulate the registered recipe data with Recipe Viewer objects.

## Registering a New Recipe

To use recipes you must create them.

1 Right-click HMI - Recipe in the Multiview Explorer and select Add - Recipe Template from the menu.

HMI		
Pages		
🕨 🐗 User Alarms		
🗆 📠 Data Logging		
📕 🧾 Recipes	Add 🕨	Recipe Template
▶ 🗊 Data	Huu /	neepe rempiate
🗆 🐓 Global Events	Nakie.	
🕨 📄 Global Subroutines	-	

Recipe0 is added under Recipes.

▼ HM	1
-	🕨 🛅 Pages
	User Alarms
	💷 🌆 Data Logging
	🔽 🗐 Recipes
0	💷 📱 Recipe0

**2** Double-click the new **Recipe0**. A tab page to make settings for Recipe0 is displayed in the Edit Pane. You can set the variables to use and other parameters.

RecipeU X	-
Ingredient Name   Variable   Default Value   Min Value   Max Value   Visible   Editable	

#### Additional Information

You can copy the recipe settings to Excel or another spreadsheet application to edit the settings.

## **Deleting, Copying, and Pasting Recipes**

You can delete, copy, and paste recipes using the same procedures as those that you use for pages.

#### 4-4-6 Registering Custom Keypads

## **Custom Keypads**

You can specify the colors, layouts, and other properties of buttons to create keypads.

You can manage custom keypads by creating groups in which to register multiple keypads including Boolean Keypad, Numeric Keypad, Hexadecimal Keypad, QWERTY Keypad, DataTime Keypad, and TimeSpan Keypad.


## Registering a New Custom Keypad

To create a custom keypad, you must first create a custom keypad group. You can register up to 50 groups.


1 Right-click HMI - Custom Keypads in the Multiview Explorer and select Add - Custom Keypad Groups from the menu.

HMI				
💽 🕨 🛅 Pages				
🕨 🖈 🐗 User Alarms				
Controller Events				
Data Logging				
Data Groups				
Recipes				
📕 👘 Custom Keypads		_		_
▶ 🗊 Data	Add	👌 Custo	m Keypad Group	
5 Global Events				

"Goup0" is added under Custom Keypads.



2 Right-click the new custom keypad group, and select *Add* and then select a custom keypad from the menu.



**3** Double-click the new custom keypad.

A tab page to edit the custom keypad is displayed in the Edit Pane. You can set the layout, design, and other parameters for the objects.



## Applying a Custom Keypad

To use a custom keypad, you must specify the custom keypad group to use on the Language Settings Tab Page.

- **1** Double-click Language Settings under Configuration and Setup in the Multiview Explorer.
- 2 Select a custom keypad group from the drop-down list of the Software Keypads in the Edit Pane.

RufeviewTexplorer 💦 🗸 🚇 OvertyKeypado 👘 🖓 Language Settings 🗙					
HEU_NAS_0	Default language Project Languages English (United States)	System Languages Engrish (United States)	Software Keypads Standard	Transfer to Device	
Variable Mapping	Other languages		GroupU Standard		
ロート HMI Settings 論、Security Settings の てのいやまわのter	Project Languages	System Languages –	Software Keypads	Transfer to Devic	
Language Settings					

## Deleting, Copying, and Pasting Custom Keypads or Custom Keypad Groups

You can delete, copy, and paste custom keypads or custom keypad groups using the same procedures as those that you use for pages.

## 4-4-7 Setting Global Events and Corresponding Actions

## **Global Events**

Global events occur at the project level and do not belong to any specific page.

When a global event occurs, the action that is assigned to the event is executed.

Global Events

Global events include function key operations, changes in the values of variables, starting the project, etc. A list of the events that you can set is provided in *A-1 Events and Actions* on page A-2.


#### Actions

You can specify the action to perform when a global event occurs from a list of predefined actions. Actions include executing global subroutines and other system-defined operations. A list of the actions that you can set is provided in *A-1 Events and Actions* on page A-2.

## **Setting Up Global Events**

To set up a global event, you select the global event and then set the action to execute when the event occurs.

1 Right-click HMI - Global Events in the Multiview Explorer and select *Edit* from the menu. Or, double-click HMI - Global Events.



**2** A tab page to make settings for the global event is displayed in the Edit Pane.

Global Events ×	-
Events	< Select Event to Add > •


**3** Click in the column on the right to select the event to set from the event list.

ilobal Events X		
Events	< Select Event to Add >	
	Condition	
	F1KeyPress	
	F1KeyClick	
	F1KeyRelease	
	F2KeyPress	
	F2KeyClick	
	F2KeyRelease	
	F3KeyPress	
	F3KeyClick	
	F3KeyRelease	
	Interval	
	ProjectInitialization	

A global event is added.

🖩 Global Events 🗙		-
▼ Events	< Select Event to Add >	
▼ [0]	F1KeyPress	Û
AsyncExecution		
Actions	< Select Action to Add >	*

4 In the Actions row below the new global event, click in the right column and select the action to perform for the event from the action list.



**5** When you add global events, they are numbered serially from 0 in the order that you add them.

## **Deleting Global Events**

To delete all of the settings for global events, right-click the Events header at the top and select Reset.

To delete an individual event, click the 💼 Button on the right edge of the event.

#### 4-4-8 Registering Global Subroutines

## **Global Subroutines**


You can register global subroutines, which you can then call from anywhere in the project.

You can register common subroutines that do not rely on page conditions to make subroutines easier to maintain.


## **Registering a New Subroutine Group**

To register global subroutines, you must create one or more subroutine groups. You can use subroutine groups to separate subroutines by purpose.

**1** Right-click **HMI** - **Global Subroutines** in the Multiview Explorer and select **Add** -**Group** from the menu.



SubroutineGroup1 is added under Subroutine Groups.



**2** Double-click the new subroutine group. A tab page for the Code Editor is displayed in the Edit Pane.

Su	broutin	eGroup1 ×	-
			•
	1	'Add global subroutines	
	2		

## Deleting, Copying, and Pasting Subroutine Groups

You can delete, copy, and paste subroutine groups using the same procedures as those that you use for pages.

## 4-4-9 Setting Up Resources

## Resources

Resources are the text strings, movies, still images, and documents that are displayed for objects and alarms on user pages.

You can use **Resources** to manage all of the text strings, images, files, and other resources that you use in a project.

For multi-language projects, you can set resources for each project language.


## **Setting Up Resources**

To set up a resource, select the resource to set up and then make the settings.

**1** Right-click **HMI** - **Resources - Root** in the Multiview Explorer and select *Edit* from the menu. Or, double-click **HMI** - **Resources - Root**.



**2** A tab page to make settings for resources is displayed in the Edit Pane. You can select the resource to set and make the settings.



#### 4-4-10 Setting Up IAG Resources

## IAG Resources


IAG resources are used within IAGs on user pages. When you place an IAG on a page, the resources for the IAG are automatically registered.

The languages that are displayed by the IAG resources are determined by the project languages. The resources that are set in advance for the IAGs are displayed for the IAG resources. If a language that is not included in an IAG is set as a project language, the resources will be blank by default.

#### **Setting Up Resources**

To set up an IAG resource, select the IAG resource to set up and then make the settings.

**1** Right-click the IAG resource to edit under **HMI** - **IAG Resources** in the Multiview Explorer and select *Edit* from the menu. Or, double-click the IAG resource.



**2** A tab page to make settings for IAG resources is displayed in the Edit Pane. The procedures are the same as for other resources, but you can change only the contents of the resources that are in the IAGs.



## 4-4-11 Registering Scaling

## Scaling

Scaling is used to transform displayed numeric values by specifying a multiplier and offset value.

To perform the settings for each object, open the object properties and set the parameters for scaling under **Behavior**.

You can perform the settings for individual variables on the Global Variables Table.

Example: In this example, a multiplier of 100 and an offset of 50 are specified for an integer variable (intSample):

Value of intSample	Calculation formula	Displayed value
0	50+0×100	50
1	50+1×100	150
2	50+2×100	250
100	50+100×100	10050

## **Registering a New Scaling**

You c an register a maximum of 1,000 scaling settings.

**1** Right-click **HMI - Scale Transformations** in the Multiview Explorer, and select *Edit* from the menu. Or, double-click **HMI - Scale Transformations**.

▼ HMI	
📄 🕨 🛅 Pages	
📄 🕨 🬒 User Alarms	
📄 🕨 🔚 Controller Events	
📲 Data Logging	
Data Groups	
🗐, Recipes	
Custom Keypads	
🕨 🕨 🖬 Data	
5 Global Events	
📄 🕨 📕 Global Subroutines	
📄 🕨 💭 Resources	
Imported IAGs	
Scale Transformations	Edit
	Eun

**2** A tab page to perform settings for the scaling is displayed in the Edit Pane.

Con Scale Transformations X				+
Scale Name	Multiplier	Offset	Comment	

#### **3** Right-click in the grid and select *Add* from the menu.

Scale Name	Multiplier	Offset	Comment	
Add				
Cut				
Сору				
Paste				
Delete				

4

Specify the scale name, multiplier, offset, and other items.

Scale Name	Multiplier	Offset	Comment	
мтосм	100	5	Cm conversion	
ramToKG	2	5	Kg conversion	
SpeedAdjust	10	25	Speed offset	

## Deleting, Copying, and Pasting Scalings

To delete all of the settings for scaling, select all the items and then right-click and select **Delete** from the menu.

To delete an individual scaling, click the 💼 button at the bottom left of the setting pane.

## 内

#### **Precautions for Correct Use**

When rounding values to the nearest integer, ".5" is rounded to the nearest even-number integer, as shown in the following examples.

Value before rounding	Value after rounding
1.2	1
1.5	2
1.8	2
2.5	2 (not 3)

# 4-5 Subroutines

## Subroutines

Subroutines are Visual Basic programs that the user can create. You create subroutines under **Subroutines** in the HMI project.



#### **Precautions for Correct Use**

This manual describes only aspects that are different from the specifications standardized by Microsoft Corporation. For any specifications not given in this manual, refer to commercially available reference materials.

## Subroutines

There are global subroutines and page subroutines, as described below.

#### Global Subroutines

Global subroutines are shared by the entire project.

You create global subroutines under **Global Subroutines** in the HMI project. You set CallSubroutine as the action in a global event, object event, or user alarms event to call a global subroutine.

You can also call a global subroutine from a page subroutine or from another global subroutine.

#### Page Subroutines

Page subroutines are specific to one page.

You create page subroutines with the Code Editor for a page in the HMI project.

You can directly create the subroutines to execute in the events for individual objects on pages.

#### 4-5-1 Subroutine Execution

You can execute subroutines in the following ways.

- · Execution from Global Events
- You can execute a global subroutine from a global event.
- Execution from Page and Object Events You can execute a page subroutine or global subroutine from a page or object event.
- Execution from User Alarm Events You can execute a global subroutine from a user alarm event.

## **Execution from Global Events**

The following example shows how to use a global event to execute a global subroutine.

In this example, settings are made to execute the global subroutine when the F1 Key is pressed.

**1** Display the global events and select *F1KeyPress* as the event.

obal Events X		
Evants		
	Condition	
	FLKeyFreis	
	F1KeyClick	
	F1KeyRelease	
	F2KeyPress	
	F2KeyClick	
	F2KeyRelease	
	F3KeyPress	
	F3KeyClick	
	F3KeyRelease	
	Interval	
	Projactinitialization	

2 Select *CallSubroutine* as the action.

Events	< Select Event to A	dd ≫ ·
▼ [0] -	F1KeyPress	0
- AsyncExecution		
Actions	<. Select Action to A	idd >
	BuzzerOff	
	BuzzerOn	1
	BuzzerOneShot	
	CallSubroutine	

**3** For the subroutine name, specify the name of a previously created subroutine in the following format: *Subroutine\_group.Subroutine\_name* 


Events	< Select Event to Add >	
▼_[0] _	F1KeyPress	ō
AsyncExecution		
▼ Actions	<. Select Action to Add >	
▼ [0]	CallSubroutine	õ
SubroutineName	SubroutineGroup@	

## **Execution from Objects**

The following example shows how to use an object event to execute a subroutine.


In this example, settings are made to execute the subroutine when a Button object is pressed.

**1** Select the Button object and display the events and actions.




2 Select *Click* as the event.

Page0 ×		e Ev	Events and Actions 👻	
REREALSA	张斯斯斯加	부 리 팩 Bu	itton0	
			Events	< Select Event to Add > *
				Click
				Press
				Release
The second s				
		H H		
And and a second se				



4 Specify the subroutine to execute in the following format: *Subroutine\_group.Subroutine\_name* 




## **Execution from User Alarms**

The following example shows how to use a user alarm event to execute a subroutine.

In this example, settings are made to execute the subroutine when the user alarm occurs.


**1** Select the user alarm and display the events and actions.




2 Select *Raised* as the event.

C Group0 ×		_			Svents and Actions	* û *
Group Display N					S_mple1	
Name	Alarm ID	Alarm Code	log ression	Priority	Events	< Select Event to Add > *
Samplel	Availante		emplek m	Liber Rould Level 4		Acknowledged
Concession of the local division of the						Cleared
						Raised
4			-			
+ 8.						

**3** Select *CallSubroutine* as the action.





**4** Specify the subroutine to execute in the following format: *Subroutine\_group.Subroutine\_name* 

#### 4-5-2 Precautions on Internal Processing

#### • Handling of Variables

If the value of an external variable is changed in a subroutine, the change is immediately updated at the connected device. Therefore, if you frequently change the value of an external variable inside a subroutine, the performance of that subroutine will be reduced.

#### • Processing during Subroutine Execution

The touch panel and function keys will not respond during execution of a page subroutine. If you execute processing that requires time, the HMI will not perform other operations until the processing is completed. Consider the execution time when you create subroutines. However, processing will continue for background operations, such as communications, and for page refreshing.

#### Simultaneous Execution of Subroutines

It is possible that a subroutine for a global event and a page subroutine will be executed simultaneously. If both subroutines manipulate the same variable, implement exclusive control or other suitable measures.

## **Background Processing of Subroutines for Global Events**

If you select the *AsyncExecution* Check Box, a subroutine process and a drawing update process for that global event are asynchronously executed. Up to five subroutines can be executed simultaneously. If you attempt to execute more than that, the processes enter standby for execution. If the number of subroutines waiting for execution exceeds 100, a warning dialog box appears on the screen.

When you asynchronously execute subroutines, the execution timing is controlled by the OS. Therefore, if you do not synchronize subroutines, you may get unexpected results.

Start actual system application only after sufficiently checking the timing of the execution of the operations of the programs.

## 4-5-3 Code Editor

Subroutines are edited with the Code Editor.

## Starting the Code Editor

#### Global Subroutines

Double-click a previously registered subroutine under **HMI - Global Subroutines** in the Multiview Explorer. Or, right-click the subroutine and select *Edit* from the menu.

### Page Subroutines

Right-click a previously registered page name under *HMI - Pages* in the Multiview Explorer and select *Code Editor* from the menu.

## **Code Editor Features**

The Code Editor provides functions equivalent to those of a standard text editor. It also provides functions that are optimized for Visual Basic, such as keyword highlighting, entry assistance, and collapsing Sub statements.

## 4-5-4 Differences in Language Specifications

Although subroutines are used in Visual Basic, some of the functions are restricted for HMIs. There are also extensions that are provided for use with HMIs. Refer to the *NA-series Subroutine Reference* for details.

# 4-6 Search and Replace

You can search and replace strings in the data of an HMI project. The basic Sysmac Studio operations for searching and replacing generally apply to HMIs. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details.

## **Differences When an HMI Is Selected**

The following differences apply when an HMI is selected.

• You can select only All for the Look at Box.



#### **Precautions for Correct Use**

You can use an action name as a search string, but you cannot replace it with another action name.

Example: You can search for the objects that specify the Login action. However, you cannot replace the Login action settings with the Logout action settings using the replacement function.

# 4-7 Cross References

#### 4-7-1 Cross References

Cross references allow you to confirm in a list format where an element<sup>\*1</sup> that is part of a project is used within the project.

On the list that shows the locations where an element is used, you can access the locations where the element is used.

\*1. You can cross-reference the following elements.

- Variables
- Data types
- Pages
- Resources

The basic operating procedures are the same as for the rest of the Sysmac Studio. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details.

## **Displaying and Manipulating Cross References**

**1** From the main menu, select *View - Cross Reference Tab Page*.

The Cross Reference Tab Page is displayed. You can check a list of the locations where the selected element is used.

# 4-8 Building

#### 4-8-1 Building

The project must be built to convert it into a form that the HMI can execute. During the building process, subroutines and variables are checked.

If there are any errors, the build operation is not performed and  $\bigcirc$  is displayed next to the program or variable where the error occurred in the Multiview Explorer. You can confirm the errors on the Build Tab Page.

#### 4-8-2 Build Operation

Use the main menu to execute the build operation. HMI projects are not built automatically even if no operations are performed for 5 seconds.


## **Executing a Build Operation**

1 Select Build HMI from the Project Menu.


## Aborting a Build Operation

No functions can be executed while building the project is in progress. If necessary, you can abort building to check the project.

1 Select Abort Build from the Project Menu.



**2** The build operation is aborted and a message that says it was aborted is displayed in the Output Tab Page.



# 4-9 Offline Comparison

HMI projects are not included in offline comparisons. Even if you perform an offline comparison for a project that contains an HMI as a device, information on the HMI is not included in the comparison results.

# 5

# Objects

This section describes the objects that are provided as standard features.

5-1	Objects					
	5-1-1	Object List	5-2			
	5-1-2	Object Attributes	5-4			
	5-1-3	Using Objects	5-8			
5-2	Exam	ples of Using Objects 5	-12			
	5-2-1	Displaying a PDF File	-12			
	5-2-2	Displaying a User Alarm 5	-14			
	5-2-3	Displaying a Trend Graph 5	-16			
	5-2-5	Using a Recipe	-21			
	5-2-5	Using a Recipe	-21			
	5-2-6	Setting the Order of Automatic Move of Input Focus 5	-25			
	5-2-7	Displaying Text Strings by Indirect Addressing 5	-27			

# 5-1 Objects

Basic objects are provided in the Sysmac Studio as standard features. You can use these objects to easily create pages.

## 5-1-1 Object List

The following objects are provided.

## **Functional Objects**

A functional object provides some sort of function by itself.

Classification	Object name	Description
Buttons	Button object	Used to execute an action without writing a value to a variable.
	Momentary Button object	Used to change the value of the specified variable to True only while the object is being touched.
	Set Button object	Used to change the value of the specified variable to True when the object is touched.
	Reset Button object	Used to change the value of the specified variable to False when the object is touched.
	Toggle Button object	Used to toggle the value of the specified variable between True and False when the object is touched.
Lamps	Bit Lamp object	Lit while the result of the condition expression is True.
	Data Lamp object	Used to change the color of the lamp according to the value of a condi- tion expression.

Classification	Object name	Description
Standard con-	CheckBox object	Used to change a variable to True or False depending on whether the
trols		check box is selected. Also, the check box can be displayed when the
		value of the specified variable changes.
	Data Display object	Used to display numeric values or text strings.
	Data Edit object	Used to display and enter numeric values or text strings.
	DateTime object	Used to display the value of a variable as a date and time.
	DropDown object	Used to store the value that corresponds to the item selected in a
		drop-down list in a variable. Also, the item that corresponds to the
		specified variable value is displayed.
	Image object	Used to display an image. Refer to A-2 Supported Formats on page
		A-5 for the supported formats.
	Label object	Used to display a fixed text string. Also, if you use DisplayValue for the
		animation property, you can display the value of the variable.
	ListBox object	Used to store the value that corresponds to the item selected in a list in
		a variable. Also, if the value of the specified variable is changed, you
		can move the focus to an item that corresponds to the new value of the
		variable.
	Radio Button object	Used to set the specified variable to the value that was set for the
		selected button. Only one of the specified group of buttons can be
		selected. Also, the option button can be displayed when the value of
		the specified variable changes.
	Slider object	Used to set the specified variable to the value that corresponds to the
		position of the slider. Also, if the value of the specified variable is
		changed, you can move the slider to the position that corresponds to
		the new value.
	Tab Control object	Used to partially change pages within the screen. Several tab pages
		are used to change the displayed contents by changing the tab page.
		You can create a maximum of 64 tab pages for a Tab Control object,
	<b>T</b> ( <b>D</b> ) ( )	and up to 10 Tab Control objects on a screen.
	TextBox object	Used to display a fixed text string. A TextBox object differs from a Label
		object in that the text string in a TextBox object will wrap.
Gauges	Gauge Object	There are several types of gauges provided, such as one with a needle
		that rotates in a circle and one with a needle that moves in a straight
	Dealers line Oreach	line.
HMI controls	Broken-line Graph	Used to display broken-line graphs.
	object Modia Dlavar object	Lload to graate on object that plays video. Defer to A.2 Symperted For
	Media Player object	Used to create an object that plays video. Refer to A-2 Supported For-
	Pooino Viewer object	<i>mats</i> on page A-5 for the supported formats. Used to display the contents of a recipe.
	Recipe Viewer object	
	Trend Graph object	Used to display data from data logging as a graph.
	User Alarms Viewer	Used to display a user alarm.
	object	

## Graphic Objects


A graphic object does not provide any specific function by itself. You must add functions by using events and actions. Many different graphic objects are available. Some typical ones are described in the following table.

Classification	Object name	Description
Shapes	Curve object	Used to draw a curved line. You can double-click the graphic object to
		edit it.
	Ellipse object	Used to draw a circle or ellipse.
	Line object	Used to draw a straight line. You can double-click the graphic object to edit it.
	Polygon object	Used to draw a polygon. You can double-click the graphic object to edit it.
	Polyline object	Used to draw connected straight lines. You can double-click the graphic object to edit it.
	Rectangle object	Used to draw a rectangle.
	Triangle object	Used to draw a triangle. You can double-click the graphic object to edit it.

## 5-1-2 Object Attributes

There are the following three types of attributes for objects.

- Properties
- · Animations
- · Events and actions



## Properties

#### • Properties

Properties are the static attributes of an object.

These include settings for the names and other general properties, colors, positioning, and other display properties, and assigned condition expressions or variables, as described in the following table.

#### Properties

	Properties	Description		
General		You can set the name of the object and check the object type.		
Appearance		You can set the object color, shape, label, etc.		
Beh	avior	You can set condition expressions, variables, and delay times to assign to the object.		
	Expression	You can specify a condition expression that uses variables.		
	Variable	You can specify a variable.		
	IsEnabled, DoubleTouch- Time, OnDelayTime, etc.	You can make settings to enable the object, determine the double-touch interval, set the ON-delay time, etc.		
Layo	out	You can set the position and size of the object.		
Sec	urity	You can set security for the object.		
Poin	ter Marker	You can set the needle marker for a gauge.		
Ran	ges	You can set the range for a gauge.		
Sca	e Bar	You can set the scale bars for a gauge.		
Tick	Label	You can set scale labels for a gauge.		
Tick	Major	You can set the major scale division labels for a gauge.		
Tick	Minor	You can set the minor scale division labels for a gauge.		
Nee	dle	You can set the needle for a gauge.		
Needle Cap		You can set the needle cap for a gauge.		
Data		You can set the display target of a Trend Graph or Broken-line Graph.		
Left Axis		You can set the left axis for a graph.		
Righ	it Axis	You can set the right axis for a graph.		
Time	e Scale	You can set the time axis for a graph.		

#### • Notation for *Expression*

If you specify a BOOL variable, e.g., for a Lamp object, you can specify an expression for the Behavior property.

Examples of the expression notations are given below.

Example 1: Executing a Function when a Boolean Variable (*blnSample* in this Example) Is True blnSample=True

Example 2: Executing a Function when an Integer Variable (*intSample* in this Example) Is Less Than 20

intSample<20

Example 3: Executing a Function when a Boolean Variable (*blnSample* in this Example) Is True and an Integer Variable (*intSample* in this Example) Is Less Than 20.

(blnSample=True) AND (intSample<20)

Example 4: Setting a Value by Adding 100 to an Integer Variable (*intSample* in this Example) intSample+100

#### Notation for CustomDisplayFormat

If you set *DisplayFormat* to *Custom* for a Data Display object, you must set the custom display format (*CustomDisplayFormat*). The basic format is 0:\*\*\*\*\*, where \*\*\*\*\* is replaced with the result of *Expression*.

This format follows the specifications of custom numeric format strings in Visual Basic. For details, refer to the Microsoft website or to commercially available reference materials.

Example 1: Display When Result of Expression is 1.234 and {0:00.0000} Is Specified 01.2340

Example 2: Display When Result of Expression is 1.234 and {0:##.####} Is Specified 1.234

Example 3: Display When Result of Expression is 1.234 and X={0:##.####} Is Specified X=1.234

## Animations

#### Animations

You can use animations to change the status of the object according to *Expression* (condition expression).

As described below, you can specify the status when the condition expression is met, such as flashing, enabling/disabling operation, size/coordinate changes, and displaying/hiding the object.

Animation name	Description
Blink	When the condition expression is met, the object flashes in the specified color.
ColorChange(Analog)	Changes the color of the object according to a value.
ColorChange(Boolean)	Changes the color of the object according to True/False status.
DisplayValue	Displays a value based on a condition expression.
Enable	Enables operating the object when the condition expression is met.
Move	Changes the coordinates of the object according to specified condition expres-
	sions.
PercentageFill	Fills a graphic figure based on a condition expression and a percentage
	between the upper and lower limits.
ResizeHeight	Changes the height of the object according to a specified condition expression.
ResizeWidth	Changes the width of the object according to a specified condition expression.
Rotate	Rotates a graphic object based on a condition expression.
Visibility	Displays the object when a condition expression is met.

Animation List

## **Events and Actions**

#### • Events and Actions

You can make settings for object events and corresponding actions.

You can specify events and the actions to perform when the events occur.


You can specify the required conditions and operations, such as executing a specified subroutine when a function key is touched.

The events and actions are listed in A-1 Events and Actions on page A-2.

## 5-1-3 Using Objects

The objects are provided in the Toolbox on the right side of the window.

You can create them on pages and set the properties and animations and also the events and actions.



## **Creating Objects**

- Image: New Project: Herd Node, 0- Systematisation

   Image: New Project: New Project: New Project: Node, 0- Systematisation

   Image: New Project: New Project: New Project: Node, 0- Systematication
- **1** Drag the objects from the Toolbox and drop them on the page.

#### **Setting Properties**



Double-click the object.

#### Additional Information

You can also use the following methods to display the properties.

- Select *Properties* from the View Menu.
- Right-click the object and select *Properties* from menu.

#### **2** The properties are the static attributes of the objects.



5


Make the following settings as required.

#### Setting Animations

**1** Select *Animations* from the View Menu.

S New Proje	ect - HMI_NAS_0 - Sysmac Studio		
File - Edit	View Insert Project HMI Simulat	ion Tools Help	
in the second second	Multiview Explorer	Alt+1	
	Toolbox	Alt+2	
MUIOVIEW P	Output Tab Page	Alt+3	
	Watch Tab Page	Alt+4	
HL LNA5	Build Tab Page	Alt+6	
► Configu	Search and Replace Results Tab Page	Alt+7	
▼ HMI	Page Explorer	Ctrl+Shift+1	
	Code Explorer	Ctrl+Shift+2	
	Properties	Ctrl+Shift+3	
	Animations	Ctrl+Shift+4	
	Events and Actions	Ctrl+Shift+5	
	Smart Project Search	Ctrl+Shift+F	
0 H	Recently Closed Windows	Ctrl+Shift+H	
<b>B L</b> (	Clear Recently Closed Windows History	·	
	Zoom	•	
	Reset Window Layout		

**2** You can set the animations of the objects in the Animations Window.




#### Setting Events and Actions

#### **1** Select *Events and Actions* from the View Menu.

📓 New Proje	ct - HMI_NA5_0 - Sysmac Studio	
File Edit	View Insert Project HMI Simulat	ian Tools Help
	Multiview Explorer	Alt+1
	Toolbox	Alt+2
Multiview P	Output Tab Page	Alt+3
	Watch Tab Page	Alt+4
HIMI_NA5	Guild Tab Page	Alt+6
► Configu	Search and Replace Results Tab Page	Alt+7
▼ HM!	Page Explorer	Ctri+Shift+1
	Code Explorer	Ctrl+Shift+2
	Properties	Ctrl+Shift+3
1.1	Animations	Cta1+Shift+#
	Events and Actions	Ctri+Shift+5
	Smart Project Search	Ctd+Shift+F
	Recently Closed Windows	Ctrl+Shift+H
	Clear Recently Closed Windows History	1
	Zoom	•
	Reset Window Layout	

#### **2** You can set the actions for events in the Events and Actions Window.



## 5-2 Examples of Using Objects

This section provides examples of using objects.

#### 5-2-1 Displaying a PDF File

1

The following example shows how to display a PDF file full screen when a button is touched.

Place a button of	on the page.	
📕 New Project - HM0,N45,0 - Sysn	ac Studie	= 3
File Edit View Index Project	. Hinii Shmulation Taoli: Hulp	
米面回日やけ		
Multiview Explorer 🔹 🗰	Poget X	:0 00+
1 . TT . TT	23 田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田	
<ul> <li>Configurations and Setup</li> </ul>	the second	Searce Cont
V In Pages		in and
i⊷ +t) User Alaram Ng Cata Logging		Momentary Butto
E Nocipes		Set Button
ir ∰ Data ♦ Giolad Guesta		Toogle Button
<ul> <li># Eloted Substatives</li> <li></li></ul>		Lamps
L @ MG Resources		Shapes
		<ul> <li>Standard Controls</li> </ul>
		Gauges
		<ul> <li>HMLGastrols</li> </ul>
	Calput - 7 X	<ul> <li>Custom</li> <li>Armos-</li> </ul>
		<ul> <li>Blowers.</li> </ul>
		Conveyors
		Button
		Button A llutton object.
🖬 Filter 😽	Couput 🔨 Suite д Watch Project	

2 Select *Events and Actions* from the View Menu.

File Ed	jit 🛛 View	Insert	Project	HMI	Simulati	an	Tools	Не
	Muit	iview Expi	lorer			Alt-	+1	
L <u>^</u> -	Tool	бох				Alt-	+2	
Multiviev	v 🖪 Outp	ut Tab Pa	ge			Alt-	+3	
		h Tab Pag	9e			Alt-	+4	
HMILN	A5. Guik	l Tab Page	2			Alt-	+6	
► Conf	igi Sear	ch and Re	epłace Re	sults Ta	ab Page	Alt-	+7	
▼ HM!	Fage	Explorer				Ctri	+Shift+	- 1
- C.	🔟 Code	Code Explorer				Ctd+Shift+2		
	Prop	erties				Ctrl	+Shift+	- 3
		Animations			Ctal+Shift+#			
	_	its and Ac	tions			Ctri	+Shift+	-5
	► Sma	rt Project	Search			Ctrl	+Shift+	F
	<ul> <li>Rece</li> </ul>	ntly Clase	ed Windo	WS		Ctrl	+Shift+	н
	Clea	r Recently	Closed \	Vindov	/s History			
	Zoor	n						Þ
	Rese	t Window	Lavout					





4

Select ShowDocument (FullScreen) from Actions.




5 Set DocumentFileName to the name of the file to display.

Eve	nts and Actions	<b>↓</b> 4	×
But	ton0		
V	Events	< Select Event to Add >	•
	▼ [0]	Click	Û
	▼ Actions	< Select Action to Add >	*
	▼ [0]	ShowDocument	Û
	DocumentFilename	sample.pdf 🔹	
-	e		

Transfer the project to the HMI and confirm the operation.

The PDF file should be displayed when the button is touched.



#### 5-2-2 Displaying a User Alarm


The following example shows how to register a user alarm and display a message when the user alarm occurs.

This example creates a user alarm that displays the message *Alarm1* in a confirmation dialog box when the *blnAlarm1* variable changes to True.

**1** Double-click **Group0** under **HMI** – **User Alarms** in the Multiview Explorer.



**2** Right-click in the user alarm table for the new group and select **Add** from the menu.



**3** A row is added. Make the following settings in the new row. Use the default values for settings that are not specified.


Name: UserAlarm1

Expression: blnAlarm1=True

Message: Alarm1

Popup: Selected

Acknowledge: Selected



#### Additional Information

If you set a page name for the Page parameter, the screen is switched to the specified page when an alarm occurs. Select an alarm displayed on the User Alarms Viewer, and execute the ShowAlarmPage action/function. The screen is changed to the specified page.

4 Double-click **HMI - Pages - Page0** in the Multiview Explorer. Drag a User Alarms Viewer object from **HMI Controls** in the Toolbox to the page.



Transfer the project to the HMI and confirm the operation.

When the *blnAlarm1* variable changes to True, the contents that was set for the User Alarms Viewer object are displayed in a confirmation dialog box.

Den ant Tera SIG-CDA LEOPOL Proc. Komit	- Prov Boop	
-		
	Ren Cale Perez Marit Augusta Age	
	Comment /s (1255474) Or (1556734	

5

#### 5-2-3 Displaying a Trend Graph

The following example shows how to register a data set for data logging and display a trend graph that accesses it.

This example records log data continuously every 5 seconds and saves it in a separate file for each 24-hour period.

**1** Register an integer variable called *intDatalog1* in the global variable table.

2 Right-click HMI - Data Logging in the Multiview Explorer and select Add - Data Set from the menu.


▼ HMI		
▼ 🖮 Pages ∟ 🛲 Page0 ▶ 🚸 User Alarms		
Data Logging	Add 🕨	Data Set
Data 4 Global Events	Paske	

**3** Double-click the new data set.

Michen Project - HM1_NA5_0 - Sysme		1¢
	1 HAGI Simulation Iaals Helo	
K # @ @ 5 C #		
Multiview Explorer 🗸 0	Peasen x	
Configurations and Setup  Configurations and Setup  Configurations and Setup  Configurations  Configurations	Storinge Type Target Denice Target Rolain Update Type Update Type Update Type Update Rolain Data Loop "grucop Fires Update Rolain Data Loop "grucop Fires Update Rolain Data Loop "grucop Fires Data Manual Manual Control of the period After specific member of loop Number of loop Number of loop	
<ul> <li>▶ 67 Data</li> <li>▶ 4 Global Evenes</li> <li>▶ 6 Global Evenes</li> <li>↑ 7 Recentors</li> <li>↑ 6 Glob Subcontrem</li> </ul>	Variable Dara Type Commont	



Right-click in the new data set grid and select *Add* from the menu.



**5** A row is added. Set *intDatalog1* in the *Variable* column of the new row. Use the default values for other settings.

Storage Type	ex.		Start New Database File
Target Device	SD Memory Card		After specific time period
Target Folder	\Data Logging\Log F es		7
Update Type	Regular Interval		After specific number of logs
Update Rate	5 Secondu		Number of logs 1000
Automatically Si	art on HMI Device		
	Variable	Data Type	Comment

**6** Double-click **Page0** under **HMI - Pages** in the Multiview Explorer. Drag a Trend Graph object from **HMI Controls** in the Toolbox to the page.

Nutriew Explore     Image: A second sec	New Project - HMJ,NA5,0 - šýsmac Studio		
Multinew Explores Page 2 X	File Solis Miew Insens Project Hinis Shitulation Topols Hulp		
<ul> <li>Scringurstons and Selop</li> <li>Scringurstons and Selop</li> <li>- ллс</li> </ul>			1.4
• With Rapes	Carfiguration: and Setup  Cardina  Car	<ul> <li>The of dial and a second second</li></ul>	Vigore -

**7** Set the name of the data set that you created as the data set in the properties.

7	Data			
	DataSet	DataSet0		
	AnalogTraces	0	+	
	DigitalTraces	0	+	

**8** Click the for *Analog Traces* and set the variable to display on the graph. Set *intDatalog1* as the variable.

V	Data	1		
	Data	Set	DataSet0	
V	AnalogTraces		1	+
	<b>V</b> [0	)]	analogTrace0 :	Û
		Name	analogTrace0	
		Variable	intDatalog	
		ScaleAss	Left Scale	•
		Color	DarkOrchie	٠
		MarkerT	None	•
	Digi	talTraces	0	+

Insert an SD Memory Card into the HMI, transfer the project to the HMI, and confirm the operation.



Every 5 seconds, the value of *intDatalog1* should be sampled and displayed on the graph.

#### 5-2-4 Displaying a Broken-line Graph

The following example shows how to use a broken-line graph.

- **1** Register an integer array variable called *intData(10)* in the global variable table.
- 2 Right-click HMI Data Groups in the Multiview Explorer and select Add Data Groups from the menu.



#### **3** Double-click the new data group.

New Project - HMI_NAS_0 - Sysm	mac Studio		
File Edit View Insert Project	t HMI Simulation Tools Help		
	「「「「」」を見る。	ia ia 🖀 🐠 🗛 💌 🖾 🖉	
Multiview Explorer 🚽 🗸 🗸	🚰 DetaGroup0 🗙		
HML NAS_0  Configurations and Setup HMI HMI Pages	Data Series	Τγρε   Οστα Τγρε	Comment
<ul> <li>Image: state of the state of th</li></ul>	+		
■ Data Logging         ■ Data Groups         ■ Logics         ■ Recipes         ■ Custom Keypads         ● Ø Data         夕 Global Events         ● Global Subroutines         ● Ø Resources         ■ Imported IAGs         ■ Scale Transformations	Vəriable	рата Түре	Comment

Register a data series in the new DataGroup0. Right-click in the grid and select *Add* form the menu.

4

DataGroup0 ×		B-1- T	t	
Data Series	Type	Data Type	Comment	
bbA				
Cut				
Сору				
<ul> <li>Paste</li> </ul>				
Delote Variable		Data Type	Comment	- T
Valitute		Long type	Continuent	

5


A row is added. Perform the following settings in the new row. Use the default values for all other settings.


U DataGroup X				-
Data Series	Түре	Data Type	Comment	
TestDataSeries1	Алтау	Integer		
ф.				1

**6** Set an array variable called *intData* in the added data series. Use the default values for all other settings.

E DataGroup X							
Data 9	ieries	Түре		Data Type		Comment	
TestDataSeries1		Алау	Integer				
<b>F</b>							
	Variable			Data Type		Comment	
IntOata			Integer(10	)			Constant of
Target Dimension	0 ^						
Target Index	:						
Target Member							
Targeted Oata	IntData(*)						

7 Go back to the Page Edit Pane. Double-click Page0 under **HMI - Pages** in the Multiview Explorer. Drag a Broken-line Graph object to the page from **HMI Controls** in the Toolbox.





T	Data	
	DataGroup	DataGroup0
	Offset	0
	Traces	0 +

9

Click the 🛞 for *Traces* and set the variable to display on the graph. Set *TestDataSeries1* in DataSeries.

T	Data	a	
	Dat	aGroup	DataGroup0
	Offs	et	0
T	Trac	es	1 +
	<b>▼</b> [0]		trace0 : TestDalase 🗖
	Name		trace0
		DataSeries	TestDataSeries1
		ScaleAssociatio	Left Scale 🔹 👻
		Color	Red 🔹
		MarkerType	None -

Transfer the project to the HMI, and confirm the operation.

The value of each element of *intData(10)* should be displayed on the broken-line graph.



#### 5-2-5 Using a Recipe

The following example shows how to use a recipe.

- **1** Register integer variables called *intRecipe1* and *intRecipe2* in the global variable table.
- 2 Right-click HMI Recipes in the Multiview Explorer and select Add Recipe Template from the menu.

▼ HMI		
▼ 🛅 Pages ∟ 🖽 Page0		
► 🗤 User Alarms		
🕨 🎥 Data Logging		
🔳 🧾 Recipes		Derin Trendet
🕨 🖾 Data	Add 1	Recipe Template
🗆 🐓 Global Events	Øaste	
Global Subroutines	1 442 44	

#### **3** Double-click the new recipe template.

Bie Eais View Insen Zeigert HAG Simulation Janis Heis	
火車員会 ちぐる 下共改善人 各物物画 ゆたし	R DAR AROPHEM
Multiview Explorer v. 9 RecipeD ×	-
Configurations and Setup  HAT  HAT  HAT  HAT  HAT  HAT  HAT  HA	Default Value   Man Value   Man Value   Default value   Value   Edit


4

Register ingredients in the recipe template for the new recipe, Recipe0. Right-click in the grid and select *Add* from the menu.

5	how Recipes
A	Add
	Delete
	Vove Up Vove Down
	Cut
	Paste

#### Additional Information

A recipe template is a defined data structure for a recipe.



**8** A row is added. Make the following settings in the new row. Use the default values for other settings.

Recipe Name: RecipeSample1 Recipe1: 30 Recipe2: 40

Recipe Name: RecipeSample2

Recipe1: 50

Recipe2: 60

Recipe0 ×			
Recipe Name	Recipe1	Recipe2	
RecipeSample1	30	40	
	50	60	
Recipesampiez	JU	oU.	

**9** Create a button to transfer the recipe.

Right-click HMI - Pages- Page0 in the Multiview Explorer and select View Code from the menu.



**10** Create the following subroutine.

Tiget vb 🗶	
9	T
1 Code behind Page - Add local subroutines for the page.	
2 GSub WriteSubroutine	
3 WriteRecipeToController("Recipe0","RecipeSample1")	- 10
4 End Sub	
5	

5

11 Double-click HMI - Pages - Page0 in the Multiview Explorer. Drag a Recipe Viewer object from HMI Controls in the Toolbox to the page.

📕 New Project - HM0,N45,0 - Sysma	ic Studie	- 18 <b>- 2</b>
File Edit View Incent Project		
X 10 10 10 10 10 1		
Multiview Explorer 🔹 🕸	Paget M	
	· · · · · · · · · · · · · · · · · · ·	
<ul> <li>Configurations and Setup</li> <li>HMC</li> </ul>		
The Pages		
H- ++) User Aleren III, Cata Logging		-
v ∰ Neckpes 11 Nackpat		tandard Controls
Brance     A Global Secures		IMI Controls
Otobal Subroution     P Resources		Record Views
Q NG Records		Teanel Graph
		Usar Alarna Yasaar
		lustom
		hrisws.
		ionveyors
		lags-
		e <b>Viene</b> Ipe vienes elejac
1 Filter	Culput 🔨 Burle 🙀 Waser (Project)	

**12** Then drag a Button object from **Buttons** in the Toolbox to the page and set the following event and action.

Events and Actions			<b>→</b> ‡	×	
But	ton0				
▼ Events			< Select Event to Add >	*	
	▼ [0]		Click		
	Actions		< Select Action to Add >	٠	
▼ [0]		)]	CallSubroutine	Û	
		SubroutineName	WriteSubroutine		

Transfer the project to the HMI and confirm the operation.


When the button is touched, the values that are set for the specified recipe should be written to the connected device.

Recipe Template	Ingredient	Valu	button
Recipe0	Retipe1 Retipe2	30 40	Curron
Recipe0			
Recipelnstance0			
RecipeInstance1	<	2	

#### 5-2-6 Setting the Order of Automatic Move of Input Focus

The following example shows how to consecutively enter numeric values in the multiple data input objects placed on a page.


- **1** Register an integer variable called *intData1* in the global variable table.
- **2** Place a data input object on the page.



**3** Set *intData1* in **Variable** of the properties for the data input object.

▼ Behavior			
	IsEnabled		
	DataType	Numeric -	
	Variable	intData1	


**4** Place the multiple data input objects on the page by copying and pasting one.




**5** Click the **Data Input Order Setting** Button on the Toolbar to switch to the mode for setting data input order.



**6** Click the data input objects in the order in which to move the input focus.



**7** When you complete the settings, the following dialog box appears.



8 Select the *AutoNavigateKeypads* Check Box under **Behavior** in the properties of the page.

V	Behavior			
	РадеТуре	Main 🔻		
	BackgroundPage			
	AutoNavigateKeypads			

Transfer the project to the HMI, and confirm the operation.

When you press a data input object, a keypad is displayed. After you complete an input, the input focus is automatically moved from one data input object to the next.

#### 5-2-7 Displaying Text Strings by Indirect Addressing

You can dynamically change text strings that are displayed on label objects or text box objects. The following example shows how to switch a text string displayed on an object by using a value specified in a variable.

- **1** Register an integer variable called *intData1* in the global variable table.
- **2** Register a new resource group in a Resources table.



**3** Open the added Resources table, and register a text string to display on an object.

to, Group0 🗙					7
L SHL	General Strings				
	<b>.</b>	Nøme	Resource ID	English (United States)	
491	String0 String1		Group0_String0 Group0_String1	ABC	
4	Joingi		oroupo_pumit	-	
121					
		-			
	10 10 10	P.Ma			

v Project - HMI_NA5_0 - Sysmac Studio	
Edit <u>View</u> Insert <u>Project</u> <u>HM</u> I <u>Simulation</u> <u>Tools</u> <u>H</u> elp	the second s
● ● ● ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○	
iew Explorer 🗸 🕴 🦉 Pagel/ 🗙	Too box
14450 V TO 8 8 8 4 4 4 5 5 5 5 5 5 5 5	4 W + J 2 # B B
infigurations and Secure	< Search >
	Data Edit
Rages	Date Time
Len Page0	Породочи
Controller Events	Image
Ba Data Logging	C has
▶ Ba Data Groups @ Recipes	E ListBox
🕞 Custom Keypads	C B Radio Button
▶ ∰ Data ∳ Gkobal Events	→ Sider
→ Global Subroutines	TabControl
Resources	TestBox
L 💭 Roat L 💭 Group0	► Gaugas
🗊 Imported IAGs	Hind Controls
Cale Transformations	Custom
	Searchart Searchart
ممتحل بلد فستشار تحديداني .	
BURG-	Conveyors
	► Flaga
I I Description I Program I	Location I Figure Motors
	► Happens
	Motors
	Pipes
and the second sec	> Pomos

5 Open the properties of the Label object, and set Link Type to Dynamic under Appearance -Text (Default) - Resource.

V	Appearance		
v	Text (Default)	####	
	Resource Link Type	Dynamic 🔹	
	Expression		

#### 6 Set "Group0\_String" & intData1 in Expression.

7

On the page, create the data input object that inputs values to intData1. Transfer the project to the HMI and confirm the operation. When the value in intData1 is 0, the Label object displays "ABC".

When the intData1 value is changed to 1, the object displays "XYZ".

#### **Additional Information**

In Expression, set the text string that is displayed for the Resource ID on the Resources table.

## 

## **Connecting to the HMI**

This section describes how to go online with an HMI.

6-1	Introd	uction	6-2
6-2	Going Online with an HMI		
	6-2-1	Methods for Going Online with an HMI	6-3
	6-2-2	Setting the Connection Method	6-4
	6-2-3	Online Connection	6-5
	6-2-4	Going Online after Checking the Connection Method	6-6
	6-2-5	Going Offline	6-6
	6-2-6	Confirming Serial IDs	6-7

### 6-1 Introduction

#### Connecting to the HMI

You must go online with the HMI or connect to the Simulator to communicate with it from the Sysmac Studio.

The Sysmac Studio supports the following online connections for different applications.

Online connection	Connection made to	Application
Online connection	The actual HMI	To perform debugging, startup, or normal maintenance, the same project as in the actual HMI is opened on the Sysmac Studio and then an online connection is made. An online con- nection is made based on the Communications Setup in the project.
Simulator connection	HMI Simulator	The Simulator is used to debug the program offline. The Com- munications Setup in the project is not used.



#### Additional Information

Refer to 7-1-4 Offline Debugging with Only the HMI Simulator on page 7-6 for information on connecting to the Simulator and debugging operations.

## 6-2 Going Online with an HMI

You can simultaneously go online with more than one HMI in a project from the Sysmac Studio. The operations that are described in this section apply to the currently selected HMI. If there is more than one HMI registered in the project, confirm the HMI to operate before connecting to it.

#### **Precautions for Correct Use**

Do not reconnect the USB cable for at least 10 seconds after you disconnect it. After you connect the USB cable, do not disconnect it until Windows detects the connection.

It may become impossible for Windows to detect when the cable is connected or disconnected, which would effectively disable the USB port. If that occurs, restart the computer. Otherwise, you will not be able to use the USB device until Windows recovers from the suspended status.

#### 6-2-1 Methods for Going Online with an HMI

To go online with an HMI, there are three connection methods that can be used. These are described in the following table.

Connection method	Connection diagram	Description
Direct connection via USB	4	The USB port on the computer is connected directly to the USB slave port on the HMI.
		This is the default connection con- figuration.
Direct connection via Ethernet		The Ethernet port on the computer is connected directly to Ethernet port 2 on the HMI.
Ethernet connection via hub		The Ethernet port on the computer is connected through the Ethernet network to an Ethernet port on the HMI.

#### 6-2-2 Setting the Connection Method

You must set the connection method, IP address to connect to, and other parameters for communications between the computer and HMI.

**1** Select **Communications Setup** from the HMI Menu.

The Communications Setup Dialog Box is displayed.



**2** Select the connection method for the connection configuration in the *Connection Type* Field.

For an Ethernet connection via a hub, enter the IP address of the HMI to which you need to connect in the Remote IP Address Area. Select any required options and enter the communications time-out time if required.

Note Refer to *Communications Setup Dialog Box Settings* on page 6-5 on the next page for information on the settings.

Di Communications besta			
Chenadere Type - Bidez, andhelle in canner, soft hier deales for an eany tane pre-soften: Evel convertient re-Vill Evel convertient re-Vill Evel convertient re-Andre Evel convertient re-Andre			
l Trans I rated			
New Y BRARKS			
Optime © contract to the young which, Comparison to the stat.			
Leastly, the mispanies these art parties for communicating with the animal	moel		

**3** c

Click the **OK** Button.

This concludes the settings.

ltem	Description			
Connection Type	Select the connection port to use to go online.			
	The selected method is nor	The selected method is normally used to go online.		
Remote IP Address		If you specify an Ethernet hub connection, set the IP address of the HMI that you will connect to. Also, you can click a test button to perform a communications test.		
Test USB Connec- tions	Click the test button to perform a USB communications test.			
Options	Confirm serial ID when going online.       If you select this option, the names and serial IDs compared between the project and the HMI when go online to make sure that a connection is made intended HMI.			
Communications	You can set the response monitoring time for communications with the HMI.			
time-out An error is displayed if a response is not received before this t		sponse is not received before this time expires.		
	*1. The time can be set to between 1 and 3,600 s.			

#### • Communications Setup Dialog Box Settings

#### 6-2-3 Online Connection

Use the following procedure to place the Sysmac Studio online with the HMI.

**1** Select **Online** from the HMI Menu. Or, click the **Go Online** Button (M) in the Toolbar.

The following message is displayed the first time you go online. After you write the project name, this message is not displayed.

The HMI device has no name.	
Do you want to write the project name[HMI_NA5_0] to the HMI device name? (Y)	N)
<u>Y</u> es <u>N</u> o	

#### Additional Information

The same message will be displayed the next time you connect if the HMI device name that is set in the project is different from the HMI device name that is set in the HMI.

#### **2** Click the **Yes** Button.

The Sysmac Studio goes online and the color of the bar under the Toolbar changes to yellow.

New Project + HMI_NA5_0 + Sys	imac Studio	2							
Elle Edit Views Insert Broys	ह्य मल्ज	gioulatio	n <u>Toble</u>	Beir	_				
3999708	1 12	17. <del>0</del>	<b>4 4</b>	A U			AA		H
Multiview Explorer   Corrigo: site us and Site op  Hut  Hut  Hut  Galaxies  Galaxies			1 1					VE3 V Buttons	dany Kalkan walion mu Butlon
E filter (?)	Output 	e 🔨 Build					~ 1 ×	Control Status	• 0 ⊘ ★ Nitest (USB)

#### 6-2-4 Going Online after Checking the Connection Method

Use the following procedure to go online if you selected the option to select the connection method whenever you connect the computer with the HMI in the Communications Setup Dialog Box.

Select *Online* from the HMI Menu. Or, click the **Go Online** Button (
 ) in the Toolbar.

 The Communications Setup Dialog Box is displayed.

S Communication Settings	
Connection Type	
<ul> <li>Direct connection via USB</li> <li>Direct connection via Ethernet</li> </ul>	÷ 📻
Ethernet connection via a hub	
192.168.250,1	
OK	

The IP address that is set in the Communications Setup Dialog Box is displayed below the *Ethernet connection via a hub* Option.

2 Select the connection method and then click the **OK** Button. The Sysmac Studio goes online.


#### 6-2-5 Going Offline

Use the following procedure to go offline.

Select *Offline* from the HMI Menu. Or, click the **Go Offline** Button (**M**) in the Toolbar. The Sysmac Studio goes offline.

#### 6-2-6 Confirming Serial IDs

The serial ID is verified when going online if the option to do so was selected in the Communications Setup Dialog Box. If the serial ID of the project on the Sysmac Studio is different from that of the HMI, the following confirmation dialog box is displayed when you attempt to go online.



#### 1 Click the **Yes** Button.

The serial ID of the project on the Sysmac Studio is rewritten to the same value as that of the HMI.



#### Precautions for Correct Use

- If a USB connection is used, an Ethernet IP address of 192.168.255.xxx is used internally.
   When using a USB connection, do not use an IP address of 192.168.255.xxx for the Ethernet interface card in the computer.
- Socket ports 9600 and 2224 are used for Ethernet UDP/IP communications. When using Ethernet UDP/IP communications, do not use these ports for any other application.
- When using a direct Ethernet connection and there is more than one Ethernet interface card mounted in the computer, you must select the Ethernet interface card to use. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for specific selection procedures.

# 

## Debugging

This section describes offline debugging using the HMI Simulator.

7-1	HMI De	bugging Functions
	7-1-1	Watch Tab Page
	7-1-2	Breakpoints
	7-1-3	Step Execution
	7-1-4	Offline Debugging with Only the HMI Simulator
	7-1-5	Offline Debugging with the Controller Simulator

## 7-1 HMI Debugging Functions

The operations you can use for debugging on the Sysmac Studio are listed below. The HMI Simulator is used for offline debugging. You can use the HMI Simulator by itself, or you can connect it to the Controller Simulator to debug the entire system.



Although the Simulator simulates the operation of the HMI, there are differences from the HMI in operation and timing. After you debug operation with the Simulator, always check operation on the actual Controller and HMI before you use them in the actual system. Accidents may occur if the controlled system performs unexpected operation. Refer to *A-3 Differences between the Physical HMI and Simulator* on page A-7 for details on differences in operation.



Although offline debugging simulates the integrated operation of the HMI and Controller, there are differences in operation and timing in comparison with combining the actual HMI and Controller. After you debug operation with the simulation, always check operation on the actual Controller and HMI before you use them in the actual system. Accidents may occur if the controlled system performs unexpected operation. Refer to *A-3 Differences between the Physical HMI and Simulator* on page A-7 for details on differences in operation.



The following three functions are provided for debugging during HMI simulations. These functions are the same regardless of whether they are used in offline debugging.

- Watch Tab Page
- Breakpoints
- · Step execution

#### 7-1-1 Watch Tab Page

The basic Sysmac Studio operations of the Watch Tab Page apply to HMIs.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details.

However, the following differences exist for HMI projects.

• You can monitor the following variables on the Watch (Project) Tab Page.

Standard projects:Only global variables can be registered. You can continuously monitor any of<br/>the global variables. Register the variable names as they are.IAG projects:You cannot monitor variables in the IAG project.

 The Watch Tab Page functions only for the Simulator. Even if you are online with the physical HMI, you cannot monitor the variables in the physical HMI.

#### 7-1-2 Breakpoints

You can set breakpoints in the source code of a subroutine. You can use breakpoints to pause the execution of a subroutine at any desired point.

#### **Setting and Clearing Breakpoints**


#### Setting Breakpoints

You can set breakpoints to pause execution of a simulation, e.g., to see the status after a subroutine is executed.

#### Procedure

To set a breakpoint, move the cursor to the line in the subroutine where you want to set the breakpoint and select **Set/Clear Breakpoint** from the Simulation Menu.

If you repeat this operation, the breakpoint will be cleared.



#### **Clearing All Breakpoints**

You can clear all of the breakpoints at the same time.

Select Clear All Breakpoints from the Simulation Menu to clear all of the breakpoints.

- Edit View Insert - Project HMI	Simulation Tools Help		
	Start NA Simulation Stop NA Simulation	F5 Shift+F5	£, ℝ Ξ € € ▲
age0.vb ×	Step Execution	-F10	
WriteSubroutine	Step In	F11	
1 Code behind Page - Add	Step Out	Shift+F11	
2 BSub WriteSubroutine	Continue	F6	
S WriteRecipeToControl     4 End Sub	Set/Clear Breakpoint	£9	
4 [200 500	Clear All Sreakpoints	Ctrl+Sbift+39	
	Run with Controller Simul	itor	

#### 7-1-3 Step Execution

You can use step execution when subroutine execution is paused at a breakpoint to trace operation one line of the source code at a time.

#### **Step Execution**

You can use step execution to execute the source code of a subroutine one line at a time.

If you select **Step In** and other commands from the Simulation Menu while paused at a breakpoint during a simulation, you can control execution one line or one function at a time.

#### **Step Execution**

The Step Execution command executes one function at a time.

Select *Step Execution* from the Simulation Menu when subroutine execution is paused during step-in execution.

- Edit View Insert - Project HMI	Simulation Tools Help		
	Start NA Simulation Stop NA Simulation	F5 Shift+F5	5. R I & & A
Pageûwb X	Step Execution	F10	-
WriteSubroutine 1 Code behind Page - Add 2 BSub WriteSubroutine	Step In Step Out Continue	F11 Shift+F11 F6	
<ul> <li>WriteRecipeToControll</li> <li>End Sub</li> </ul>	Set/Clear Breakpoint Clear All Breakpoints	ያዓ Ctrl+Shiੈ#+የ9	
	Run with Controller Simula	itor	

#### **Step-in Execution**

Step-in execution performs step execution for the source code of a subroutine.

When you execute a program through the Simulator, select *Simulation - Step In* when the subroutine is stopped at a breakpoint, paused, or stopped during step execution.

– Edit View Insert – Project HMI	Simulation Tools Help		
	Stad NA Simulation Stop NA Simulation	F5 Shift+F5	54 K <sup>1</sup> □ € € <sup>1</sup> ▲ ▲ 0
Page0.vb X	Step Skecution	F10	-
WriteSubroutine	Step In	F11	1
1 Code behind Page - Add 2 BSub WriteSubroutine	Step Out Continue	Shift+F11 F6	
S     S     S	Set/Clear Breakpoint Clear All Breakpoints	₽9 Ctrl+Shi#+₽9	
	Run with Controller Sintula	tor	

#### **Step-out Execution**

Use the Step Out command to exit a subroutine during step-in execution.

Select Step Out from the Simulation Menu during step-in execution.

– Edit View Insert – Project HMI	Simulation Tools Help		
	Start NA Simulation Stop NA Simulation	F5 Shift+F5	54 R I & &
Pageturb X	Step Execution	F10	
WifteSubroutine	Step In	511	
1 Code behind Page - Add	Step Out	Shift+F11	
2 🗄 Sub WriteSubroutine 💼	Continue	F6	1
<ul> <li>WriteRecipeToControll</li> <li>4 End Sub</li> </ul>	Set/Clear Breakpoint	<u>89</u>	
4 [End 500	Clear All Breakpoints	Ctrl+Shift+F9	
	Run with Controller-Simul	stor	

#### Continue

The Continue command executes the subroutine to the next breakpoint.

Select *Continue* from the Simulation Menu when subroutine execution is paused during step-in execution.

	Start NA Simulation Stop NA Simulation	F5 Shift+F5	5. R	
Pageûve X WriteSubroutine 1 Code behind Page - Add	Step Execution Step In Step Out	F10 F11 Shift+F11		1
2 BSub WriteSubroutine 3 WriteRecipeToControll 4 End Sub	Continue Set/Clear Breakpoint	96 F9		
4 [End Sdb 5	Clear All Breakpoints Run with Controller Simula	Ctrl+Shi#+P9		

7

#### 7-1-4 Offline Debugging with Only the HMI Simulator

Before you check the entire system, you can perform debugging with the HMI Simulator alone.

When you create a project and want to debug it, always check operation with only the HMI Simulator first. The Sysmac Studio comes with a Simulator that simulates HMI functions.


#### Procedure

Use the following procedure to start the Sysmac Studio and perform debugging.

- **1** Start the Sysmac Studio and create a project.
- **2** Create the HMI application.
- **3** Select **Build HMI** from the Project Menu to build the project.
- 4 Select Start NA Simulation from the Simulation Menu.




The Simulator starts.





#### **Additional Information**

If the project is not yet built, it is built automatically.





#### 7-1-5 Offline Debugging with the Controller Simulator

You can perform debugging with the HMI Simulator connected online to the Controller Simulator. This allows you to debug the project while the Controller program is actually running.

After you complete checking operation with the HMI Simulator alone, check operation that includes the Controller program. The Sysmac Studio enables integrated debugging of the Controller program and the HMI application by connecting the Controller Simulator to the HMI Simulator.

You can perform debugging with the HMI Simulator and Controller Simulator connected when either the HMI or the Controller is selected, but the restrictions depend on which is selected, as described below. You cannot change a device while debugging is in progress.

Starting When the HMI Is Selected

You cannot use the debugging functions and Simulator control functions of the Controller. The only Controller debugging function you can use is monitoring in the Watch Tab Page.

Starting When the Controller Is Selected

You cannot use the debugging functions of the HMI. The only HMI debugging function you can use is monitoring in the Watch Tab Page.

7

#### Procedure


Use the following procedure to start the Sysmac Studio and perform debugging.

- **1** Start the Sysmac Studio and create a project.
- **2** Create the Controller program.
- **3** Create the HMI application.
- 4 Select **Build HMI** from the Project Menu to build the project.
- 5 Select *Run with Controller Simulator* from the Simulation Menu.

	teri MA Simulation IGU NA Simulation teo Execution teo Execution teo Exe	55 5475-65 722 721	( <u>н</u> (), (),			LNLM M
	teoilt		TTA		100.00	
			5 T 5 T 4	1 1 1 1		
and the second se						
		SER-F13				
Configurations and Setup		=0	-	and the second second	100	C 121
P Device References	el/Eles: Breakpoint	10	1 1		Euttons	
	lear 49 Breskpoints	Col-Shift-79			b-langs	-
a Ci Hall Settings	un with Controller Simula	bolf	1		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
- III. Sacurity Settings A. Language Settings		The second second			<ul> <li>Shapes</li> </ul>	_

#### **Additional Information**

If there is more than one Controller in the project, the window will be displayed for the Controller that is currently connected. If you select a Controller for which variables are not mapped, an error will occur and starting the Simulator will be canceled.



The Controller Simulator is started and the HMI Simulator is displayed.

#### Additional Information

If the project is not yet built, the entire project including the Controller is built automatically. If a building error occurs for the Controller, a dialog box is displayed to notify you of the error. Change the device to the relevant Controller, build the project, and check the error.

**6** To stop the simulation, click *Stop NA Simulation* from the Simulation Menu. The Controller Simulator and the HMI Simulator are stopped.



# Additional Information

You can also start online debugging when the Controller is selected in the project. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details.

7 Debugging

# 8

# **Synchronizing Projects**

This section describes how to synchronize the projects between the HMI and the Sysmac Studio.

8-1	Synchronizing Projects		
8-2	Downl	oading	8-5
	8-2-1	Downloading While Online	8-5
	8-2-2	Using Storage Media for Downloading	8-6
8-3	Uploa	ding	8-9
	8-3-1	Uploading Projects Online	8-9
	8-3-2	Uploading with Storage Media	8-11
	8-3-3	Relinking Internal Devices	8-15

# 8-1 Synchronizing Projects

Synchronization is used to transfer the project from the Sysmac Studio to the HMI.

The basic Sysmac Studio operations for synchronization generally apply to HMIs. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details.

This section describes differences in synchronization when an HMI is selected.

# Sufficiently check the operation of any project that you create before you start actual system operation.



### Precautions for Safe Use

Unexpected operation may result if you set inappropriate network configuration settings. Even if appropriate network configuration settings are set, confirm that the controlled system will not be adversely affected before you transfer the data.

## Precautions for Correct Use

Do not perform any other operations on the Sysmac Studio while the Synchronization Window is active. An error will occur and synchronization will fail.

# **Functional Differences When an HMI Is Selected**

The following differences exist in synchronization when an HMI is selected.

- · Detailed comparison is not supported.
- Algorithm checking is not supported. Therefore, there is no way to prevent mismatches in build dates that result from rebuilding.
- If the project version specified in the project is different from the version of the project in the HMI, the runtime files will always be transferred.
- The following synchronization options are provided.

Option	Default	When trans- fer is enabled	Description
Transfer source code to the NA device.	Selected.	Values written to HMI	Select this check box to transfer the source code.
Relink internal devices in the project (valid for Transfer From Device)	Selected.	Values written from HMI	If this check box is selected, global variables are automatically mapped to the Controller that is registered in the project when the project is uploaded.
Clear the present values of variables with Retain attribute.	Selected.	Values written to HMI	If this check box is selected, the present val- ues of Retain variables are cleared after the data is downloaded.
Clear alarm log data from memory	Selected.	Values written to HMI	If this check box is selected, the alarm log in non-volatile memory is cleared. If you have changed the user alarm settings, you cannot clear the selection of this check box.
Clear Data log data from memory	Selected.	Values written to HMI	If this check box is selected, the data log data in non-volatile memory is cleared. If you have changed the data logging settings, you cannot clear the selection of this check box.

• The following dialog box is displayed when you connect to the HMI if the version of the system program in the HMI is older than the version of the system program in the Sysmac Studio. You must update the system program before you can perform synchronization. Update the system program according to the displayed instructions.

Operating Sy	Operating System Version Mismatch				
	Project Operating System Version = 1.1.0				
Δ	Device Operating System Version = 1.0.0				
	The versions are incompatible.				
	Would you like to update the device to match the project?				
	OK Cancel				

### Precautions for Correct Use

- Projects that are downloaded with Sysmac Studio version 1.10 cannot be uploaded.
- Projects that are downloaded when the Transfer source code to the NA device Check Box is not selected cannot be uploaded.

# **Differences in Comparison Results**

The following differences apply to the comparison results.

### • Verification Results Example

The verification results are displayed as shown in the following example.

Column	Item
Source	Project name on the Sysmac Studio
Source Modified Date	The last time that the project was built on the Sysmac Studio
Target Modified Date	The last time that the HMI project was built on the Sysmac Studio
Target	HMI project name
Detailed Comparison	This column is not used when an HMI is selected.

### • Verification Units

The units for comparison that are shown in the Synchronization Window are listed in the following table.

Synchronization data name	Level	Qty	Detailed comparison	Remarks
HMI name	1	1	None	
Project	2	1	None	
Pages	3	1	None	
Page*	4	N	None	
Subroutines	3	1	None	
SubroutineGroup*	4	N	None	
Variables	3	1	None	
Global Events	3	1	None	
Alarms	3	1	None	
Data Groups	3	1	None	
Data logging	3	1	None	
Recipe Template	3	1	None	
Project Security	3	1	None	
Troubleshooter	3	1	None	
Languages	3	1	None	
*	4	N	None	
Settings	3	1	None	
HMI Settings	4	1	None	
User Data	3	1	None	
User Accounts	4	1	None	
Recipe Instances	4	N	None	
Resource Files	3	1	None	
Documents	4	1	None	
* *	5	N	None	
Images	4	1	None	
* *	5	N	None	
Videos	4	1	None	
* *	5	N	None	
Runtime Files	3	1	None	

# 8-2 Downloading

To execute a project that you created in the HMI, you must use synchronization to download the project. This section describes how to download the project.

# 8-2-1 Downloading While Online


You can use the following procedure to download the project while the Sysmac Studio is online.

- **1** Place the Sysmac Studio online with the HMI. Refer to Section 6 Connecting to the HMI for details.
- 2 Click 🐚 on the Toolbar. Or, select Synchronization NA Device from the HMI Menu.
- **3** The project on the Sysmac Studio is compared with the project in the HMI and the Synchronization Window is displayed.

Synchronization			
Same Subjective Scription Subjective Scription Reference Acciption Scription Reference Acciption Scription Particle Metallione Particle Metallione Acciption Scription Particle Metallione Acciption Scription Particle Metallione Acciption Scription Acciption Scription Acciption	Source Griefins Data Tanget Mindelan Char Statu Jawa Stranget Mindelan Char Statu Jawa Stranget Mindelan Char Statu Jawa Stranget Status Status Status Status Status Status Status Status Status	Dargut V Salana daran Dargandi Manakaran Ad	Detailed Georges Leet

4

Select the items to download and select the options as required. Click the **Transfer to Device** Button. The data is downloaded and the HMI is restarted.



# 8-2-2 Using Storage Media for Downloading

With an HMI, you can perform product downloads with storage media.

- 1 Insert an SD Memory Card or USB memory device to use for the download into the computer.
- 2 Select *Media Device Synchronization* from the HMI Menu.



Select the file to use for the download and click the **OK** Button.

Synchronize with Media Device					
Media Folder	D:¥	Browse-			
Available Files	HMI <u>N</u> A_2014_10_01.nabin HMI <u>N</u> A5_0.nabin				
Filename	HMI_NA5_0.nabin				
	ОК	Cancel			

**4** The project on the Sysmac Studio is compared with the project in the storage media and the Synchronization Window is displayed.

Synchrönisation					
Source Source Modified Dat	Target Modified Date Target Detailed Com	parison			
▼ Subroutines	▼ Subroutines				
SubroutineGroup0 2014/10/09 17:59:14	2014/10/09 17:50:16 SubroutineGroup0				
Giobal Events 2014/10/09 17:59:14	2014/10/09 17:50:16 Global Events				
Alarms 2014/10/09 17:59:14	2014/10/09 17:50:17 Alarms				
Recipe Templates 2014/10/09 17:59:14	2014/10/09 17:50:17 Recipe Templates				
Project Security 2014/10/09 17:59:14	2014/10/09 17:50:16 Project Security				
■ ▼ Linguages	▼ Languages				
English (United State 2014/10/09 17:59:14					
▼ Subroutines           . SubroutineGroup0         2014/10/09 17:59:14           Global Events         2014/10/09 17:59:14           Alarms         2014/10/09 17:59:14           Recipe Templates         2014/10/09 17:59:14           Wingers         2014/10/09 17:59:14           Project Security         2014/10/09 17:59:14           Visitings         2014/10/09 17:59:14           Visitings         2014/10/09 17:59:14           Viser Data         2014/10/09 17:59:14           Viser Data         2014/10/09 17:59:14           Recipe Instances         2014/10/09 17:59:14           Viser Subranes         2014/10/09 17:59:14           Viser Joban         2014/10/09 17:59:14	▼ Settings				
HML Settings 2014/10/09 17:59:16 ▼ User Data	2014/10/09 17:50:18 HMI Settings ▼ User Deta				
User Data User Accounts 2014/10/09 17:59:14	▼ User Deta 2014/10/09 17:50:16 User Accounts				
Recipe Instances 2014/10/09 17:59:14	2014/10/09 17:50:16 Diser Accounts 2014/10/09 17:50:16 Recipe Instances				
Resource Files	Z014/10/09/17:0010 Recipe instances ▼ Resource Files				
▼ Images	▼ Mesource raes. ▼ Images				
10.bmp ,2014/04/02 15:24:27	* images 114/04/02 15:24:27 10.bmp				
	2014/04/02 12:02:43 9.bmp				
	2014/10/07 W-12/02 Runtime File				
		and a second sec			
Legend: Synchronized Edists only on o					
Some the HMI Project source code on the NA Device (required for uploading the project)					
😰 Relink internal devices in the project (valid for Transfer From Device)					
116 16-101	Tracke TO Media Devide Tracke Total Media Devide Recentiging Advance				


5

Click the Transfer to Device Button to transfer the project to the storage media.

**6** Insert the storage media into the HMI, display the Device System Menu, and touch the **Transfer Operations** Button.



7 Touch the Transfer User Program to HMI Button.



8 Select the project to transfer and touch the **Transfer to HMI** Button to download the selected project to the HMI.

ansfer User Prog	gram To HMI		Back
Source Media	USB Storage		•
\USBDisk			
Name		Last modified	
HMI_NA5_0.nabin		2014-06-05-18:19:54	
			_
Transfer to HMI			


# 8-3 Uploading

To edit the project in an HMI on the Sysmac Studio, you must use synchronization to upload the project. This section describes how to upload the project.


# 8-3-1 Uploading Projects Online

You can use the following procedure to upload a project while the Sysmac Studio is online.

- **1** Place the Sysmac Studio online with the HMI. Refer to Section 6 Connecting to the HMI for details.
- 2 Click the (Synchronize) Button on the Toolbar. Or, select **Synchronization NA Device** from the HMI Menu.
- **3** The project on the Sysmac Studio is compared with the project in the HMI and the Synchronization Window is displayed.



- 4
- Select the items to upload and select the options as required.




## Precautions for Correct Use

When a project is uploaded, the internal devices are not linked. In this condition, you will not be able to perform offline debugging with the Controller Simulator, or variable mapping.

Refer to 8-3-3 *Relinking Internal Devices* on page 8-15 for information on how to relink internal devices.

**5** Click the **Transfer To PC** Button. The following confirmation message for overwriting is displayed. Click the **Yes** Button.



The project is uploaded and the changes are applied to the open project.



# 8-3-2 Uploading with Storage Media

With an HMI, you can perform project synchronization with storage media.

- 1 Insert the SD Memory Card or USB memory device to use for the upload into the computer.
- **2** Display the Device System Menu and touch the **Transfer Operations** Button.




**3** Touch the **Transfer User Program from HMI** Button.

Transfer Operations					
4					
Transfer User	Transfer User	Transfer Data To	Transfer Data From		
Program To HMI	Program From HMI	HMI	HMI		

4 Specify the destination media and file name and touch the **Transfer from HMI** Button. The project is uploaded to the specified media.

ransfer User Program From HMI			
Destination Media	USB		-
<b>\USBDisk</b>		-	
Name		Last modified	
File Name		N 04 11	_
File Name	HMI_NA_2014_10	J_01.nabin	
= Transfer From HM	I		

**5** Insert an SD Memory Card or USB memory device into the computer and select **Synchroniza***tion - Media Device* from the HMI Menu.



**6** Specify the file name on the media specified for the upload and click the **OK** Button.

Synchronize with Media Device					
Media Folder	D:¥	Browse-			
Available Files	HMI <u>N</u> A_2014_10_01.nabin HMI <u>N</u> A5_0.nabin				
Filename	HMI_NA5_0.nabin	1			
	OK	Cancel			

7 The project on the Sysmac Studio is compared with the project in the storage media and the Synchronization Window is displayed.


	▼ Salaraulines		▼ Submedimes	
	Solara dina Ganapat	2014/10/03 1621-12 2014/10/03 1666607	Sub- mile Group	
	Gislasi Sutanta	2014/10/03 16:31:13 2014/10/03 16:64.07	Giologia Systemator	
	Aleres	2014/10/03 1651-13 2014/10/03 1644/07	Alaram	
	- Data Logging	2014/14/08 16:104 2014/16/08 16:448	Dela Leguinig	
	- Martin Lagrand		in the second se	
	Project Security	2014/19/08 10:5143 2014/10/08 10:49/07	Project Security	
	T Languages		▼Languages	
		2004/10/09 10:1143 2014/10/09 10:4427	L Gragesh (United Sea	
	Settings		T Serings	
	- IIII Settings	2014/10/03 18/51/15 2014/10/01 11/22/57	Hill Sections	
1 1				
	- Liver Accounts	2314/14/08 16/11/13 2014/10/08 16:4462	User Arcounts	
	T Resource Films		w Nescence Films	
	▼ Invegel		₩ Imageli	
	1übenp	2014/09/29 18:55:87 2014/09/29 18:55:87	_ 10.hrap	
	Slomp	2014/05/29 18:55:37 2014/09/29 18:55:37	9.bmp	
	Rantime Files	2014/09/29 17:05:11 2014/09/29 17:05:11	Runtime Files	
synd	Rios-298	so sta univ en ena sute Not checke	-st	
u tihe tri Ni imbiri	fill Projaci source cash: nal devices in the projec	om ime NA Denica (raquined for opticating the cutraind for Transfet From Device)	e projecti)	
			r From Media Device	Class

# Precautions for Correct Use

When a project is uploaded, the internal devices are not linked. In this condition, you will not be able to perform offline debugging with the Controller Simulator or variable mapping.

Refer to 8-3-3 *Relinking Internal Devices* on page 8-15 for information on how to relink internal devices

8 Click the **Transfer From Media** Button. The following confirmation message for overwriting is displayed. Click the **Yes** Button.



The project is uploaded and the changes are applied to the open project.

Synchronis	adon				
	Source	Source Monified DateTarget Modified Date	Forget	Detailed Comparison	
			Synchronizing - 0%		
					Cancel

# 8-3-3 Relinking Internal Devices

When a project is uploaded, the internal devices will not be linked and there will be restrictions on operations related to the Controller, such as variable mapping. This section describes how to relink a Controller in the project.


# **Relinking while Uploading**

If you select the *Relinking to Internal Devices* Check Box and upload the project, the internal devices in the project that was uploaded are automatically relinked to the Controller of the same name. If there is no Controller of the same name in the project, the Controller is registered as an unlinked Controller.

During relinking, the variables that are registered in the Controller in the project are compared with the variables that are not registered in the Controller in the project. If no errors are detected, relinking is completed.

# **Relinking after Uploading**


If you do not select the *Relinking to Internal Devices* Check Box and upload the project, the internal devices in the project that was uploaded will not be linked to the Controller's project.



Use the following procedure to link the unlinked Controller with the Controller in the project.

**1** Place the Sysmac Studio offline from the HMI. Refer to Section 6 Connecting to the HMI for details.

2 Open **Device References** under **Configurations and Setup** in the Multiview Explorer and double-click the unlinked Controller.



**3** Select the Controller to link in the *Internal Devices* Area and click the **Link to Internal Device** Button.


🙀 new_Controller_0 (Unlink-	* X	
V Dense Garaganación	-	
- Device Configuration		Communications Configuration
Device Name	new_Controller_D	Use the IP address configured on the internal device
Device Vendor		IP Address 192 . 168 . 2501
Device Series		Timeout 2 \$second
Communication Driver		Communication Error Indication
_ _ Internal Device		
A This device reference is	s not linked to an internal o	device
E. S. J. Meine Dent	new_Controller_0	
8	new_Controller_0	

4 The variables that are registered to the specified Controller are compared with the variables that are registered to the unlinked Controller. If no errors are detected, relinking is completed.

### Additional Information

If any variables that are registered to the destination Controller do not agree with the variables that are registered to the unlinked Controller when relinking is executed, the following dialog box is displayed.

Modify the global variables in the Controller and in the HMI according to the information provided in the dialog box.



Letter	Item	Description	Remarks
(a)	Conflict list	Lists all of the conflicts.	
(b)	Cancel	Cancels relinking.	
(C)	Continue	Leaves the conflicts and completes relinking.	

# 9

# **Reusing Objects**

This section describes how to reuse objects.

9-1	Reusi	ng Objects
9-2	IAGs	
	9-2-1	Differences when an IAG Project Is Selected
	9-2-2	Creating an IAG
	9-2-3	Using IAGs
9-3	Custo	m Objects
9-3	<b>Custo</b> 9-3-1	-
9-3	9-3-1	•
9-3	9-3-1	Objects That You Can Register as Custom Objects

# 9-1 Reusing Objects

The Sysmac Studio provides the following two functions to simplify and increase the speed of the development of HMI applications.

- Intelligent application gadgets (IAGs)
- · Custom objects

IAGs and custom objects are different in the following ways.

- You can distribute IAGs to other parties. You can use custom objects only on the Sysmac Studio.
- You must treat IAGs as IAGs even after you place them on pages. You treat custom objects like any other objects after you place them on pages.
- After you place an IAG on a page, you can change only the properties of the IAG objects. You can change any of the attributes of custom objects.
- You can hide the contents of subroutines in IAGs. Therefore, you can provide IAGs to other parties without disclosing technology.

You can customize objects yourself and create reusable objects that combine other objects.

# 9-2 IAGs

An IAG is a library object that you can distribute to other parties. To create a new IAG, you must create it in an IAG project. This section describes the procedures to create and use IAGs.

# 9-2-1 Differences when an IAG Project Is Selected

Even when an IAG project is selected, basic operations are generally the same as for a standard project. However, the following items are different.

# Items in the Multiview Explorer

The structure of the Multiview Explorer when you select an IAG project is shown below. You can edit the user-defined variables, subroutines, and other resources in an IAG from the menu that is displayed when you right-click the IAG.

Resources

Multiview Explorer	<b>, 4</b>
E	100
✓ Configurations and Setup	1. A.
Language Settings	
呵 IAG Collection Settin	ngs
▼ HMI	
🕨 🕨 🖬 IAGs	
🕨 🖿 Data	
► 🗇 Resources	
Configurations and Setup	HN
Language Settings	IAGs
IAG Collection Settings	Data

# Toolbar

This section describes the differences in the Toolbar compared with a standard project.

### • Insert Menu



Item	Description	Remarks
IAG	Inserts a new IAG in IAGs.	


# • Project Menu

Sample Project [IAG] - IA	G_Device_	0 - Sysmac Sti	udic	
File Edit View Insert	Project	Simulation	Tools	Help
	6uild [	AGs	FS	-
	Publis	h 14G Collectio	on	<u>P</u>

Item	Description	Remarks
Build IAGs	Builds all of the IAGs.	
Publish IAG Collection	Saves an IAG collection in a file format that you can use in a standard project.	

# Language Settings

You can set the languages to use in the IAG.



Symbol	Item	Description	Remarks
(a)	Default language	Sets the language that is selected by default.	
(b)	Defined Languages	Displays the languages that you select.	
(c)	>	This button moves a selected language to the defined language list.	
(d)	<	This button deletes a selected language from the defined language list.	
(e)	Available Languages	Displays the languages that you can select.	

# IAG Collection Settings

You can make the following settings for an IAG collection.


S New Project [IAG] - IAG_Device_0 - Sys	mac Studio		
$\underline{E}ile = \underline{E}dit - \underline{V}iew  \underline{I}nsert - \underline{E}roject - \underline{S}im$	ulation <u>T</u> ools <u>H</u> el	p	
XIIISCE	* 2 8 8		
Multiview Explorer 🚽 🖣 🔤 🗛 🖉	Collection Settings $\times$		
	E IAG	Collection Settings	
Configurations and Setup	Name	New Project	_(a)
14G Collection Settings	Version	1.00	-(b)
HMI	Description	Sample Project	-(c)
i ▶ ⊞ Data	Publisher	OMRON	(d)
👔 🕨 🗇 Resources	Visible By Defau		-(d) <sup>-</sup> (e)

Symbol	Item	Description	Remarks
(a)	Name	Sets the name.	
(b)	Version	Sets the version.	
(C)	Description	Sets a description.	
(d)	Publisher	Sets the publisher.	
(e)	Visible By Default	Select this check box to display the IAG collection in the Toolbox when the IAG collection is imported into the Sysmac Studio.	

# IAGs

The following tab page is used to create an IAG. The procedures are generally the same as for standard projects, except for the following differences.

- There are no global variables. Only the user variables for each IAG can be used.
- You cannot set page animations.
- You cannot use functions that cannot be placed on a page, such as global events and recipes.
- You cannot use Trend Graph or Broken-line Graph objects and user-created IAGs.




# **User Variables**

For IAG, only the variables for each IAG can be used. The variables that are defined for each IAG are called user variables.

You can create user variables that are internal variables and user variables that are In/Out variables.


### • Editing User Variables

To edit user variables, right-click IAG and select View User Variables from the menu.



## Internal Variables


The internal variables are used only within the IAG. The internal variables are displayed in the user variable table, but you cannot access them when you use the IAG.



Letter	Item	Description	Remarks
а	Internals or In/Out	Changes the display between internal variables and In/Out variables.	
b	Name	Sets the variable name.	
С	Data Type	Sets the data type.	
d	Initial Value	Sets the initial value.	
е	Comment	Sets a comment.	

# • In/Out Variables

In/Out variables are exposed externally. You can access the In/Out variables when you use the IAG.



Letter	Item	Description	Remarks
а	Internals or In/Out	Changes the display between internal variables	
		and In/Out variables.	
b	Name	Sets the variable name.	
С	Data Type	Sets the data type.	
d	In/Out	If you set an In/Out variable, you can read and	
		write the variable when you use the IAG.	
		If you set an input variable, you can only write	
		the variable when you use the IAG.	
е	Initial Value	Sets the initial value.	
f	Comment	Sets a comment.	

# Data Types

You can set the data types to use in the IAG. The procedures are the same as for a standard project.

📴 Data Types	×					-
root						•
Structures		Name	Base Type	I Co	omment	I I
Enumerated	•	RGB	STRUCT			
		Red	Boolean			
		Green	Boolean			
		Blue	Boolean			

# Resources

You can set the resources to use in the IAG. The procedures are the same as for a standard project.

Root X	🟭 General Strin	gs		
	Name String0 String1	Resource ID String0 String1	Ervitan (United States) Set Button Rel Button On	
	Gi Int at			

9

9-2 IAGs

# 9-2-2 Creating an IAG

This section describes how to create an IAG.

The size of the IAG will be the size of the page when the IAG is created. Any objects that are positioned outside of the page are ignored.

**1** Create a new project and set the project type to *IAG Project*.

offline	Project Pro	operties
New Project	Project name	New Project
Open Project	Author	
import	Comment	Select IAG Project.
Pipon,	Туре	Standard Project
A Online	Select L	IAG Project
4 Connect to Controller	Category	Controller
	Device	NJ501 💌 - 1500 🔍
License	Version	
	1	Greate


# 2 Click the Create Button.

An IAG project is created and the following window is displayed.

Sample Piojen (IAG) - IAG, Device	.0 - Sysmac Studio	6 8 🜌
Bills Boliv Wew Weekt Ricciect	i Simulation Ionis Usla	
	▖▖▖▖▖▖▖▖▖	
Muste ex po arer ● ● ● Cor figurateria anu Secup ● HMT	E.id Function Program   Location	Portons     Portons     Lamos     Shapes     Shape
T Fiter 2	AT Output Sund	

3

Right-click the IAG, select *View User Variables* from the menu, and then register the required user variables.



**4** Create the IAG with the same methods as for a normal page.


5 Select Build IAGs from the Project Menu.




6 Select *Publish IAG Collection* from the Project Menu.



7 Click the **Browse** Button (...) and specify where to save the collection.





8 Click the **Publish** Button. The IAG collection is created.


# 9-2-3 Using IAGs

This section describes how to use the IAGs that you create when you edit a standard project.

To use IAGs, you must first register them in the Toolbox. After you register them in the Toolbox, you can drag them to the page to use them in the same way as for other objects.

# **Registering IAGs**

1 Select IAG Collections Manager from the Project Menu.




2 Click the + Button. Select the IAG file and click the **Open** Button.

Add LAG Collection			-
OO- · Libraries	• Documents • •	49 Search Documents	p
Organize 🔻 🔤 New folder		)= • 🖪 G	
🖈 Favorites	Documents library Includes: 2 locations	Arrange by: Folder 🝷	
Downloads	Name	Date modified Type	
🗐 Recent Places	Sample.iag	6/5/2014 5:06 PM IAG File	
Computer			
👾 Network 🔶 🛨	4 [		F
File <u>n</u> ar	me: Sample.iag		)   

9-2


- 3
  - Select the *Show in Toolbox* Check Boxes for the IAG collections that you want to display in the Toolbox.



- 4
- The IAGs for the selected check boxes are displayed in the Toolbox.




**5** Drag the IAG to the page.



**6** Double-click the IAG and set the properties.

Set global variables or constants for the variables that are set as In/Out variables.



# 9-3 Custom Objects

You can register the objects that you use most frequently to increase your productivity. This section describes the procedures to create and use custom objects.

# 9-3-1 Objects That You Can Register as Custom Objects


An object must meet the following conditions before you can register it as a custom object.


- You can register only individual objects.
   You cannot register more than one object as a custom object. If you want to register more than one object as a custom object, group the objects into one object first.
- The object cannot be a user-defined IAG. You cannot register a user-defined IAG or a group that contains a user-defined IAG as a custom object.

# 9-3-2 Creating Custom Objects

Use the following procedure to create a custom object.


**1** Create a standard project and place the objects to register as a custom object on the page.





**2** Group the objects to register the group as a custom object.

**3** Right-click the group of objects and select **Add to Toolbox** from the menu.



**4** The group is added as a custom object under **Custom** in the Toolbox. The displayed name is the name of the registered group or object.




# 9-3-3 Deleting Custom Objects

Use the following procedure to delete a registered custom object.

**1** Right-click the custom object to delete from the Toolbox. Select **Delete** from the menu.




- 2
  - A confirmation dialog box is displayed. Click the **Yes** Button.



# 9-3-4 Using Custom Objects

It is very easy to use a custom object. Just select the desired custom object in the Toolbox and drag it to the page. You can handle the custom objects on pages in the same ways as you handle normal objects.



# 10

# Connecting to HMIs from External Devices

This section describes how to connect to an HMI from an external device.

10-1 Acces	sing an HMI from an External Device	10-2
10-1-1	VNC	. 10-2
10-1-2	FTP	. 10-3

# 10-1 Accessing an HMI from an External Device

You can use the following two methods to access an NA-series Programmable Terminal from an external device.

- · Remote monitoring and control with VNC
- · File operations with FTP

#### Precautions for Correct Use


- Only password security is provided for using VNC and FTP. Sufficiently consider the network configuration in terms of security and implement any required measures to prevent unauthorized access.
- Use the same keyboard layout settings for the VNC client computer and the HMI. If the settings are not the same, different characters may results from the characters input from the VNC client.

### 10-1-1 VNC

You can enable VNC to use a VNC client to monitor and control HMI pages. You can also use a mode setting to prohibit controlling operation from a VNC client and allow only monitoring.

# **Setting Method**

Double-click HMI Settings under Configurations and Setup. Click the VNC Settings Button.



Select the Use Option for Enable VNC and change the setting of the Mode Box as required. Set a text string in the Password Box.

After you complete the settings, select **Build HMI** from the Project Menu. When building the project is completed, download the project to the HMI.

After the download is completed, you can access the HMI from a VNC client.



#### Additional Information


Refer to the relevant software manuals for the operating procedures of the VNC client.

### 10-1-2 FTP

You can enable the FTP server to use an FTP client to access files in the HMI. However, you can access only specific folder.

# **Setting Method**

Double-click HMI Settings under Configurations and Setup. Click the FTP Settings Button.



Select the Use Option. Set text strings for the login name and password.

After you complete the settings, select **Build HMI** from the Project Menu. When building the project is completed, download the project to the HMI.

After the download is completed, you can access the HMI from an FTP client.

#### Additional Information

Refer to the relevant software manuals for the operating procedures of the FTP client.

# 11

# **Other Functions**

This section describes other functions that the Sysmac Studio provides for HMIs.

11-1 Sysmac Studio Option Settings	11-2
11-2 Printing	11-4
11-2-1 Printable Items	.11-4

# **11-1 Sysmac Studio Option Settings**

The following Sysmac Studio option settings are related to HMIs.

- HMI Code Editor
- · HMI Page Editor

# HMI Code Editor

You can make settings to highlight text in the HMI Code Editor.

S Option				
Color Theme				
Ladder Editor				
ST Editor				
▼ HMI Code Edi	tor			
Color Selection	Global variables	R:180 G:0 B:90 🔻	(a)	
	Keywords	Blue 🔻	(u)	
	Comments	Green 🔻		
	Strings	Maroon 🔻		
	Breakpoints	Maroon 🗸		
	Collapsed text or region	Gray 🔻		
	Foreground text	Black 🔻		
	Background	White •		
		Reset to default settings	—— (b)	
▶ HMI Page Edi				
▶ Program Cheo				
Variables				
Comments for				
Synchronization				
	OK Can	cel		

Symbol	Item	Description	Remarks
(a)	Color Selections	Select the color for each item.	
(b)	Reset to default settings	This button resets the colors to the default settings.	

# HMI Page Editor

You can make settings for the grid in the HMI Page Editor.

S Option		×	
Color Them	e		
▶ Ladder Edit	or		
ST Editor			
► HMI Code E	ditor		
▼ HMI Page E	ditor		
Grid Settings	Grid Size	20	(a)
	Snap to Grid		
	Show Grid		
	Thickness	1	
	Color	DarkGray 🔻	
	Style		
	Opacity	50 🗘	
		Reset to default settings	(b)
▶ Program Ch	neck/Build		
Variables			
Comments	for Variables	and Data Types	
Synchroniza	ation		
	OK	Cancel	

Symbol	Item	Description	Remarks
(a)	Grid Settings	Make the settings for the grid.	
(b)	Reset to Defaults	Defaults This button restores the default grid	
		settings.	

# 11-1 Sysmac Studio Option Settings

# 11-2 Printing

This section describes the printing feature.

# 11-2-1 Printable Items

The following items can be printed. You can select the items to print.

láoma	Category	of project
Items	Standard	IAG
Device References	✓	
Variable Mapping	✓	
Pages	✓	
Page Subroutines	✓	
User Alarms	✓	
HMI Settings	✓	
Controller Events	✓	
Data Logging	✓	
Security Settings	✓	
Troubleshooter	✓	
Language Settings	✓	✓
Recipes	✓	
Data	✓	$\checkmark$
Global Events	✓	
Global Subroutines	✓	
Resources	✓	✓
IAG Collection Settings		✓
IAGs		✓

## Additional Information

For printing features that are unique to devices other than the HMI, refer to the relevant manuals.

For details on the settings and the procedure for printing, refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).

# A

# Appendices

The appendices provide information on supported file formats and other information.

A-1	Event	s and Actions	<b>A-2</b>
A-2	Suppo	orted Formats	A-5
A-3	Differ	ences between the Physical HMI and Simulator	<b>A</b> -7
A-4	Versio	on Upgrade History	<b>A-</b> 8
	A-4-1	Version Upgrade History for Sysmac Studio and Runtime	A-8
	A-4-2	Version Upgrade History for Sysmac Studio Only	A-9
	A-4-3	Sysmac Studio Corresponding Versions	A-10
A-5	Preca	utions for Version Upgrades	A-11

Α

# A-1 Events and Actions

# Events

Name	Description		Page	Objects	User alarms	IAG
Acknowledged	The event occurs when the user alarm is acknowledged.	_		_	Yes	
Checked	The event occurs when the check box is selected.	_	_	Yes	_	_
Cleared	The event occurs when the user alarm is cleared.	_			Yes	_
Click <sup>*1</sup>	The event occurs when the object is tapped.	—	—	Yes	—	—
Condition	The event occurs when the set condition is met.	Yes	Yes	_	_	Yes
F1 Key Click <sup>*1</sup>	The event occurs when the <b>F1</b> Key is tapped.	Yes	Yes		—	_
F1 Key Press	The event occurs while the <b>F1</b> Key is held down.	Yes	Yes	_	—	_
F1 Key Release <sup>*1</sup>	The event occurs when the <b>F1</b> Key is released.	Yes	Yes	_	_	_
F2 Key Click <sup>*1</sup>	The event occurs when the <b>F2</b> Key is tapped.	Yes	Yes	_	_	_
F2 Key Press	The event occurs while the <b>F2</b> Key is held down.	Yes	Yes	_	_	_
F2 Key Release <sup>*1</sup>	The event occurs when the <b>F2</b> Key is released.	Yes	Yes	_	_	
F3 Key Click <sup>*1</sup>	The event occurs when the <b>F3</b> Key is tapped.	Yes	Yes			
F3 Key Press	The event occurs while the <b>F3</b> Key is held down.	Yes	Yes	_	_	
F3 Key Release <sup>*1</sup>	The event occurs when the <b>F3</b> Key is released.	Yes	Yes	_	—	_
Interval	The event occurs at the specified interval.	Yes	_	-	—	
Page Displayed	The event occurs while the page is displayed.	—	Yes	—	—	—
Page Hidden	The event occurs when the page is hidden.	—	Yes	_	—	
Press	The event occurs while the object is held down.	—	-	Yes	—	_
Project Initialization <sup>*2</sup>	The event occurs when the project is initial- ized.	Yes	_	_	_	—
Raised	The event occurs when the user alarm occurs.	_	_	_	Yes	_
Release <sup>*1</sup>	The event occurs when the object is released.	_	_	Yes	_	
Selection Changed	The event occurs when the item selected in the list changes.	_	_	Yes	_	
Unchecked	The event occurs when the check box selec- tion is cleared.	_		Yes	—	_

\*1. For both *Click* and *Release*, the event occurs when the object is released, but the operation when the page is changed is different. If the page changes when an object set for *Click* is touched but not yet released, the event does not occur. If the page changes when an object set for *Release* is touched but not yet released, the event does occur.

\*2. The results of accessing external variables during project initialization immediately after startup are not always dependable. Do not access external variables during project initialization.

# Actions

Action	Action Description		Page	Objects	User alarms	IAG
BuzzerOff	Turns OFF the buzzer.	Yes	Yes	Yes	Yes	Yes
BuzzerOn	Turns ON the buzzer.	Yes	Yes	Yes	Yes	Yes
BuzzerOneShot *1	Turns ON the buzzer that beeps for only 0.25 second.	Yes	Yes	Yes	Yes	Yes
CallSubroutine	Executes a subroutine registered as a global subroutine or page subroutine.	Yes <sup>*2</sup>	Yes	Yes	Yes <sup>*2</sup>	Yes
ClearUserAlarmLog	Clears the user alarm log.	Yes	Yes	Yes	Yes	Yes
ClosePage	Closes the specified page.	Yes	Yes	Yes	Yes	Yes
DecreaseVariable	Subtracts the specified value from the specified variable.	Yes	Yes	Yes	Yes	Yes
EjectSDMemory	Enables removing the SD Memory Card.	Yes	Yes	Yes	Yes	Yes
EnableInputOperation	Enables or disables inputs on the touch panel.	Yes	Yes	Yes	Yes	Yes
EndSyncLock <sup>*3</sup>	Ends a critical section.	Yes				
IncreaseVariable	Adds the specified value to the specified variable.	Yes	Yes	Yes	Yes	Yes
InvertVariable	Inverts the value of the specified Boolean variable.	Yes	Yes	Yes	Yes	Yes
Login	Displays the login page.	Yes	Yes	Yes	Yes	Yes
Logout	Logs out the user.	Yes	Yes	Yes	Yes	Yes
ResetVariable	Changes the value of the specified Boolean variable to False.	Yes	Yes	Yes	Yes	Yes
SaveUserAlarmLog- ToFile	Saves the user alarm log to a file.	Yes	Yes	Yes	Yes	Yes
SetInputFocus	Sets the data input focus.		Yes	Yes		Yes
SetLanguage	Changes the project language set- tings.	Yes	Yes	Yes	Yes	Yes
SetVariable	Sets the value of the specified vari- able to a specified value.	Yes	Yes	Yes	Yes	Yes
ShowAlarmPage	Displays the page set in a specified User Alarm.	Yes	Yes	Yes	Yes	
ShowDocu- ment(FULL SCREEN)	Displays a PDF or other file full screen.	Yes	Yes	Yes	Yes	Yes
ShowDocument(Win- dow)	Displays a PDF or other file in a window.	Yes	Yes	Yes	Yes	Yes
ShowPage <sup>*4</sup>	Displays a page.	Yes	Yes	Yes	Yes	Yes
ShowPreviousPage <sup>*4</sup>	Displays the most recently dis- played page.	Yes	Yes	Yes	Yes	Yes
ShowSystemMenu	Displays the System Menu.	Yes	Yes	Yes	Yes	Yes
ShowTroubleshooter	Displays the NJ/NX Trouble- shooter.	Yes	Yes	Yes	Yes	
StartDataLogging	Starts data logging.	Yes	Yes	Yes	Yes	Yes
StopDataLogging	Stops data logging.	Yes	Yes	Yes	Yes	Yes
SyncLock <sup>*3</sup>	Starts a critical section.	Yes				

Action	Description	Global events	Page	Objects	User alarms	IAG
TriggerEvent	Sets the UserEvents for IAG objects.					Yes

\*1. When multiple actions attempt to simultaneously beep buzzers, the last buzzer demand overwrites the previous demands.

- \*2. You cannot execute page subroutines for global events or user alarms.
- \*3. The SyncLock and EndSyncLock actions must be specified as a pair.
- \*4. If you execute an action with a Momentary Button, use a Click or Release event.

#### Additional Information

If the same variable might be accessed simultaneously from different locations, such as for simultaneous execution of subroutines, perform exclusive control to prevent simultaneous access.

For a section where exclusive control is required, specify the start of the section with the SyncLock action and the end of the section with the EndSyncLock action. This defines the section between these two actions as a critical section. Until the execution of the critical section is completed, other processing will not be executed, therefore achieving exclusive control.

# A-2 Supported Formats

The HMI objects support the following formats. However, it may not be possible to display some files even if the file format is supported.

# Image Files

The following formats are supported.

Format name	Exten- sion	Specifications
Microsoft Windows Bit-	BMP	1, 4, 8, 16, 24, or 32-bit
map Image		Uncompressed or RLE compression
Graphics Interchange	GIF	1, 4, or 8-bit
Format		Transparent GIF or interlaced GIF
JFIF or EXIF	JPG	8-bit gray scale
		24-bit/basic DCT or progressive DCT
Portable Network Graph-	PNG	1, 4, 8, or 24-bit
ics		Transparency is supported.
Scalable Vector Graphics	SVG	SVG 1.0 is supported.
Extensible Application	XAML	
Markup Language		
Drawing Exchange For-	DXF	R12 and older are supported.
mat		

# Video

The following formats are supported. However, only progressive formats are supported. The maximum size of the file that can be registered in a project in Sysmac Studio is 100 MB.

Format name	Exten- sion	Specifications	Maximum resolution
MPEG-1	mpg	The MPEG-1 Video Stream format is not supported.	768×480
MPEG-2	mpg	Main Profile Low, Main, and High 1440	1280×720
		MPEG-2 TS is not supported.	
MPEG-4 Part 2	mp4	Simple Profile L0, L1, L2, and L3	1280×720
		Advanced Simple Profile L0, L1, L2, L3, L4, and L5	
		Global motion compensation is not supported.	
MPEG-4 Part 10	mp4	Baseline Profile L1, L1.2, L1.3, L2, L2.2, and L3	1280×720
(H.264)		Main Profile L1, L1.2, L1.3, L2, L2.2, L3, L3.1, L3.2, and L4.1	
		High Profile L1, L1.2, L1.3, L2, L2.2, L3, L3.1, L3.2, and L4.1	
Windows Media Video	wmv	WMV9	240×160

Α

# Files Supported by Document Viewer

The Document Viewer can display the following files. The maximum size of file that can be registered in a project in Sysmac Studio is 16 MB.

Format name	Exten- sion	Specifications
Adobe Acrobat Document	PDF	
Microsoft Excel Books	xlsx	
Microsoft Excel 97-2003 Books	xls	
Microsoft Word Documents	docx	
Microsoft Word 97-2003 Docu-	doc	
ments		

# A-3 Differences between the Physical HMI and Simulator

The following differences exist between the physical HMI and Simulator.

- Trend Graph and Broken-line Graph Objects
   The Simulator does not update graphic displays. Fixed still images are displayed.
- ShowDocument Action and ShowDocument Function

The Simulator ignores parameters that specify the display positions and sizes for documents. To display documents, there must be a compatible application, such as Adobe Reader. The application used to display a document will not be exited when the Simulator is exited or the page is changed after the document is displayed. Exit the application manually.

- ShowTroubleshooter Action and ShowTroubleshooter Function The Simulator cannot display the NJ/NX Troubleshooter.
- \_HMI\_Brightness Variables The brightness of the screen does not change for the Simulator.

# A-4 Version Upgrade History

This section describes the additions and improvements that were made during version upgrades.

# A-4-1 Version Upgrade History for Sysmac Studio and Runtime

Sysmac Studio Version 1.10 and Runtime Version 1.00

Item	Description
First release	Support added for NA-series Programmable Terminals.

Sysmac Studio Version 1.11 and Runtime Version 1.01.

Item	Description
Uploading	Added support for uploading.
Expansion of popup page func- tionality	Expanded functionality for popup pages, such as the addition of display position specifications.
Expansion of IAG functionality	Expanded functionality for IAG variables. Also added support for a Condition event.
Expansion of settings for object	Expanded settings related to appearance, such as adding vertical text for
appearance	some objects.
Addition of data logging	Added Data Log and Trend Graph objects.

Sysmac Studio Version 1.13 and Runtime Version 1.02.

Item	Description
Support for NX7-series Control-	Added support for connection to NX7-series Controllers and NJ1-series
lers and NJ1-series Controllers	Controllers.
Addition of NJ/NX Troubleshooter	Added support for the NJ/NX Troubleshooter.
Addition of system variables for	Added _HMI_ConnectedVNCClientCount system variable that represents
VNC function	the number of clients that are connected to the HMI via VNC.

Sysmac Studio Version 1.14 and Runtime Version 1.03.

Item	Description	
Addition of broken-line graph func-	Added support for the broken-line graph function.	
tion		
Expansion of NJ/NX-series trouble-	Expanded functionality to display/delete event logs of the EtherCAT slave	
shooter functionality	units. Also added support that allows the troubleshooter to switch to a user	
	screen.	
Support for union/enumeration vari-	Enabled handling of union and enumeration variables of NJ/NX-series	
ables	Controllers, as well as inputting and displaying of them on HMIs.	
Support for creating new structure	Enabled creating new structure variables in the HMI.	
variables		
Expanded maximum number of	The number of global variables that can be registered in a connected	
variables registered in a connected	device was expanded to 30,000.	
device		
Expansion of IAG functionality	Enabled settings of user events for IAG.	
HMI Main Unit screen capture func-	Enabled capturing screens displayed on the HMI.	
tionality		
Custom keypad functionality	Enabled creation of system keypads with user-specified sizes. Also added	
	support for editing then to make a user-specific colored/shaped keypad.	

Item	Description
Tabbing order functionality	Enabled settings of order in which to tab around the input focus during
	data input
Scale conversion functionality for	Enabled scale conversion of numeric values.
numeric values	
Indirect addressing of text strings	Enabled indirect addressing of text strings that are displayed on objects.
Buzzer function	Enabled sounding a buzzer from the HMI when a button is pressed, and
	when an alarm occurs, or for other events.
Page jump from an alarm message	Enabled a page jump from an alarm screen specified in the Alarm Viewer
to a specified screen	to a specified screen.
Enhanced VNC functionality	Support for accesses control of VNC clients for various conditions.
Addition of tab control objects	Added tab control objects.
Support for background processing	Added support for background processing of subroutines to enable parallel
of subroutines	processing with updating of the display.

# A-4-2 Version Upgrade History for Sysmac Studio Only

#### Version 1.11

Item	Description
Support for copying settings	Added support to copy settings for user alarm tables, data sets, and recipe templates and paste them into external applications.
Improvement to property display method	Enabled displaying properties by double-clicking objects.

#### Version 1.13

Item	Description
Support to copy CJ/NJ variable	Added support to copy and paste variables directly from the Sysmac Studio
settings	and CX-Programmer.

#### Version 1.14

Item	Description	
Enhanced Search and Replace	Expanded target for the Search and Replace function to all the texts within	
functionality	a project.	
Support for the simulation mode	Enabled confirmation of indications such as the ON/OFF status of Lamps	
	and other objects.	
Sysmac Studio printing functionality	Enabled printing of information including project settings with HMI	
	selected.	
Direct text editing	Enabled direct editing of Labels on the Page Editor.	
Importing of vector graphic files	Enabled selecting of vector graphic files (e.g.,.XAML files) for the Image	
	files of objects.	
Improved Watch Tab Page	Enabled constant monitoring of global variables.	
Cross reference function	Enabled cross reference when the HMI is selected.	

# A-4-3 Sysmac Studio Corresponding Versions

Sysmac Studio	Runtime	System program
1.10	1.00	1.1.0
1.11 to 1.12	1.01*1	2.0.0
1.13	1.02*2	3.0.3
1.14	1.03 <sup>*3</sup>	4.1.6

\*1. The projects created in version 1.00 are converted to version 1.01.

\*2. The projects created in either version 1.00 or 1.01 are converted to version 1.02.


\*3. Projects created in version 1.00, 1.01, or 1.02 are converted to version 1.03.

# A-5 Precautions for Version Upgrades

Observe the following precautions for version upgrades.

#### Sysmac Studio Version 1.14 and Runtime Version 1.03

- User-defined enumerations on external devices are not assigned during version upgrades. You must redefine them.
- Some data type definition names are reserved for the data definitions of structures, unions, and numerations on the HMI. An error will occur if a reserved name is used, in which case you must change the name.



# Index

## Α

actions	4-32, A-3
adding an HMI	
alarms	1-9
animations	

# В

Battery	
breakpoints	
building	
0	

# С

Clear All Memory	3-24
Code Editor	4-45
Code Explorer	
Communications Setup	6-4
comparison results	8-4
connected devices	3-3
Continue	7-5
creating a project file	2-13
creating pages	
custom objects	

### D

data logging1-9	, 4-26
debugging functions	7-2
device references	3-3
device settings	3-11
differences between the physical HMI and Simulator .	A-7

# Ε

entry assistance	
entry methods for global variables	
events	1-7, A-2
events and actions	
examples of using objects	5-12
external	
external connected devices	3-3
external variables	3-8, 4-3, 4-5

## F

FINS settings	3-15
FTP	
FTP settings	
functional objects	5-2

# G

global events	
global subroutines	4-34, 4-39
global variables	4-3
graphic objects	5-4

## Η

HMI clock	3-21
HMI Code Editor	11-2
HMI Name	3-22
HMI Page Editor	11-3
HMI projects	1-4
HMI software configuration	1-4
HMI versions	2-15
HMI Write	3-23

## I

IAG collection settings	
IAG resources	4-36
IAGs	9-3, 9-5
importing device variables	3-6
internal connected devices	3-3
internal variables	4-3

# L

language settings	. 3-20, 9-4
language specifications	4-45

## Μ

main pages	4-14
mapping variables	3-7
memory specifications	1-6
menu	
Multiview Explorer	2-3

# Ν

NA-series Programmable Terminals	1-2
new user alarm	4-22
notation for CustomDisplayFormat	5-6
notation for expression	5-6
NTP settings	

# 0

	<b>F</b> 4
object attributes	
object list	5-2
objects	1-5, 5-2
offline comparison	4-49
offline debugging	7-6, 7-7
online connection	6-2
operating procedure	1-10
option settings	11-2

### Ρ

Page Explorer	2-4
page subroutines	4-39
pages	1-4
PDF file	5-12

popup pages4-14	
properties5-5	

## R

recipe	5-21
recipes	1-9, 4-28
registering IAGs	9-11
reset	3-25
resources	1-9, 4-35, 9-7

## S

search and replace	4-46
security settings	3-18
serial IDs	
simulator connection	6-2
step execution	7-4
step-in execution	7-4
step-out execution	7-5
storage media	
subroutine execution	4-40
subroutine group	4-34
subroutine variables	4-3, 4-12
subroutines	1-8, 4-39
supported formats	
synchronizing projects	8-2
system-defined variables	

# т

TCP/IP settings	3-12
Toolbar	
Toolbox	2-5
trend graph	5-16

# U

updating device variables	6
user alarm5-14	1

## V

variables	4-3
VNC	10-2
VNC settings	3-16
-	

## W

Watch Tab Page7-2	2
-------------------	---

Index

#### **OMRON** Corporation **Industrial Automation Company** Kyoto, JAPAN

#### Contact: www.ia.omron.com

# Regional Headquarters OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

# OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

# OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

#### Authorized Distributor:

© OMRON Corporation 2014 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. V118-E1-04